



## Service Manual

2170 ACADEMY, SANGER, CALIFORNIA 93657  
Ph. (209) 875-5563 Fax. (209) 875-7665 Telex 703797

Model # AFH-60-2-EC

Serial # 3061TK

'WISCONSIN CHEESEMAN'

1-24-91

Please have this information available when calling

70930001

Phone hours 8:00am to 12:00noon and 1:00pm to 5:00pm PDT

Monday through Friday



CONTENTS

FORMERS

[SECTION]

SAFETY.....	[1]
MACHINE ARRIVAL.....	[2]
INSTALLATION, SET-UP, AND START-UP.....	[3]
MAINTENANCE.....	[4]
MACHINE OPERATION.....	[5]
SET UP, SEQUENCE.....	[6]
ADJUSTMENTS.....	[7]
TROUBLE SHOOTING.....	[8]
PARTS DRAWINGS, RECOMMENDED SPARE PARTS LIST.....	[9]
MANUFACTURERS PARTS LISTS AND INSTRUCTIONS.....	END PAGES



SAFETY REQUIREMENTS  
FORMING MACHINES

All persons involved with this machine and its components whether operating, working on it, or near it, shall read these safety instructions, or be instructed by their supervisor or a qualified person. No one should be allowed to operate this equipment, or perform any type of maintenance, unless they have read these safety instructions or have been instructed by the above mentioned individuals.

---

GENERAL SAFETY INFORMATION:

---

This equipment has been designed to perform its purpose of operation. It has been guarded for the safety of the operator and those who work on it or near it.

While operating this equipment all guards must be in place. Guards, safety switches and interlocks shall not be bypassed for any reason. Any change or modification to the safety equipment of this machinery may produce a hazardous condition which could cause injury or be fatal to persons working with the machine. Operators, and maintenance personnel shall read the entire service manual. No one who has not read the service manual shall be allowed to operate the machinery.

---

SAFETY RULES:

---

1. NO ONE SHALL OPERATE THIS EQUIPMENT UNLESS THEY HAVE READ THE SERVICE MANUAL AND HAVE BEEN INSTRUCTED ON THE SAFETY AND OPERATION OF THE MACHINE BY A QUALIFIED INDIVIDUAL.
2. GUARDS MUST BE IN THEIR PROPER PLACE BEFORE STARTING OR RUNNING THE MACHINE.
3. THE OPERATOR SHOULD LOOK TO INSURE THAT THE MACHINE IS CLEAR BEFORE STARTING UP, AND POSSIBLY CALLING OUT A WARNING TO ALERT THAT THE MACHINE IS BEING STARTED.
4. DO NOT REACH INTO THE MACHINE UNTIL IT HAS COME TO A COMPLETE STOP.
5. ACTIVATE AN EMERGENCY STOP WHEN CLEARING JAMS OR REACHING INTO MACHINE.
6. TURN OFF POWER WHEN PERFORMING MAINTENANCE ON THE MACHINE.
7. WEAR SAFETY GLASSES AND GLOVES WHEN WORKING ON PRESSURIZED HOT GLUE SYSTEMS. (READ INSTRUCTIONAL MATERIAL PROVIDED BY HOT GLUE SYSTEMS MANUFACTURER)



## SAFETY REQUIREMENTS

### FORMING MACHINES

---

#### SAFETY RULES CONTINUED:

---

8. DO NOT WEAR LOOSE CLOTHING, JEWELRY WHEN OPERATING EQUIPMENT.
9. ON MACHINES WITH "AUTOMATIC RESTART" PERSONNEL SHALL STAY CLEAR OF MACHINE WHEN STOPPED, TO AVOID POSSIBLE INJURY UPON RESTART.
10. PERSONNEL SHALL BE FAMILIAR WITH THE LOCATION OF STOP SWITCHES OF THE MACHINE.
11. ELECTRICAL CABINETS AND BOXES SHALL NOT BE OPEN UNLESS POWER HAS BEEN DISCONNECTED.
12. DO NOT LEAVE TOOLS IN MACHINE WHEN RUNNING OR STARTING UP EQUIPMENT.
13. DO NOT USE MACHINE OR EQUIPMENT FOR ANY OTHER PURPOSE EXCEPT FOR THAT WHICH IT WAS DESIGNED.
14. DO NOT EXCEED THE SPEED FOR WHICH THE MACHINE WAS DESIGNED TO OPERATE AT.
15. ONLY QUALIFIED PERSONNEL SHALL ADJUST, REPAIR AND MAINTAIN THIS EQUIPMENT.

---

THE FOLLOWING IS A LIST OF AREAS THAT STRONG SAFETY PRECAUTION SHOULD BE OBSERVED:

---

- 1.1 DO NOT REACH INTO THE MACHINE AROUND HOPPERS WHILE MACHINE IS RUNNING.
- 1.2 DO NOT REACH INTO THE MACHINE THROUGH THE CARTON DISCHARGE OPENING.
- 1.3 USE CAUTION AROUND FLIGHT LUGS AND INFEED CONVEYOR LUGS AND TRACK.
- 1.4 ON HAND LOAD MACHINES KEEP CLEAR OF THE END OF THE LOAD TABLE WHEN IN OPERATION.
- 1.5 DO NOT REACH OR CRAWL UNDER THE EQUIPMENT WHILE IT IS RUNNING.

Personnel shall be trained and familiarized with said safety rules of this equipment. It is the responsibility of the owner of this equipment to insure the safety of his employees.





## MACHINE ARRIVAL

Your machine and/or equipment has been thoroughly tested at the ADCO facilities prior to shipment, and is ready for your use. Before shipment the machine has been checked to make sure that all nuts, bolts, set screws, and fastening devices are tight. However when machinery is shipped on long distances and even short distances, hardware sometimes has a tendency to work loose.

---

THE FOLLOWING IS A GUIDELINE OF WHAT TO DO WHEN YOUR MACHINE FIRST ARRIVES:

---

- 1 INSPECT THE MACHINE THOROUGHLY FOR DAMAGE.
- 2 (IF POSSIBLE) CHECK THE VEHICLE IN WHICH THE MACHINE WAS SHIPPED FOR HARDWARE WHICH MAY HAVE FALLEN FROM THE MACHINE.
- 3 CHECK PACKING LIST TO INSURE ALL ACCESSORIES ARE PRESENT.

---

BEFORE MOVING THE MACHINE TO ITS FINAL DESTINATION:

---

- 1.1 WATCH FOR HOSES AND ELECTRICAL CONDUITS WHEN MOVING THE MACHINE WITH A FORK LIFT OR OTHER POWERLIFT DEVICE.
- 1.2 MAKE SURE THE FEET OF THE MACHINE ARE UP AND WILL NOT HIT FLOOR HIGH SPOTS WHEN ROLLING THE MACHINE.
- 1.3 CHECK PATHWAYS FOR CLEARANCE SO THAT PROPERTY OR MACHINE DAMAGE WILL NOT OCCUR.
- 1.4 IF SPACE IS LIMITED, MAKE SURE THE MACHINE GOES IN THE RIGHT DIRECTION.

ONCE THE MACHINE IS IN OR AT ITS FINAL DESTINATION, PERSONNEL INVOLVED SHOULD READ AND EXAMINE THE SERVICE MANUAL, ESPECIALLY THE SECTION ON SAFETY BEFORE GOING ANY FARTHER WITH THE MACHINE.



## INSTALLATION

### SET-UP AND START-UP

ONLY QUALIFIED PERSONNEL SHALL BE ALLOWED TO WORK ON THIS EQUIPMENT WHO HAVE READ THE SERVICE MANUAL AND ARE FAMILIAR WITH THE SAFETY AND OPERATION OF THE MACHINE.

As stated in the machine arrival section, machine hardware may have worked loose or fallen off. Your machine may have been shipped in two pieces or with machine accessories. This section helps guide you in setting up your machine, and bring to your attention items you may have missed otherwise.

#### SETTING UP THE NEW MACHINE:

- 1 CHECK THE ENTIRE MACHINE FOR TIGHT, (i.e. NUTS, BOLTS, SPROCKET SET SCREWS, AND FASTENERS).
- 2 MAKE SURE ALL SPROCKETS HAVE KEYS IN THEM.
- 3 CHECK INSIDE THE ELECTRICAL CABINET, MAKE SURE NO COMPONENTS HAVE FALLEN.
- 4 CHECK WIRE TERMINAL STRIP FOR LOOSE CONNECTIONS.
- 5 INSPECT THE MACHINES WIRE CONDUITS FOR BREAKS, CRUSHED AREAS, AND THAT THE FITTING CONNECTORS ARE TIGHT.
- 6 ON PRESSURIZED HOT GLUE APPLICATORS CHECK HOSES FOR DAMAGE.
- 7 ON HOT AIR SEALERS CHECK AIR HOSES LEADING TO HEATERS FOR LEAKS AND TIGHTNESS

#### PUTTING THE NEW MACHINE TOGETHER:

Your new machine may have been shipped in two or more pieces, use the machine floor plan prints for proper set up.

- 1 POSITION THE MACHINE (MAIN MACHINE IF IN TWO PIECES)
- 2 CHECK DISCHARGE HEIGHT AND INFEED HEIGHT IF MATCHING UP TO OTHER EQUIPMENT.
- 3 WITH THE MACHINES FEET, LEVEL THE MACHINE. DO NOT USE THE MACHINES CASTERS FOR SET-UP, REMOVE THEM IF THEY OBSTRUCT WHEN TRYING TO LEVEL.



## INSTALLATION

---

### PUTTING THE MACHINE TOGETHER CONTINUED:

---

- 4 CONNECT ADDITIONAL EQUIPMENT TO THE MACHINE (IF ANY), A LIST OF CONNECTING SEQUENCES MAY HAVE BEEN SHIPPED WITH THE MACHINE, IF THERE IS NO LIST, CONNECT COMPONENT(S) AS THEY MATCH UP. CONNECT CHAINS, MATCHING UP TIMING MARKS (IF ANY).
- 5 INSURE CONNECTIONS ARE TIGHT.
- 6 MOUNT GUARD ACCESSORIES (IF ANY).

---

### ELECTRICAL:

---

ONLY QUALIFIED PERSONNEL SHOULD PERFORM ELECTRICAL CONNECTIONS TO MACHINE. ALL LOCAL AND STATE REGULATIONS FOR ELECTRICAL CONNECTION SHOULD BE FOLLOWED.

---

### BEFORE CONNECTING ELECTRICAL POWER:

---

- 1 CHECK THE MACHINES SERIAL NAME PLATE AND THE ELECTRICAL PRINT TO INSURE THE MACHINE IS SET-UP AT THE PROPER VOLTAGE, OR THAT THE PROPER VOLTAGE IS BEING CONNECTED TO THE MACHINE. (IF THE VOLTAGE IS DIFFERENT THAN SPECIFIED, CONTACT ADCO TO NOTIFY THEM OF THE DISCREPANCY, ADDITIONAL EQUIPMENT MAY HAVE TO BE ADDED (i.e. TRANSFORMERS, OVERLOAD HEATERS)).
- 2 THE ELECTRICIAN SHOULD INSPECT ALL ELECTRICAL APPARATUS'S
- 3 AN ELECTRICIAN SHOULD CONNECT WIRE CONNECTIONS TO OTHER EQUIPMENT, OR IF MACHINE WAS SHIPPED IN TWO OR MORE PIECES, REWIRING ASSEMBLED MACHINE USING THE ELECTRICAL DIAGRAM.
- 3 A 1 - 1/8 INCH HOLE IS SUPPLIED AT THE BOTTOM OF THE MAIN ELECTRICAL CABINET FOR CONNECTING POWER TO THE MACHINE.
- 4 THE MACHINE NAME PLATE SUPPLIES THE AMPERAGE RATING OF THE MACHINE, THE BREAKER AND/OR FUSE SIZE, WIRE SIZE AND TYPE SHOULD CONFORM TO LOCAL AND STATE CODES.
- 5 A GROUND WIRE MUST ALSO BE SUPPLIED FROM THE PLANTS GROUNDING SYSTEM, AND BE ABLE TO CARRY THE FULL AMPERAGE LOAD OF THE MACHINE.
- 6 AN ELECTRICIAN SHOULD MAKE SURE THE GUARD INTERLOCK SYSTEM (IF SUPPLIED) IS IN PROPER WORKING CONDITION.



## INSTALLATION

---

### START-UP:

---

With all connections made, the machine gone over for tight and the machine guards in their proper place, the machine can be safely started.

---

### START-UP SEQUENCE:

---

- 1 BEFORE TURNING ON THE MACHINE POWER;
  - A. MAKE SURE THERE IS NO TOOLS LEFT IN THE MACHINE.
  - B. ALL PERSONNEL SHOULD BE CLEAR OF MACHINE.
- 2 THE CONTROLS SWITCH ON THE PUSH BUTTON PANEL SHOULD BE OFF AND THE EMERGENCY STOP PRESSED DOWN.
- 3 TURN ON THE DOOR DISCONNECT OF THE MACHINE.
- 4 TURN ON THE CONTROLS SWITCH ON PUSH BUTTON PANEL, THE LIGHT ON THE EMERGENCY STOP SHOULD GO ON, IF NOT THEN A PROBLEM EXISTS, IF "ON" GO TO POSITION 5. IF THERE IS A PROBLEM AN ELECTRICIAN SHOULD CHECK THE SYSTEM.
- 5 PULL UP THE EMERGENCY STOP, MAKE SURE THE MACHINE IS CLEAR, PUT MACHINE IN JOG (IF NO JOG SWITCH THEN HOLD THE STOP BUTTON DOWN AND JOG WITH THE START BUTTON RELEASING THE STOP BUTTON TO JOG).
- 6 JOG THE MACHINE ONCE, THE MACHINE SHOULD CYCLE, IF THE MACHINE DOES NOT CYCLE, TRY JOGGING AGAIN (SOME MACHINES ARE CONTROLLED BY OTHER EQUIPMENT OR AUTOMATICALLY. THE PUSH BUTTON PANEL MAY HAVE A "MANUAL - AUTOMATIC" SWITCH, IF SUPPLIED, SWITCH TO MANUAL. BE SURE OF THE MACHINES FUNCTION BY READING THE SECTION ON THE OPERATION OF THE MACHINE), IF THE MACHINE WILL NOT JOG AND IT APPEARS THAT THE LUGS ARE TRYING TO MOVE OR YOU CAN HEAR THE MOTOR TRYING TO TURN, POSSIBLY KICKING OUT THE OVERLOAD CLUTCH. STOP JOGGING AND CHECK OVER THE MACHINE AND LOCATE THE JAM OR OBSTRUCTION. ONCE THE MACHINE IS JOGGING AND NO PROBLEM IS SEEN THEN SWITCH TO RUN AND RUN THE MACHINE.
- 7 ONCE RUNNING, PRODUCTION CAN BEGIN. HOWEVER THE OPERATION SEQUENCE OF THE MACHINE SHOULD BE KNOWN, READ THE "OPERATING THE MACHINE" SECTION OF THIS MANUAL TO BE FAMILIAR WITH THE MACHINES FUNCTION.

FOLLOW SAFETY RULES WHEN OPERATING THIS EQUIPMENT, SAFETY RULES ARE SUPPLIED IN SECTION 1 OF THIS MANUAL.
--





## MAINTENANCE

### CONTENTS

	(page)
GENERAL MAINTENANCE AND CLEANING.....	4.1
LUBRICATION:	
BEARINGS.....	4.2
BUSHINGS, CAM FOLLOWERS.....	4.3
CHAINS.....	4.3
GEAR BOXES, OPEN GEARS.....	4.4
VACUUM PUMPS.....	4.4
PNEUMATICS.....	4.5
RECOMMENDED LUBRICANTS.....	4.5



## MAINTENANCE

---

### MAINTENANCE OVERALL:

---

Because not all machines are alike and differ from one another, common sense and discretion should be used when setting up a maintenance schedule. It is recommended that the machine be kept clean and well lubricated. GOOD MAINTENANCE means longer machine life and less down time. That means more production time.

---

### CLEANING:

---

THE MACHINE SHOULD BE CLEANED IN ACCORDANCE WITH STATE AND LOCAL SANITATION RULES.

It is recommended that the machine be kept clean and well lubed. Areas where the environment is poor, such as dairies or meat packing plants, machines should be washed down on a daily basis. Areas with a cleaner environment can be done just on a visual basis only, using a mild detergent and wiping it down. A clean machine requires less repair time and is much easier to service.

Next is a list of safeguards to observe when cleaning the machine with high pressure cleaning systems.

#### WHEN WASHING DOWN MACHINE:

- 1 AVOID SPRAYING DIRECTLY AT ELECTRICAL BOXES, WHEN POSSIBLE TURN OFF POWER TO THE MACHINE.
- 2 DO NOT SPRAY DIRECTLY AT THE PUSH BUTTON PANEL, EMERGENCY STOP STATIONS, PHOTO-EYES, SOLENOIDS, ELECTRIC CLUTCHES, OR ANY ELECTRICAL APPARATUS.
- 3 IF NECESSARY COVER ELECTRICAL DEVICES WITH PLASTIC.
- 4 AVOID SPRAYING DIRECTLY AT MOTORS.
- 5 DO NOT ALLOW WATER TO SIT ON MACHINE, BLOW OFF WITH AIR.
- 6 CLEAN ELECTRICAL DEVICES SUCH AS CONTROL PANEL, EMERGENCY STOP STATIONS, PHOTO-EYES, ETC. WITH A WET WASH CLOTH.
- 7 AVOID SPRAYING ADHESIVE POTS, HOT AIR GUNS/NOZZLES OR GAS BURNERS.
- 8 NO WATER SHOULD BE USED NEAR THE HOT AIR GUNS, IF MOISTURE ENTERS THESE UNITS IT WILL DESTROY THEM.



## MAINTENANCE

### LUBRICATION:

The importance of maintenance cannot be stressed enough, if machinery is left alone and not taken care of it will break down when you least expect. If machine is well maintained of course it will last longer, but, because the machine is maintained on a regular basis, maintenance personnel can see trouble before it strikes, avoiding costly down time.

This section gives a generic lubrication schedule for the machine. The schedule can be followed safely, but we recommend you refer to the manufacturers parts information for a more accurate lubrication schedule of each particular item, (e.i. Gearboxes; Bearings, etc.). Manufacturers parts list and instructions are kept at the end of this manual.

### BEARINGS:

Bearing manufacturers usually do not supply information pamphlets with their product, it is commonly placed in their equipment catalog. A particular catalog for a specific bearing may not be available at your facilities, so a general lubrication schedule is set up here to aid you in making a lubrication timetable for your machine.

#### SUGGESTED BEARING LUBRICATION:

<u>MACHINE SPEED</u>				<u>LUBE SCHEDULE</u>
SEALED BEARINGS				
0	-	60	CPM	TWICE MONTHLY
60	-	120	CPM	BI-WEEKLY
120	-	300	CPM	ONCE WEEKLY
300	CPM AND ABOVE			DAILY
OPEN BEARINGS (NON SEALED)				
0	-	60	CPM	BI-WEEKLY
60	-	120	CPM	ONCE WEEKLY
120	-	300	CPM	ALTERNATE DAYS
300	CPM AND ABOVE			TWICE DAILY

(This list is based on an average 10 hour operating day, 5 days a week, and in average conditions. If the machine is subject to extended operating hours, or the machine is set in a harsh environment such as wet or very dusty conditions, the schedule should be adjusted to a more frequent application).



## MAINTENANCE

---

### BUSHINGS AND CAM RACEWAY'S:

---

#### LINEAR BUSHINGS:

Most of ADCO'S bushing type applications, as in the Barrel Cam section, utilize self lubricating Delrin bushings that do not require lubrication, only that the linear traveling shafts be kept clean and sprayed with a light oil to keep them from rusting. Also wipers are placed at both ends of the bearing(s) to help keep foreign materials out.

Although these bushings and shafts can operate satisfactory without added lubricants, in severe conditions where dust and contaminants are a factor, lubrication should be added.

---

### BUSHINGS AND CAM RACEWAY'S:

---

#### BRASS OR BRONZE TYPE BUSHINGS:

Brass or bronze bushings require a daily application of lubricant. If bushings run dry, lubricate immediately.

#### CAM TRACKS OR RACEWAYS:

Grease weekly, (grease immediately if dry).

Cam followers with grease fittings can be lubed according to the sealed bearing schedule.

---

### CHAINS:

---

#### DRIVE CHAINS:

Keep oiled, do not allow to run dry. Check weekly.

Lubricate with a medium grade oil or spray on type lube.

#### PRODUCT INFEED CONVEYOR CHAINS:

DO NOT RUN DRY. Lube with a medium grade oil. Avoid getting oil on product carrying surfaces. (In food packaging applications use an approved food grade lubricant).





## MAINTENANCE

---

### CHAINS CONTINUED:

---

#### FLIGHT CHAINS (CARTON CARRIER CHAIN):

DO NOT RUN DRY. Lubricate with a medium grade oil. Avoid getting oil on the chain lugs and the carton runners. (Use food grade lubricant in food packaging applications).

---

### GEARBOXES:

---

Gearbox (i.e. inline reducers, right angle drives, indexers, tolomatics, etc.) manufacturers differ widely in brand and as well as model type, size, and application. Because of this, no lubrication schedule is set up here. Instead we recommend that you follow the manufacturers lubrication schedule and requirements for that particular device, (manufacturers specification pamphlets are located at the end of this manual). However, here is a list of items that would suggest a gearbox may need attention.

- 1 GEAR BOX OPERATING AT A HIGH TEMPERATURE.
- 2 OIL DIRECTLY UNDER GEARBOX.
- 3 LOUD OPERATING NOISE.

---

### OPEN GEARS:

---

DO NOT RUN DRY. See recommended lubricant at the end of this section. Keep well lubed, checking weekly, or daily for high speed applications.

---

### VACUUM PUMPS:

---

Some vacuum pumps are equipped with an oil bottle that lubricate the pump while it runs, keep full with a 10 weight detergent oil. Do not run dry or reuse old oil. Used oil will show up (fill up) in the muffler bottle, (this is normal).

Clean the vacuum bottles and filters weekly, if left alone vacuum pressure response time will be reduced, which may cause carton feed failure. Inspect hoses and vacuum cups regularly for cracks.



## MAINTENANCE

---

### AIR-LINE LUBRICATORS:

---

CHECK FLUID LEVEL IN BOTTLE WEEKLY. FILL WITH PNEUMATIC OIL TO INDICATED LEVEL.

CLEAN OR DRAIN FILTER BOTTLE AS NEEDED.

---

### RECOMMENDED LUBRICANTS:

---

	<u>LUBRIPLATE</u>	<u>MOBIL</u>
FLIGHT CHAINS.....	FMO-85	
CHAINS (DRIVE AND PRODUCT CONV).....	APG 80W-140	
OPEN GEARS.....	FML-2	MOBILTAC E
BEARINGS.....	FML-1	MOBILUX EP2
CAM FOLLOWERS, CAM RACES.....	FML-2	MOBILUX EP2
VACUUM PUMPS.....	FMO-85	AD220 (GAST)
AIR LINE LUBRICATORS.....	FMO-85	

### AUTO LUBE SYSTEMS OR GROUP LUBE SYSTEMS:

GREASE.....930-AA (LUBRIPLATE)

OIL.....FM754 NO. 3 (G-C LUBRICANTS)

### GEARBOX (G.B.) LUBRICATION

BOSTON G.B. ....R&O 150,HD 150,MOBIL SHC-634  
SYNTH.  
ECONOGEAR.....MOBIL 636 150 V.E. 680  
EURODRIVE.....MOBIL 636 150 V.E. 680  
HUB CITY G.B.....HUB CITY ALL TEMP. SYNTH GEAR  
OIL MOBIL 636 150 V.E. 680  
OHIO G.B.....MOBIL 636 150 V.E. 680  
SM-CYCLE GEAR.....MOBIL 636 150 V.E. 680  
U.S. MOTOR G.B.....MOBIL 636 150 V.E. 680  
VON RUDEN.....MOBIL 636 150 V.E. 680, SAE  
140 W/ANTI FOAM AGENT

NOTE: CHANGE GEARBOX OIL EVERY SIX MONTHS. IF OPERATING TEMPERATURE OF GEARBOX IS ABOVE 180 DEGREES FARENHEIT CHANGE GEARBOX OIL MORE FREQUENTLY.

MAINT. 4.5



MACHINE OPERATION  
FORMING MACHINES

---

GENERAL DESCRIPTION OF MACHINE FUNCTION:

---

The Forming Machine forms cartons from simple die-cut (flat) blanks. A blank is picked from the hopper and placed on the forming frame; the plunger then pushes the blank through the forming frame where the tabs, corner posts, end panels, and lid are folded up to make a finished erect carton.

The Forming Machine has variable speed control to meet production requirements or to match speeds of other equipment. Cartons are called for by means of either a foot switch or selector switch on the control panel, or automatically where feeding is controlled by a backup eye that stops the former from picking cartons when the takeaway conveyor becomes full and is automatically restarted when the eye becomes clear.

From the Forming Machine the cartons are then ready for loading, whether by hand or automatically. Then top sealed by other equipment.

---

STARTING, STOPPING AND SPEED CONTROL:

---

CONTROL SWITCH:

The control switch controls all switches on the main panel, when this switch is off all the button and selector switches on the main panel are inactive.

START BUTTON:

The machine can only be started at the main push button station, where other machine functions are controlled. When starting up for production, all necessary switches should be on (i.e. Vacuum, Glue, Hot Air, Conveyors, etc.). The machine will only start when all guards are closed. (DO NOT DEFEAT THE GUARD INTERLOCK CIRCUIT, OR OPERATE THE MACHINE WITH GUARDS REMOVED OR PERSONAL INJURY COULD RESULT).

STOP BUTTONS:

There are two stop buttons located on the main panel, one is labeled "STOP" and the other "EMERGENCY STOP". The emergency stop button is a maintained button which stays in position whether it is pushed down or pulled up. When pushed down it prevents the machine from being accidentally started.

JOG SWITCH:

A "JOG / RUN" selector switch is supplied on the main panel to aid in change-over and set-up of the machine. When in jog mode the machine can be jogged or inched by the start button on the main panel when the guard doors are closed.

A hand held Jog Button with cord is supplied that allows easier access to different area's of the machine for set-up and change-over. The jog button only operates when the machine is in the jog mode, and bypasses the guard interlock circuit.



MACHINE OPERATION  
FORMING MACHINES

**SPEED CONTROL:**

This control switch can be used to adjust the machine speed to match your production needs. Care should be taken that the machine is not used at higher than recommended speeds.

**EMERGENCY STOP:**

A micro switch has been provided to insure stopping of the former with the vacuum cups away from the heating nozzles. If the speed on the machine is changed drastically the cam, activating this micro switch should be adjusted to stop the machine in the correct position.

**HOT AIR GUNS (IF APPLICABLE)**

Check that blower is turning in the correct direction. This will assure correct air supply to the heaters, hoses should be checked once a week for good connections and leaks. Settings for air and heat at the guns should be kept to a minimum, enough to get a good seal on the carton. Too much air on the setting switch could result into blow back in the guns and a shorter life expectancy.





## MACHINE OPERATION FORMING MACHINES

---

### OPERATING THE MACHINE:

---

Depending on the sealing or flap locking system of the machine a warmup time may be required. Example, if your cartons use locking tabs no warmup time is necessary. If your machine has a Hot Air sealing system then the hot air guns should be allowed to warm up to operating temperature, which only takes a few minutes. On Hot Melt sealing systems the glue must have at least a 30 minute warm-up time to achieve operating temperature and melt enough glue in the reservoir for operation. After warming up the sealing system (when required), the machine can then be started.

#### VACUUM:

Once ready for picking the blanks the vacuum switch can be turned on. At this time carton blanks can be picked for forming. Depending on the system to call cartons for picking, one or more of the items below may apply to your forming machine.

#### FOOTSWITCH:

To pick a blank, depress the pedal on the footswitch. As long as the switch is held down carton blanks will be picked continuously until the footswitch is released. (Some machines may have the footswitch working opposite than stated above, where the carton blanks are picked continuously until the footswitch is pressed to stop the picking).

#### AUTOMATIC:

An "AUTO - MANUAL" selector switch may be supplied on the main panel. When in Manual mode a footswitch or other similar device is used to control picking. When in Auto mode (Automatic), carton blanks will be picked automatically until some device signals to stop picking (i.e. Photo-eye, switch, or machine interface).

Once in production, Hot Melt reservoirs (where applicable) and hoppers should be periodically checked, refilling as necessary. (With pressurized Hot Melt systems if the glue runs out it takes about 15 minutes for the glue to warm up enough to start production again).

---

### GUARD DOOR INTERLOCKS:

---

The machine is provided with electrically interlocked guards that stop the machine when a door is opened. This is to protect operators and keep them from reaching into the machine while it is running. DO NOT ALTER THE GUARD INTERLOCK SYSTEM, AS PERSONAL INJURY MAY OCCUR. (See SAFETY section).




SET-UP SEQUENCE  
FORMING MACHINE  
STRIPPER LOCK STYLE

CARTON TERMINOLOGY.....	6.1
ASSEMBLY SET-UP.....	6.2
	6.3
	6.4



FORMING MACHINES  
STRIEPPERLOCK STYLE

CARTON TERMINOLOGY



NOTE: GRAIN DIRECTION SHOULD BE DIRECTION OF CORNER POST



4. Lower the plunger with the bottom edge level with the bottom edge of the brass Fig.2-G. Follow instructions as described to set brass folding shoes. Fig. 2-F
5. Install vacuum bar (see Fig. 6 before installation of this bar.)




fig. 3

6. Raise plunger, place carton on forming frame, lower plunger to touch carton. Locate carton under plunger as shown in Fig.2-H and place register pins to hold the carton in the correct place under the plunger. Fig.3-I. (Carton should not be allowed to move more than 1/32" over-all)
7. With a carton on the forming frame, bring the vacuum cups to just touch the carton, mark the position of the cups on the carton. (The cups should be positioned as low as possible on the carton as shown on Fig.4) Place the carton in the hopper frame, position the stack support rods and side guide rods to place the carton correctly on the cup marks as shown in Fig.4




fig. 4





SET-UP SEQUENCE  
FORMING MACHINES  
(STRIPPER LOCK STYLE)

FORMING ASSEMBLY SET-UP

1. Lower plunger into cavity about halfway, make sure that the plunger front face is perpendicular with the front edge of the forming frame. Fig. 1-A
2. Plunger should then be equally spaced between the sides in the forming frame. Fig 1-B. The sides should then be adjusted to leave a space of no more than two board thicknesses between the plunger sides and the side frame cam bars. Fig 2-D
3. The Fig.2-C side bars should now be adjusted with edges Fig.1-E equally spaced to the lock tip cut-outs of the plunger.







fig. 2



\* If the plunger needs to be moved to make the adjustments in paragraph 2-3, capscrews "E" Fig.5 should be loosened to make the necessary adjustments. Once the plunger is centered these should not have to use again.





TROUBLE SHOOTING HINTS  
FORMING MACHINES  
STRIPPER LOCK STYLE

TROUBLE SHOOTING.....	8.1
DO'S AND DONT'S.....	8.2



## TROUBLE SHOOTING HINTS

### FORMING MACHINES (STRIPPER LOCK STYLE)

#### SETTING LOCK TIPS:

When the male tab of the carton is folded up against the plunger, with the scores folded on the edge of the plunger, the outer edge of the locking tab Fig.6-A and Fig.8-A should fold inside the lock tip Fig 6-B. Care should be taken that the tip is not too far outward to buckle the carton locking tab.

- \* If locking tips do not pull lock tabs completely through the female portion of the carton.

Move arm (Fig. 7-A) outward will add more travel to cam follower (Fig.7-C) and will pull the carton male locking tab deeper into the plunger. Care should be taken that dimension (Fig.7-B) does not become less than one board thickness.

#### INCONSISTENT LOCKING:

Check carton register from hopper to forming frame. Carton should have no more than 1/32" overall play within the register pins.

#### VACUUM PROBLEMS:

Check vacuum cups for cracks and hoses for clogging, paper dust will clog the lines. Cups should not be set on scores unless the board is light enough not to break the vacuum avoid placing vacuum cups over cuts or cut scores.

#### CARTONS NOT STRIPPING OF PLUNGERS:

Spring loaded mechanical strippers are used on some equipment on others the cam bars on each side are used to strip the carton. When the locktabs are not pulled through, the carton does not bow out on the side, this creates stripping problems. Lock tip adjustment will be necessary or check distance between cam bars and plungers.

#### DOUBLE FEEDING:

Careful when fanning cartons, thumb pressure on the lock areas when handling a stack of cartons, could result in cartons interlocking and pulling out a second carton from the hopper. Keep vacuum cups as far down and outward on the carton as possible.






TROUBLE SHOOTING/DO'S AND DONT'S  
FORMING MACHINES  
(STRIPPER LOCK STYLE)

At no time should the plunger mounting bracket (Fig.5-D) be loosened at the six bolts, clamping it to the plunger bar, (Fig.5-CC) This will change the plunger position and could cause severe damage to the plunger and forming frame.

If your machine has a rotary vacuum valve, at no time should this valve be oiled. An oily film will suck into the vacuum line causing a clogged line.

Check the settings of the brass folding shoes often. They should not be set against the plunger, this will cause unnecessary wear. Check the jam nut for tightness.

Make sure stack hold-down in the hopper is down on the stack double feeding could result if the cartons are not held down on the bottom support rods.







**Parts Drawings &**

**Recommended Spare Parts List**



## PARTS ORDERING PROCEDURE

### I. WHEN ORDERING PURCHASED PARTS, ALWAYS SPECIFY:

- A. BRAND NAME
- B. PART NUMBER (IF AVAILABLE)
- C. VOLTAGE (IF APPLICABLE)
- D. MACHINE MODEL #
- E. MACHINE SERIAL #

IF THIS INFORMATION IS NOT AVAILABLE, PLEASE SPECIFY WHERE THE PART IS USED ON THE MACHINE.

### II. WHEN ORDERING ALL OTHER PARTS

- A. USE PARTS DRAWINGS SUPPLIED (ILLUSRTATED PARTS SECTION), BY ADCO WHENEVER POSSIBLE.
- B. WHEN DRAWINGS ARE NOT AVAILABLE FROM ADCO, PLEASE DESCRIBE WHERE THE PART IS USED ON THE MACHINE

E.G.,-

\*WHICH SIDE OF THE MACHINE, THE LEFT HAND OR THE RIGHT HAND SIDE LOOKING DOWNSTREAM.

\*WHAT ASSEMBLY THE PART IS USED IN, THE TUCKER ASSEMBLY, THE HOPPER ASSEMBLY ETC.

NOTE: WHEN ORDERING SHAFTS, ALWAYS SPECIFY LOCATION OF SHAFT ON MACHINE, DIAMETER OF SHAFT AND THE LENGTH OF THE SHAFT. ALSO, WHEN ORDERING SPROCKETS AND GEARS, ALWAYS SPECIFY PITCH, NUMBER OF TEETH ADN BORE SIZE.





### RECOMMENDED SPARE PARTS LIST

CUSTOMER: WISCONSIN CHEESEMAN  
MODEL: AFH60-2-EC  
SERIAL NO: 3061TK

#### MECHANICAL

PART NO.	QTY REC	QTY TOTAL	DESCRIPTION	PRICE
5100-25	2	4	"WALDES" TRUARC RETAINING RING .250 O.D. SHAFT	
FB46-2	2	4	"BOSTON" BOST-BRONZE FLANGE BEARING	
LE-081B-2	8	4	"LEE" EXTENSION SPRING 3/16 O.D. X .018 DIA MUSIC WIRE X 7/8 FREE LENGTH	
LC-072H-3M	1	1	"LEE" COMPRESSION SPRING 1" FREE LENGTH	
LC-063J-3	4	4	"LEE" COMPRESSION SPRING 1" FREE LENGTH	
5100-31	2	4	"WALDES" TRUARC EXTERNAL RETAINING RING 5/16 DIA SHAFT	
LC-063H-7	1	2	"LEE" COMPRESSION SPRING (.600 O.D. X .063 WIRE DIA X 1 3/4 FREE LENGTH)	
MM-4	1	2	"AURORA" MALE ROD END BRG. W/1/4-28 R/H THDS	
CYR-1	1	2	"MC GILL" CAMROL BRG-1" O.D	
LC-045E14	2	4	"LEE" COMPRESSION SPRING	
66-P	1	1	"IMPERIAL" POLY-FLO TUBING 3/8	
3/8 ODX1/4ID	1	1	CLEAN VINYL TUBING-VAC LINE	
5/8 ODX1/2ID	1	1	CLEAN VINYL TUBING-VAC LINE	
390H150	1	1	"DODGE" DYNA-SYNC BELT 1/2 PITCH-1 1/2" WIDE	







### RECOMMENDED SPARE PARTS LIST

CUSTOMER: WISCONSIN CHEESEMAN  
MODEL: AFH60-2-EC  
SERIAL NO: 3061TK

#### MECHANICAL

PART NO.	QTY REC	QTY TOTAL	DESCRIPTION	PRICE
FC2-25-1 1/2	1	2	"MCGILL" FLANGE BRG 1 1/2 BORE	
FC2-25-3/4	2	4	"MCGILL" FLANGE BRG 3/4 BORE	
CF-3/4	1	2	"MCGILL" CAMROL CAMFOLLOWER BRG 3/4 BORE	
M2428-24	2	4	"BOSTON" BRONZE BRG	
1480	2	2	"CR SEALS" TYPE HM14-LIP V (VITON)	
77R4	4	6	"NEW DEPARTURE" RADIAL B/B SERIES "R"	
DW6	2	2	"FAFNIR" EXTRA WIDE, DBL ROW BRG (3/8 BORE)	
RR-106	2	4	"SPIROLOX" RETAINER RING FOR 1 OD BRG	
KP12 A	4	4	"FAFNIR" RADIAL TYPE BRG 3/4 BORE	
DW 8	2	2	"FAFNIR" EXTRA WIDE DBL ROW BRG 1/2 BORE	
DW6	2	2	"FAFNIR" EXTRA WIDE BRG	
RR-162	2	2	"SPIROLOX" RETAINER RING FOR 1 5/8	
5555-50	2	4	"WALDES" TRUARC GRIP RING FOR 1/2 DIA SHAFT	
240LO50	1	1	"BROWNING" GEARBELT 3/8" PITCH STOCK "L"-1/2 WIDE	





### RECOMMENDED SPARE PARTS LIST

CUSTOMER: WISCONSIN CHEESEMAN  
MODEL: AFH60-2-EC  
SERIAL NO: 3061TK

#### MECHANICAL

PART NO.	QTY REC	QTY TOTAL	DESCRIPTION	PRICE
MM-4	2	5	"AURORA" MALE ROD END, 1/4 BORE 1/4 28 R/H THDS	
MB-4	1	1	"AURORA" MALE ROD END BRG 7/16 BORE 1/4-28 L/H THDS	
AM-7T	2	6	"AURORA" MALE ROD END BRG 7/16 BORE 7/16-20 R/H THDS	
AB-7T	2	6	"AURORA" MALE ROD END BRG 7/16 BORE 7/16-20 L/H THDS	
01CLA3	1	1	"NUMATICS" 3-WAY ROLLER LEVER LIMIT VALVE	
K247	1	1	"GAST" VACUUM PUMP REPAIR KIT	
AE274	1	2	PLASTIC JAR, INTAKE/EXHAUST VAC PUMP GAST	
B62A	1	2	GASKET FOR ABOVE JAR-GAST	
#56	6	2	VACUUM CUPS	





**RECOMMENDED SPARE PARTS LIST**



CUSTOMER: WISCONSIN CHEESEMAN  
MODEL: AFH60-2-EC  
SERIAL NO: 3061TK

**ELECTRICAL**

COMPUER NO. / PART NO.	QTY REC	QTY TOTAL	DESCRIPTION	PRICE
BZE6-2RN	1		LIMIT SWITCH, "MICRO"	
802T-ALP	1		LIMIT SWITCH, "A.B."	
802T-W1	1		ROLLER LIMIT SWITCH, "A.B."	
531F-012	1		"MAC" VALVE	
W-47	2		STARTER HEATER	
227-833B	1		"NUMATIC" 120V COIL	
KTK-R-1	1		FUSE	
KTK-R-2	1		FUSE	
KTK-R-3	1		FUSE	
KTK-R-10	1		FUSE	
PET 1481	1		TD RELAY	
800T-XA	1		CONTACT BLK.	
800M-N15	1		LAMP, JOG/RUN SELECTOR	
800T-N65	1		LAMP, E-STOP INDICATOR	
800T-16HA2KB6AX	1		2 POSITION ILLUM.	



SEE DETAIL 'A'



DETAIL 'A'

<b>ADCO</b> MANUFACTURING, INC. <small>2179 Academy • San Jose, California 95067 • (408) 875-5563          TELEX # 703787 FAX (408) 875-7865</small>			
SCALE	APPROVED BY	DRAWN BY <b>DK</b>	
DATE <b>2-7-90</b>	STRIPER LOCK STYLE		REVISED
<b>FORMING HEAD</b>			
FORMING MACHINES			DRAWING NUMBER <b>CAF505</b>








2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
FORMING HEAD  
STRIPPER LOCK STYLE  
CAF505

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>QTY</u>
1	CROSS ARM		2
2	SPACER	A09S-.62-.375-	4
3	PLUNGER TIP MOUNT ARM		4
4	"AURORA" MALE ROD END 1/4"-28 MM-4 R/H		2
5	PIVOT ROD, ADJUSTING		2
6	CARTON PLUNGER HEAD MNT		1
7	FORMING HEAD MOUNING PLATE		1
8	SPACER	A09-S-.50-.250	4
9	SPACER	A09-S-.56-.312	4
10	TABLOCK FINGER		4
11	CAMROL BRG 1" O.D. "MCGILL"		2
12	PLUNGER TIP MTG ARM GUIDE		2
13	PIVOT SPRING STOP		2
14	PIVOT SPRING SPACER PLUG		2
15	COMPRESSION SPRING "LEE"	LC-063H-7	2



SEE DRWGS. \*CAF502 & \*CAF503  
PICKING GEOMETRY



**ADCO**  
MANUFACTURING, INC.

2170 Assembly • San Jose, California 95127 • (408) 875-5552  
TELEX: 473277 FAX: (408) 875-7665

SCALE	~	APPROVED BY:	DESIGNED BY
DATE	12-19-89		DK
PICKING VACUUM			REVIEWED
FORMING MACHINE			DRAWING NUMBER
			CAF508






2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
PICKING VACUUM  
CAF508

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>HIGH SPEED QTY</u>	<u>LOW SPEED QTY</u>
1	PIVOT SHAFT & FD ARM MTG PLT	B55CFW-504	2	2
2	PIVOT SHAFT CENTER ARM	A55CFW-93	2	2
3	CENTER CONN. LINK ARM	B55CFW-520	2	
4	CENTER CONN. LINK ARM	B55CFW-92		2
5	VACUUM ARM CONN. LINK	A55CFW-73		2
6	VACUUM ARM CONN. LINK	A55CFW-511	2	
7	MALE ROD END BRG, 7/16-20 L/H THDS	AB-7T	2	2
8	MALE ROD END BRG, 7/16-20 R/H THDS	AM-7T	2	2
9	PLUNGER ARM CONN. LINK	A55CFW-74		2
10	PLUNGER ARM CONN. LINK	A55CFW-510	2	
11	AGITATOR BAR CONN. LINK	A55CFW-107		1
12	AGITATOR BAR CONN. LINK	A55CFW-512	1	
13	MALE ROD END BRG. 1/4-28 R/H THDS	AM-4	1	1
14	SPACER		8	8
15	ARM, HOPPER AGITATOR	A55CFW-99	1	1
16	VAC. VALVE ACUTATOR ARM	A55CFW-227	2	2
17	CAM HUB, VAC. ACTUATOR	A55CFW-189	2	2
18	MTG. PLATE, AIR VALVE	ACFW-148	4	4
19	VALVE		2	2
20	MTG. PLATE, PIVOT SHAFT R/H	A55CFW-95	1	1
21	FLANGE BRG., 2-HOLE "HUB CITY"		4	4
22	MTG. PLATE, PIVOT SHAFT L/H	A55CFW-95	1	1





**ADCO**  
MANUFACTURING, INC.

3176 Ardmore • San Jose, California 95127 • (408) 875-5583  
TELEX # 702777 FAX (408) 875-7885

SCALE: 12-11-89  
APPROVED BY: [Signature]  
DRAWN BY: DK  
REVISED:

HIGH SPEED GEOM.

FORMING MACHINE

CAF503












2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
PICKING GEOM, HIGH SPEED  
CAF506  
FORMING MACHINE

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>QTY</u>
1	BEARING "NICE"	1614 BC	12
2	FEED BAR INVERTING LINK	A55CFW500	2
3	FEED BAR ACTUATING ARM	B55CFW502A	1L/1R
4	FEED BAR ACT. SP. A11-S-.69-.75-.438-.218		4
5	FEED BAR BRG. SPACER	A55CFW284	2
6	FEED BAR INVERTING ARM	B55CFW501A	2
7	VAC. CUP FEED BAR	A55CFW72	1
8	ZERT FITTING 1/4"		
9	FEED ARM MTG. PLATE	B55CFW507	1L/1R
10	FEED BAR ACT. SP. A11-S-.69-.375-.312-1-XX		4
11	BEARING "NICE"	1621	4
12	SPACER, BRG ACT. ARM	A55CFW285	2
13	FEED ARM & HOPPER MTG. PLATE	B55CFW506	1L/1R
14	SPACER A09-S-.75-.438-.218		4
15	SPACER, FEED ARM MTG. BRKT.	B55CFW-505	2
16	CONN. LINK, VACUUM ARM	A55CFW511	2
17	MALE ROD END BRG 7/16-20 RH	AM-7T	2
18	FEED BAR INVERTING ARM	B55CFW501A	2
19	AIRCRAFT BEARING	DW-6	2
20	FEED BAR ACTIVATING ARM	B55CFW502A	1L/1R
21	AIRCRAFT BEARING	DW8	2
22	JAM NUT	3/8-24 ESNA	1
23	SPACER	A55CFW-78-4	1
24	SPIROLOX RING	RR-87	4
25	BOLT 3/8-24 X 37/64	ANG-14	1
26	BOLT 3/8-24 X 21/64	ANG-12	1
27	FLAT WASHER	AN960-616	1
28	SPACER A11-S-.69-.375-.312-1-XX		1
29	SPACER A11-S-.93-.50-.321-1-XX		1





MANUFACTURING, INC.

2170 Academy • San Jose, California 95131 • (209) 875-5563  
TELEX #703787 FAX (209) 875-7665

SCALE: ~  
DATE: 10-16-89

APPROVED BY: \_\_\_\_\_

DRAWN BY: DK  
REVISED: 9-6-90

FEEDER VACUUM VALVE  
FORMING MACHINE AAF512






2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
FEEDER VACUUM VALVE  
AAF512  
FORMING MACHINE


<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>QTY</u>
1	COMP. SPRING, LEE 1"	LC-072H-3M	1
2	VALVE MTG. STUD	A2872-118	1
3	ROTATOR, VACUUM VALVE	A2872-117-3	1
4	VALVE, VACUUM	A2872-116-3	1
5	SPACER	A10-S-.50-C4-1.25-C4	2
6	VALVE MTG. PLATE LH	A2872-120	1
7	HOSE FITTING, 90 DEG. BRASS	KF05-02-PS90	2
8	ACTUATOR PLATE	A2801-01	1
9	BEARING NHBB	SSR4SS	2
10	SPACER	A09-S-.50-.25-.375	2
11	RELEASE VALVE ACTUATOR	B2728-903K	1
12	SHAFT (SEE MAIN FRAME ASSY)		1







DETAIL A-A



**ADCO**  
MANUFACTURING, INC.

2170 Ardmore • San Jose, California 95127 • (408) 975-1543  
TELEX: 9703797 FAX: (408) 975-7845

SCALE: ~ DATE: 11-27-89 APPROVED BY: G.D.C. REVISED:

**OUTFEED CONVEYOR**

**FORMER**

DRAWING NUMBER: **CAF501**







2170 ACADEMY  
SANGER, CALIFORNIA 93657


LIST OF MATERIALS  
OUTFEED CONVEYOR  
CAF501

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>QTY</u>
1	CHAIN TAKE-UP STUD	A56SS-38B	2
2	CHAIN TAKE-UP BLOCK	A56SS-38A	2
3			
4	BOX BOTTOM GUIDE R/H	B56SS-41	1
5	BEARING-HUB CITY	FB260 X 1	2
6	SPROCKET 1" BORE	40B18	1
7	BEARING-HUB CITY	FB260 X 5/8	2
8	SPACER	A09-0.62-0.375-4.000	8
9	SPACER	A09-1.00-0.625-1.640	2
10	SPROCKET-IDLER ADJ	40BB17H	1
11	IDLER ADJ SHAFT	A56SS-21	1
12	SPROCKET 1" BORE		1
13	SHAFT-MAIN DRIVE	A56SS-19	1
14	SPROCKET 5/8 BORE		
15	SHAFT-REV. WRAP IDLER	A56SS-20	1
16	SPACER	A09-1.00-0.625-1.640	8
17	SPROCKET-IDLER	40BB17H	1
18			
19	CHAIN RAIL	A56SS-18	1
20	SPACER-CHAIN RAIL	A09-H-0.62-0.375-1.875	8
21	BOX BOTTOM GUIDE	B56SS-12-3	1
22	SUPPORT BRACKET	A56SS-22A	6
23	CARTON DROP GUIDE	C56SS-13A	1
24	CARTON DROP GUIDE	C56SS-14	1
25	LUG CONNECTING LINK	A56SS-27	
26	LUG-LINK PLATE	A56SS-28	
27	CHAIN #40		





DETAIL 'A'

 <b>ADCO</b> MANUFACTURING, INC. <small>2170 Academy • San Jose, California 95131 • (408) 875-3543          TELEX: 703787 FAX: (408) 875-7865</small>		DRAWING BY <b>DK</b>	
		REVISION	
SCALE: <b>2-1-90</b>		APPROVED BY:	
<b>STACK PUSHER</b>		DRAWING NUMBER	
FORMING MACHINE		<b>CAF500</b>	






2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
STACK PUSHER  
CAF500

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>QTY</u>
1	PEDESTAL UPRIGHT,STACK PUSHER	A55CFW152	1
2	LATCH RELEASE ROD	A55CFW157	1
3	KNOB, STACK PUSHER	A55CFW191	1
4	CROSS, STACK PUSHER	B55CFW159	1
5	ROLLER, STACK PUSHER	A55CFW155	4
6	LATCH, STACK PUSHER	A55CFW156	1
7	CROSS CLAMP	A55CFW158	1
8	MTG. BRKT. REAR HOPPER	B55CFW246	1
9	CATCH, STACK PUSHER	A55CFW149	1
10	ROLLER, TOP HOLD DOWN	A15AT229	4
11	GUIDE, STACK PUSHER	A55CFW112	2
12	BOLT, HEX HEAD, 1/4-20 X 1"	-----	1
13	SPRING	-----	1
14	SET COLLAR 1/4"	-----	1
15	FLAT WASHER 1/4"	-----	1







NOTE: DOUBLE FORMING HEADS SHOWN.



**ADCO**  
MANUFACTURING, INC.

2170 Academy • San Jose, California 95057 • (408) 875-5563  
TELEX #702787 FAX (408) 875-7863

SCALE: ~ DATE: 7-10-90 APPROVED BY: DRAWN BY: DK

PLUNGER ACTUATION

FORMING MACHINE

DRAWING NUMBER: CAF51






2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
PLUNGER ACTUATOR  
CAF511  
FORMING MACHINE

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>SGL</u> <u>QTY</u>	<u>DBL</u> <u>QTY</u>
1	SLIDE POST ADJ PLATE	A55CFW83	2	2
2	PLUNGER SLIDE POST	A55CFW82	2	2
3	OIL CUP	30234	2	2
4	PLUNGER SLIDE	C55CFW85	2	2
5	MALE ROD END BRG 7/16"-20 RH	AM7T	2	2
6	MANIFOLD, PLUNGER TUBE	B55CFW278	1	1
7	PLUNGER MOUNT CLAMP	B55CFW90	1	2
8	PLUNGER MOUNT	B55CFW517	1	2
9	PLUNGER BAR BRACE	B55CFW516	2	2
10	PLUNGER DRIVE ROD (HIGH SPEED)	A55CFW509	2	2
11	MALE ROD END BRG 7/16"-20 LH	AB-7T	2	2
12	PLUNGER ACTIVATING ASSY.	D55CFW15	1	1
13	SLIDE POST MTG. PLATE	A55CFW84A	2	2
14	PLUNGER BAR WELDMENT (HI SPD)	C55CFW517	1	1
	PLUNGER BAR WELDMENT (LO SPD)	C55CFW69	1	1
15	FORMING HEAD (REF.)			





**ADCO**  
MANUFACTURING, INC.

2170 Academy • San Jose, California 95131 • (408) 875-9543  
TEL. (408) 875-7887 FAX (408) 875-7885

SCALE: ~  
DATE: 2-2-90  
APPROVED BY:  
DRAWN BY: DK  
REVISION:

HOPPER, AGITATOR

FORMING MACHINE CAF508






2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
HOPPER AGITATOR  
DOUBLE HEAD  
CAF509

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>HIGH SPEED QTY</u>	<u>LOW SPEED QTY</u>
1	REMOVABLE BRG. SPINDLE	A55CFW-132	4	4
2	HOPPER REAR SUPPORT PLATE	B2808-134	1	1
3	STACK SUPPORT ROD	A55CFW-113	4	4
4	AGITATOR LINK	A2808-136	4	4
5	MALE ROD END BRG 1/4-28 R/H		8	8
6	AGITATOR LINK LOCK LEVER	B55CFW-192	8	8
7	STACK AGITATOR ROD	A55CFW-108A	4	4
8	REAR HOPPER MTG. BRACKET	B55CFW-246	1	1
9	STACK PUSHER GUIDE	A55CFW-112	4	4
10	STACK PUSHER	CAF500	2	2
11	AGITATOR LINK MTG. BRACKET	A55CFW-109	1	1
12	MALE ROD END BRG 1/4-28 R/H		2	2
13	AGITATOR BAR CONN. LINK	A55CFW-107	1	
	AGITATOR BAR CONN. LINK	A55CFW-512		1
14	HOPPER SUPPORT BRACKET	A55CFW-100	1	
	HOPPER SUPPORT BRACKET	A55CFW-508		1
15	BEARING SPACER	A55CFW-104	2	2
16	BEARING 1/4" I.D.		1	1
17	HOPPER AGITATOR BAR	A55CFW-103	1	1
18	AGITATOR CLAMP	A55CFW-105	1	1
19	AGITATOR CLAMP PLATE	A55CFW-106	1	1
20	BRG. "NEW DEPARTURE" A SERIES	77R4	2	2
21	AGITATOR BRG. SPINDLE	A55CFW-111	4	4
22	HOPPER WASHER TAB	A2808-133	4	4
23	HOPPER FRONT SUPP. PLATE	A2808-132	2	2
24	HOPPER GATE FRAME		1	1
25	FRONT HOPPER MTG. BRACKET	B55CFW-245	1	1
26	FRONT SUPP. PLATE MOUNT	A2808-131	2	2
27	STACK PUSHER CATCH	A55CFW-149	2	2







**ADCO**  
MANUFACTURING, INC.  
2170 Academy • San Jose, California 95131 • (408) 875-5563  
TELEX # 703797 FAX (408) 875-7865

SCALE	DATE	APPROVED BY	DRAWN BY
	12-19-89		DK

**FORMER DRIVE**

FORMING MACHINE	CAF50
-----------------	-------





2170 ACADEMY  
SANGER, CALIFORNIA 93657

LIST OF MATERIALS  
FORMER, DRIVE  
CAF507

<u>ITEM</u>	<u>ASSEMBLY/PART</u>	<u>PART NO</u>	<u>HIGH SPEED QTY</u>	<u>LOW SPEED QTY</u>
1	PLUNGER SLIDE	C55CFW-83	2	2
2	PLUNGER SLIDE POST	A55CFW-82	2	
3	PLUNGER DRIVE, LOW SPEED	A55CFW-75		2
4	PLUNGER DRIVE, HIGH SPEED	A55CFW-509	2	
5	ROD END BRG, MALE 7/16-20 L/H	AB-7T	2	
6	VAC. ARM CONN. LINK, LOW SPD	A55CFW-73		2
7	VAC. ARM CONN. LINK, HIGH SPD	A55CFW-511	2	
8	CNTR CONN. LINK ARM HIGH SPD	B55CFW-520	2	
9	CNTR CONN. LINK ARM LOW SPD	B55CFW-92		2
10	PIVOT SHAFT CENTER ARM	A55CFW-93	2	
11	ROD END BRG. MALE 7/16-20 R/H	AM-7T	2	
12	PLNGR ARM CONN. LINK HIGH SPD	A55CFW-510	2	
13	PLNGR ARM CONN. LINK LOW SPD	A55CFW-74		2
14	2 BOLT FLNG BRG "HUB CITY"	FB260-1 1/2	2	
15	PLUNGER ACTUATING ASS'Y	D55CFW-15	2	
16	BRG 3/4 BORE X 1 5/8 O.D. X 7/16	KP12A FAFNIR	2	
17	PLUNGER ARM DRIVE LINK	A55CFW-514	1	
18	FLAT WASHER		1	
19	PLUNGER CRANK	B55CFW-521	1	
20	SPLIT COLLAR "HOLOKROME"	1 7/8" X .688	1	
21	PLUNGER CRANKSHAFT	A55CFW-522	1	
22	PLATE, MOTOR MOUNT	A55CFW-523	1	
23	MOTOR "ECONOGEAR" HOLLOW SHFT	90E3.2-H-Z-1S	1	



# **Manufacturers Parts Lists and Instructions**



# AC Tech

---

Variable Speed AC Motor Drives

**L - SERIES**  
Installation and  
Operation Manual

# CONTENTS

	SECTION NUMBER	PAGE N. SE
GENERAL	1.0	
DESIGN SPECIFICATIONS	1.1	1
DRIVE MODEL DESIGNATION CODE	1.2	2
RATINGS	1.3	3
DIMENSIONAL DATA	1.4	5
PRODUCT CHANGES	1.5	8
WARRANTY	1.6	8
RECEIVING	1.7	8
CUSTOMER MODIFCATION	1.8	9
THEORY OF OPERATION	2.0	9
AC MOTOR OPERATION	2.1	9
DRIVE OPERATION	2.2	11
CIRCUIT DESCRIPTION	2.3	12
INSTALLATION	3.0	14
WIRING	4.0	15
POWER WIRING	4.1	15
CONTROL WIRING	4.3	17
VOLTAGE SELECTION	5.0	20
L1200 SERIES	5.1	20
L1300 SERIES	5.2	20
SETTING DIP SWITCHES	6.0	21
COAST TO STOP	6.1	21
AUTO START	6.2	21



	SECTION NUMBER	PAGE NUMBER
EXTENDED FREQUENCY RANGES	6.3	22
ACCEL. AND DECEL. TIME RANGES	6.4	23
DELAY OVER LOAD	6.5	23
DIAGNOSTIC DISPLAY	7.0	24
INITIAL POWER UP	8.0	25
CONTROL BOARD ADJUSTMENTS AND LAYOUT	9.0	26
MAXIMUM AND MINIMUM SPEED ADJUSTMENTS	9.1	27
ACCEL. AND DECEL. TIME ADJUSTMENTS	9.2	27
SLIP COMPENSATION	9.3	28
OVERLOAD LEVEL SET	9.4	28
SPEED METER CALIBRATION	9.5	28
LOAD METER CALIBRATION	9.6	29
VOLTS TO HERTZ RATIO ADJUSTMENT	9.7	29
BOOST VOLTAGE ADJUSTMENT	9.8	29
VARIABLE TORQUE ADJUSTMENT	9.9	30
CURRENT LIMIT ADJUSTMENT	9.10	30
STABILITY ADJUSTMENT	9.11	30
4-20 mA ZERO AND CALIBRATION	9.12	31
OPTIONS	10.0	32
REVERSE-DC BRAKE BOARD	10.1	32
DYNAMIC BRAKING	10.2	34
INPUT SELECT-FAULT RELAY BOARD	10.3	35
TROUBLE SHOOTING GUIDE	11.0	TS-1

THE L1000 SERIES  
ADJUSTABLE FREQUENCY AC MOTOR CONTROLS

DRIVE VOLTAGE AND MODEL				
RATED HORSEPOWER	208/230VAC	380/415VAC	460VAC	575VAC
1	L12010_	L13010_	L14010_	---
2	L12020_	L13020_	L14020_	L15020_
3	L12030_	L13030_	L14030_	L15030_
5	L12050_	L13050_	L14050_	L15050_
7.5	L12075_	L13075_	L14075_	L15075_
10	L12100_	L13100_	L14100_	L15100_
15	L12150_	L13150_	L14150_	L15150_
20	L12200_	L13200_	L14200_	L15200_
25	L12250_	L13250_	L14250_	L15250_
30	L12300_	L13300_	L14300_	L15300_
40	---	L13400_	L14400_	L15400_
50	---	L13500_	L14500_	L15500_
60	---	L13600_	L14600_	L15600_
75	---	---	L14750_	---

CAUTION!

\*\*\*\*\*

READ ALL INSTRUCTIONS BEFORE INSTALLING OR OPERATING DRIVE

(1.1) DESIGN SPECIFICATIONS

L1000 SERIES DESIGN SPECIFICATIONS

ENVIRONMENTAL:

Storage Temperature -20 - 70 C All Models

Ambient Temperature 0 - 55 C Chassis Models  
0 - 50 C Type 1 Enclosed Models  
0 - 40 C Type 4 and Type 12 Enclosed Models

Ambient Humidity Less than 93% (non-condensing)

Maximum Altitude 3300 feet above sea level

CONTROL:

Reference Voltage 0-5 VDC, 0-10 VDC, 4-20 mADC  
(Isolated, but common to control voltage)

Control Voltage 12 VDC  
(Isolated, but common to reference voltage)

Wave Form Sine Coded Pulse Width Modulated

Output Signals 0-1 mADC proportional to output frequency  
0-5 DC proportional to output frequency  
Pulse train at 6 or 192 times output frequency  
0-1 mADC proportional to output current

Frequency Stability +/- 0.005%/VAC, +/- 0.05%/ C

Speed Regulation 3% Induction motors, 1% with slip compensation  
0% Synchronous motors

Service Factor 1.15

Overload Capacity 180% for one minute (typical)

Output Frequency 0-60 Hz constant torque; 60-72,90, or 120 Hz constant hp  
0-120 Hz constant torque; 120-144,180, or 240 Hz constant hp  
Special ranges to 400 Hz

(1.2) DRIVE MODEL DESIGNATION CODE

THE CHARACTERS WHICH MAKE UP AN AC TECH DRIVE MODEL NUMBER DESIGNATE THE SERIES, INPUT VOLTAGE, HORSEPOWER, AND ENCLOSURE TYPE OF THE DRIVE.

EXAMPLE: L14250AB

(25 HP, 460 VAC, TYPE I ENCLOSURE)

L1 4 250 \* AB

SERIES:

L1 = L1000 SERIES

INPUT VOLTAGE:

1 = 120 VAC (SPECIAL)	4 = 460 VAC
2 = 208/230 VAC	5 = 575 VAC
3 = 380/415 VAC	6 = 346/380 VAC (SPECIAL)

RATED HORSEPOWER:

010 = 1 HP	100 = 10 HP	400 = 40 HP
020 = 2 HP	150 = 15 HP	500 = 50 HP
030 = 3 HP	200 = 20 HP	600 = 60 HP
050 = 5 HP	250 = 25 HP	750 = 75 HP
075 = 7.5 HP	300 = 30 HP	

\*:

S = SPECIAL (NON-STANDARD DRIVE MODEL OR OPTIONS)

T = THREE PHASE INPUT ON DRIVE MODEL WHICH USUALLY HAS  
HAS SINGLE PHASE INPUT

(WHEN PRODUCT IS STANDARD THIS CHARACTER SPACE IS ABSENT)

ENCLOSURE TYPE:

A = CHASSIS

AB = TYPE 1

C = TYPE 4

CX = TYPE 4X

D = TYPE 12

NONE

REMOVEABLE VENTED COVER WITH HINGED DOOR

TOTALLY ENCLOSED WATER TIGHT

STAINLESS STEEL TOTALLY ENCLOSED WATER TIGHT

TOTALLY ENCLOSED DUST TIGHT

L1200 SERIES RATINGS										
MODEL		INPUT					OUTPUT			
		FREQUENCY: 50-60 HZ					FREQUENCY: 0-60/72,90,120 HZ OR 0-120/144,180,240 HZ			
NUMBER	RATED HP	MAIN FUSE	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)
L12010_	1	10	208/230	1	8.2	1.9	0-208/230	3	4	1.6
L12020_	2	20	208/230	1/3	15.3/8.3	3.5/3.3	0-208/230	3	6.8	2.7
L12030_	3	30	208/230	1/3	21.8/11.8	5.0/4.7	0-208/230	3	9.6	3.8
L12050_	5	30	208/230	3	15	6.0	0-208/230	3	15.2	6.1
L12075_	7.5	30	208/230	3	21.7	8.7	0-208/230	3	22	8.8
L12100_	10	45	208/230	3	27.5	11.0	0-208/230	3	28	11.2
L12150_	15	60	208/230	3	41.4	16.5	0-208/230	3	42	16.7
L12200_	20	90	208/230	3	53.3	21.3	0-208/230	3	54	21.5
L12250_	25	90	208/230	3	67.1	26.8	0-208/230	3	68	27.1
L12300_	30	120	208/230	3	79	31.6	0-208/230	3	80	31.9

L1300 SERIES RATINGS										
MODEL		INPUT					OUTPUT			
		FREQUENCY: 50-60 HZ					FREQUENCY: 0-50/60,75,100 HZ OR 0-100/120,150,200 HZ			
NUMBER	RATED HP	MAIN FUSE	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)
L13010_	1	10	380/415	1	5.0	1.9	0-380/415	3	2.4	1.6
L13020_	2	15	380/415	1/3	9.3/5.1	3.5/3.3	0-380/415	3	4.1	2.7
L13030_	3	20	380/415	1/3	13.2/7.1	5.0/4.7	0-380/415	3	5.8	3.8
L13050_	5	20	380/415	3	9.1	6.0	0-380/415	3	9.2	6.1
L13075_	7.5	20	380/415	3	13.2	8.7	0-380/415	3	13.3	8.8
L13100_	10	30	380/415	3	16.7	11.0	0-380/415	3	17.0	11.2
L13150_	15	45	380/415	3	24.8	16.3	0-380/415	3	25.0	16.5
L13200_	20	45	380/415	3	32.7	21.5	0-380/415	3	33.0	21.7
L13250_	25	60	380/415	3	40.6	26.7	0-380/415	3	41.0	27.0
L13300_	30	60	380/415	3	47.6	31.3	0-380/415	3	48.0	31.6
L13400_	40	100	380/415	3	62.2	40.9	0-380/415	3	63.0	41.4
L13500_	50	120	380/415	3	78.0	51.3	0-380/415	3	79.0	51.8
L13600_	60	150	380/415	3	92.0	60.6	0-380/415	3	93.0	61.2

L1400 SERIES RATINGS										
MODEL		INPUT					OUTPUT			
		FREQUENCY: 50-60 HZ					FREQUENCY: 0-60/72,90,120 HZ OR 0-120/144,180,240 HZ			
NUMBER	RATED HP	MAIN FUSE	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)
L14010_	1	5	460	1	4.1	1.9	0-460	3	2.0	1.6
L14020_	2	10	460	1/3	7.7/4.2	3.5/3.3	0-460	3	3.4	2.7
L14030_	3	15	460	1/3	10.9/5.9	5.0/4.7	0-460	3	4.8	3.8
L14050_	5	15	460	3	7.5	6.0	0-460	3	7.6	6.1
L14075_	7.5	20	460	3	10.9	8.7	0-460	3	11.0	8.8
L14100_	10	20	460	3	13.8	11.0	0-460	3	14.0	11.2
L14150_	15	30	460	3	20.7	16.5	0-460	3	21.0	16.7
L14200_	20	45	460	3	26.7	21.3	0-460	3	27.0	21.5
L14250_	25	60	460	3	33.6	26.8	0-460	3	34.0	27.1
L14300_	30	60	460	3	39.6	31.6	0-460	3	40.0	31.9
L14400_	40	100	460	3	51.4	41.0	0-460	3	52.0	41.4
L14500_	50	100	460	3	64.2	51.1	0-460	3	65.0	51.8
L14600_	60	120	460	3	76.0	60.6	0-460	3	77.0	61.4
L14750_	75	120	460	3	95.0	75.6	0-460	3	96.0	76.5

L1500 SERIES RATINGS										
MODEL		INPUT					OUTPUT			
		FREQUENCY: 50-60 HZ					FREQUENCY: 0-60/72,90,120 HZ OR 0-120/144,180,240 HZ			
NUMBER	RATED HP	MAIN FUSE	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)	VOLTS (VAC)	PHASES	CURRENT (AMPS)	POWER (KVA)
L15020_	2	10	575	1/3	6.2/3.4	3.5/3.3	0-575	3	2.7	2.7
L15030_	3	15	575	1/3	8.7/4.7	5.0/4.7	0-575	3	3.9	3.9
L15050_	5	15	575	3	6.0	6.0	0-575	3	6.1	6.1
L15075_	7.5	15	575	3	8.8	8.8	0-575	3	9.0	8.9
L15100_	10	20	575	3	10.9	10.9	0-575	3	11.0	11.0
L15150_	15	30	575	3	16.8	16.7	0-575	3	17.0	16.9
L15200_	20	45	575	3	21.4	21.3	0-575	3	22.0	21.5
L15250_	25	45	575	3	27.0	26.9	0-575	3	27.0	26.9
L15300_	30	60	575	3	31.7	31.6	0-575	3	32.0	31.9
L15400_	40	60	575	3	40.7	40.5	0-575	3	41.0	40.9
L15500_	50	100	575	3	51.6	51.3	0-575	3	52.0	51.8
L15600_	60	100	575	3	61.5	61.2	0-575	3	62.0	61.7

# AC Tech

Variable Speed AC Motor Drives

AC Technology Corporation  
Uxbridge, Massachusetts 01569

## The L1000 CHASSIS AND TYPE 1 DIMENSIONS

Drawing no 1003.100.2



Sheet 1 of 1

Date 3-29-89

Drawn RMP

Checked FEL

Ref. L12010A - L15400AB



HP	VOLTAGE	CHASSIS	TYPE 1	'H'	'W'	'D'	'L'	'M'	'N'	'V'	'Y'
1	230VAC	L12010A	L12010AB	14.00"	10.00"	6.60"	1.13"	2.50"	N/A"	7.88"	0.00"
	460VAC	L14010A	L14010AB								
2	230VAC	L12020A	L12020AB	14.00	10.50	6.60	1.13	2.50	N/A	7.88	0.00
	460VAC	L14020A	L14020AB								
	575VAC	L15020A	L15020AB								
3	230VAC	L12030A	L12030AB	14.00	11.00	6.60	1.13	2.50	N/A	7.88	0.00
	460VAC	L14030A	L14030AB								
	575VAC	L15030A	L15030AB								
5	230VAC	L12050A	L12050AB	16.50	11.25	8.90	1.13	3.50	N/A	7.88	0.00
	460VAC	L14050A	L14050AB								
	575VAC	L15050A	L15050AB								
7 1/2	230VAC	L12075A	L12075AB	24.00	13.00	8.90	2.13	3.50	1.75	9.75	0.00
	460VAC	L14075A	L14075AB								
	575VAC	L15075A	L15075AB								
10	230VAC	L12100A	L12100AB	24.00	13.00	8.90	2.13	3.50	1.75	9.75	0.00
	460VAC	L14100A	L14100AB								
	575VAC	L15100A	L15100AB								
15	230VAC	L12150A	L12150AB	29.00	18.50	10.50	7.13	4.50	1.75	14.25	0.00
	460VAC	L14150A	L14150AB								
	575VAC	L15150A	L15150AB								
20	230VAC	L12200A	L12200AB	29.00	20.50	10.50	7.13	4.50	1.75	14.25	2.00
	460VAC	L14200A	L14200AB								
	575VAC	L15200A	L15200AB								
25	230VAC	L12250A	L12250AB	29.00	21.00	10.50	7.13	4.50	1.75	14.25	2.50
	460VAC	L14250A	L14250AB								
	575VAC	L15250A	L15250AB								
30	460VAC	L14300A	L14300AB	29.00	20.50	10.50	7.13	4.50	1.75	14.25	2.00
	575VAC	L15300A	L15300AB								
40	460VAC	L14400A	L14400AB	29.00	21.00	10.50	7.13	4.50	1.75	14.25	2.50
	575VAC	L15400A	L15400AB								

# AC Tech

Variable Speed AC Motor Drives

AC Technology Corporation  
Uxbridge, Massachusetts 01569

Title L1000 TYPE 4 AND TYPE 12 DIMENSIONS

Drawing no 1003.101.2

Sheet 1 of 2



Date -

Drawn RMP



Checked FEL

Ref. L12010C - L15600D

TYPE 4



TYPE 12



HP	VOLTAGE	TYPE 4	TYPE 12	'H'	'W'	'D'	'X'	'Y'
1	230VAC	L12010C	L12010D	14.00"	12.75"	8.00"	12.00"	0.00"
	460VAC	L14010C	L14010D					
2	230VAC	L12020C	L12020D	14.00	13.25	8.00	12.00	0.00
	460VAC	L14020C	L14020D					
	575VAC	L15020C	L15020D					
3	230VAC	L12030C	L12030D	14.00	13.75	8.00	12.00	0.00
	460VAC	L14030C	L14030D					
	575VAC	L15030C	L15030D					
5	230VAC	L12050C	L12050D	16.50	14.00	10.00	12.00	0.00
	460VAC	L14050C	L14050D					
	575VAC	L15050C	L15050D					
7½	230VAC	L12075C	L12075D	24.00	17.25	10.00	14.00	1.25
	460VAC	L14075C	L14075D					
	575VAC	L15075C	L15075D					
10	230VAC	L12100C	L12100D	24.00	17.75	10.00	14.00	1.25
	460VAC	L14100C	L14100D					
	575VAC	L15100C	L15100D					
15	230VAC	L12150C	L12150D	29.00	21.50	12.00	17.00	2.00
	460VAC	L14150C	L14150D					
	575VAC	L15150C	L15150D					
20	460VAC	L14200C	L14200D	29.00	21.25	12.00	17.00	1.75
	575VAC	L15200C	L15200D					
25	575VAC	L15250C	L15250D	29.00	21.50	12.00	17.00	2.00



# AC Tech

Variable Speed AC Motor Drives

AC Technology Corporation  
Uxbridge, Massachusetts 01569

Title L1000 TYPE 4 AND 12 DIMENSIONS

Drawing no. 1003.101.2

Sheet 2 of 2



Date 3-29-89

Drawn RMP

Checked FEL

Ref. L12010C - L15600D

## TYPE 4 AND TYPE 12



(3) CONDUIT KNOCKOUTS  
1.38"/1.63" DIA.  
(NOT ON TYPE 4)

HP	VOLTAGE	TYPE 4	TYPE 12	'H'	'W'	'D'	'Y'
20	230VAC	L12200C	L12200D	32.00"	27.00"	14.00"	2.50"
25	230VAC	L12250C	L12250D	36.00	32.00	16.00	3.00
	460VAC	L14250C	L14250D	32.00	27.00	14.00	2.50
30	230VAC	L12300C	L12300D	36.00	32.00	16.00	3.00
	460VAC	L14300C	L14300D	32.00	27.00	14.00	2.50
	575VAC	L15300C	L15300D				
40	460VAC	L14400C	L14400D	36.00	32.00	16.00	3.00
	575VAC	L15400C	L15400D				
50	460VAC	L14500C	L14500D	36.00	32.00	16.00	3.00
	575VAC	L15500C	L15500D				
60	460VAC	L14600C	L14600D	36.00	32.00	16.00	3.00
	575VAC	L15600C	L15600D				

#### (1.5) PRODUCT CHANGES

AC Technology Corporation reserves the right to discontinue or make modifications to the design of its products without prior notice, and holds no obligation to make modifications to products sold previously. AC Technology also holds no liability for losses of any kind which may result from this action.

#### (1.6) WARRANTY

AC Technology Corporation warrants the L1000 series AC motor control to be free of defects in material and workmanship for a period of eighteen months from the date of sale to the user, or two years from the date of manufacture, whichever occurs first. Any control component, which under normal use, becomes defective, within the stated warranty time period, shall be returned to AC Technology, freight prepaid, for examination. AC Technology Corporation reserves the right to make the final determination as to the validity of a warranty claim, and sole obligation is to repair or replace only components which have been rendered defective due to faulty material or workmanship. No warranty claim will be accepted for components which have been damaged due to mishandling, improper installation, unauthorized repair and/or alteration of the product, operation in excess of design specifications or other misuse, or improper maintenance.

AC Technology Corporation makes no claim that its products are compatible with any other equipment, or to any specific application, to which they may be applied and shall not be held liable for any other consequential damage or injury arising from the use of its products.

This warranty is in lieu of all other warranties, expressed or implied. No other person, firm or corporation is authorized to assume, for AC Technology Corporation, any other liability in connection with the demonstration or sale of its products.

#### (1.7) RECEIVING

Inspect all cartons for damage which may have occurred during shipping. Carefully unpack equipment and inspect thoroughly for damage or shortage. Report any damage to carrier and/or shortages to supplier.

All major components and connections should be examined for damage and tightness, with special attention given to PC boards, plugs, knobs, and switches.

## (1.8) CUSTOMER MODIFICATION

AC Technology, it's sales representatives and distributors, welcome the opportunity to assist our customers in applying our products. Many customizing options are available to aide in this function. AC Technology cannot assume responsibility for any modifications which have not been authorized by it's engineering department.

## (2.0) THEORY OF OPERATION

The AC Tech L1000 series drive is a high performance, sine coded, pulse width modulated (PWM), transistorized AC motor control. Many years of product development and refinements are utilized in its compact, cost effective design. The L1000 can efficiently control the output speed and torque of both induction and synchronous three phase AC motors.

### (2.1) AC MOTOR OPERATION

Three phase AC motors are comprised of two major components, the stator and the rotor. The stator is a set of three electrical windings held stationary in the motor housing. The rotor is a metal cylinder, fixed to the motor drive shaft, which rotates within the stator. The arrangement of the stator coils and the presence of three phase AC voltage give rise to a rotating magnetic field which drives the rotor.

The speed at which the magnetic field rotates is known as the synchronous speed of the motor. Synchronous speed is a function of the frequency at which the voltage is alternating and the number of poles in the stator windings. The following equation gives the relation between synchronous speed, frequency, and the number of poles:


$$S_s = 120 f / p \quad \text{Where: } S_s = \text{Synchronous speed (rpm) } \\ f = \text{frequency (Hz) } \\ p = \text{number of poles}$$

In three phase induction motors the actual shaft speed differs from the synchronous speed as load is applied. This difference is known as "slip". Slip is commonly expressed as a percentage of synchronous speed and common values are usually about three percent.

The strength of the magnetic field in the gap between the rotor and stator is proportional to the amplitude of the voltage at a given frequency. The output torque capability


of the motor is, therefore, a function of the applied voltage amplitude and frequency.

When operated below base (rated) speed, AC motors are commonly run in a mode known as "constant torque". Constant torque output is obtained by maintaining a constant ratio between voltage amplitude (volts) and frequency (hertz). For 60 hertz 230, 460, and 575 volt motors, common values for this volts to hertz ratio are 3.83, 7.66, and 9.58 respectively. Operating with these values of the volts to hertz ratio generally yields optimum torque capability. Operating at lower ratio values would lower torque and power capability. Operating at higher ratio values would cause the motor to overheat. Most standard motors are capable of providing full torque output from 3 to 60 hertz. However, at lower speeds, where motor cooling fans become less effective, supplemental cooling may be needed to operate at full torque output continuously. A typical motor derating curve is depicted below.




If the motor's applied frequency is increased while voltage remains constant, its torque capability will decrease as speed increases. This will cause horsepower capability of the motor to remain approximately constant. Motors are commonly run in this mode when operated above base speed, where drive output voltage is limited by the input line voltage. This operating range is known as the "constant horsepower" range. The typical maximum range for constant horsepower is about 2.3 to 1 (60 to 140 Hz). The diagram below depicts the operating characteristics of a typical AC induction motor.

## AC MOTOR OPERATING RANGES



### (2.2) DRIVE CONFIGURATION AND OPERATION

The L1000 series AC motor control has four major sections; an input diode bridge and filter, a driver board, a control board, and an output transistor bridge.



## (2.2 CONT.) DRIVE OPERATION

Incoming AC line voltage is converted to a pulsating DC voltage by the input diode bridge. The DC voltage is supplied to the BUS filter capacitors through a charge circuit which limits inrush current to the capacitors during power-up, and discharges the capacitors after power is removed.

```
*****  
* CAUTION! ELECTRICAL SHOCK HAZARD! *  
* DISCHARGE TIME FOR THE BUS CAPACITORS *  
* IS APPROXIMATELY THREE MINUTES! *  
*****
```

The pulsating DC voltage is filtered by the BUS capacitors which reduces the ripple level. The filtered DC voltage enters the inverter section of the drive, composed of six output transistors which make up the three output legs of the drive. Each leg has one transistor connected to the positive voltage and one connected to the negative voltage. Alternately switching on each leg transistor produces an alternating voltage on each of the corresponding motor windings. By switching each output transistor at a very high frequency (known as the carrier frequency) for varying time intervals, the inverter is able to produce a smooth, three phase, sinusoidal current wave which optimizes motor performance.

## (2.3) CIRCUIT DESCRIPTION

The flexible design of the L1000 drive allows for frequency (speed) control from four different input signals; a speed potentiometer (0-5 VDC), or an external 4-20 mA, 0-5 VDC or 0-10 VDC signal. The start/stop, reversing, jog, and speed select circuits are operated from 12 VDC. The start/stop circuit allows for either three wire (two contact) control or two wire (one contact) control. All input and output functions on the control board share a single power supply and a common terminal (number 2). The control board is isolated from the power section and can be grounded if necessary.

The rate at which the drive attempts to accelerate or decelerate the motor, to the speed commanded by the input speed signal, is determined by the ramp time of the "ACCEL-DECEL" circuit. The rates of the acceleration and deceleration ramps are separately adjustable by setting the "ACCEL" and "DECEL" potentiometers.

The L1000 has several adjustments available that can alter output voltage, frequency, and wave shape. One of these adjustments is the slip compensation which helps maintain motor speed with increased loading. Slip compensation slightly increases the output frequency as output current (load) increases. The amount of slip compensation is adjusted by the "SLIP COMP" potentiometer. The voltage output can be altered by adjusting the "VOLTS/HERTZ" potentiometer and biased at low frequency by adjusting the "BOOST" potentiometer. Biasing the volts to hertz ratio at low frequency increases the low frequency torque capability of the motor by compensating for resistance.

The Base Driver Board of the L1000 incorporates six amplifiers and protection circuits which supply power to the six output transistors. The Base Driver Board also contains a charging and discharging circuit for the BUS filter capacitors, an isolated motor current feedback circuit, a voltage feedback circuit, and a fault signal circuit.

The L1000 has many built in protection circuits. These include phase-to-phase and phase-to-ground short circuit protection, high and low line voltage protection ( $\pm 12\%$ ), protection against excessive ambient temperature and against continuous excessive output current (adjustable by the "OL" potentiometer). Activation of any of these circuits will cause the drive to shut down in a protection mode ("trip") and diagnostic display to indicate an "F", "H", "L", "A", or "P".

The L1000 has terminals for three output signals, which are proportional to output frequency; a 0-1 mA signal, a 0-5 VDC signal, and a pulse train at 6 or 192 times the output frequency. A terminal for a 0-1 mA output signal, which is proportional to motor current, is available for load indication.

The L1000 series control board comes equipped with a control relay which has an isolated form "C" contact rated at 1.5 amps resistive at 28 VDC or 120 VAC. This relay can be programed to indicate either drive run or fault.

### (3.0) INSTALLATION

```
*****
*                                     WARNING!                                     *
*                                                                              *
*  DRIVES MUST NOT BE INSTALLED WHERE SUBJECTED TO ADVERSE                *
*  ENVIRONMENTAL CONDITIONS!                                                *
*  DRIVES MUST NOT BE INSTALLED WHERE SUBJECTED TO:                        *
*  COMBUSTIBLE, OILY, OR HAZARDOUS VAPORS OR DUST; EXCESSIVE                *
*  MOISTURE OR DIRT; STRONG VIBRATION; EXCESSIVE AMBIENT                   *
*  TEMPERATURES. CONSULT AC TECHNOLOGY FOR MORE INFORMATION                 *
*  ON THE SUITABILITY OF THE L1000 SERIES DRIVE TO A                       *
*  PARTICULAR ENVIRONMENT.                                                  *
*                                                                              *
*****
```

All models of the L1000 series drive must be mounted in a vertical position for proper heatsink cooling. Chassis models should be installed in an electrical enclosure which will provide ample protection and is capable of maintaining internal ambient temperatures below 55 C (130 F). Drives with ventilated (Type 1) enclosures can be installed in ambient temperatures up to 50 C (122 F). Drives with Type 4 and Type 12 enclosures require ambient temperatures which are not above 40 C (104 F). Adequate space (2-4 inches) must be maintained around the drive to allow for convective cooling. Fans or blowers may be used to insure proper cooling in tight quarters. Other heat producing equipment should not be allowed to interfere with the proper cooling of the L1000 drive.

Extreme care must be taken to avoid damaging drive components or contaminating the drive with metal fragments (which may cause shorting of electrical circuits), when drilling holes for wiring. Cover drive components with a clean cloth to keep out metal chips and other debris when drilling. Use a vacuum cleaner to clean drive components after drilling, even if chips do not appear to be present. Do not use positive air pressure to blow chips out of drive components, (as this tends to lodge chips under drive components).

Type 4 and type 12 enclosures have brackets or knockout holes for mounting. Chassis models and Type 1 enclosures have pre-drilled mounting holes. Mounting holes on type AB enclosures can be accessed by removing the top cover and bottom plate. To remove the top cover; open the enclosure door and loosen the screw holding the top cover to the heatsink, remove the screws on the upper right (front) of the top cover and loosen the screws on the top of the drive, then slide the cover forward. The bottom plate of the enclosure can be removed by loosening the four retaining screws, pivoting the front of the plate down (about 1") and sliding the plate forward and off.



AC Technology Corporation  
Douglas Street, Uxbridge, MA 01569  
508-278-6781 FAX 508-278-7873

# AC Tech

Variable Speed AC Motor Drive

AC Technology Corporation  
Uxbridge, Massachusetts 01569

Title L1000 POWER WIRING DIAGRAM

Drawing no. 1004.018.0

Sheet 1 of 1

Date 4-17-

Drawn RMP


Checked JF

Ref.

\*\*\*\*\*  
\* DO NOT WIRE INCOMING AC TO TERMINALS T1, T2, OR T3! \*  
\*\*\*\*\*


## MODELS:

L12010-L12050  
L13010-L13075  
L14010-L14075  
L15020-L15075



## MODELS:

L12075-L12030  
L13100-L13600  
L14100-L14750  
L15100-L15600



INSTALL, GROUND, AND WIRE IN ACCORDANCE WITH ALL APPLICABLE ELECTRICAL CODES

NOTE: 1.) WIRE THE MOTOR FOR THE PROPER VOLTAGE PER THE OUTPUT RATING OF THE DRIVE. MOTOR WIRES SHOULD BE RUN IN A SEPARATE CONDUIT AWAY FROM CONTROL WIRING AND INCOMING AC POWER WIRES.

2.) USE TERMINALS L1 AND L2 FOR DRIVES NAMEPLATED AS SINGLE PHASE INPUT. USE TERMINALS L1 AND L2 FOR SINGLE PHASE INPUT, AND L1, L2, AND L3 FOR THREE PHASE INPUT FOR DRIVES NAMEPLATED AS SINGLE OR THREE PHASE INPUT. USE TERMINALS L1, L2, AND L3 FOR DRIVES NAMEPLATED AS THREE PHASE INPUT.

#### (4.0) WIRING THE L1000 SERIES DRIVE

Check applicable electrical codes for required wire type and size, grounding requirements, over-current protection, and incoming power disconnect, before wiring the L1000 drive. Input and output wire should have insulation rated to a minimum of 105 C (221 F ) and should be sized conservatively to minimize the voltage drop.

Extreme care must be taken to avoid damaging drive components or contaminating the drive with metal fragments (which may cause shorting of electrical circuits), when drilling holes for wiring. Cover drive components with a clean cloth to keep out metal chips and other debris when drilling. Use a vacuum cleaner to clean drive components after drilling, even if chips do not appear to be present. Do not use positive air pressure to blow chips out of drive components, (as this tends to lodge chips under drive components).

#### (4.1) POWER WIRING

```
*****
*
* DO NOT WIRE INCOMING AC POWER TO TERMINALS T1, T2, OR T3! *
* THIS WILL CAUSE SEVERE DAMAGE TO THE DRIVE                *
*
*****
```

An input power disconnect switch or contactor MUST be wired in series with terminals L1, L2, and L3 (L1 and L2 if input is single phase). This may be supplied by AC Tech as an option. If one has not been supplied by AC TECH, a disconnect means must be wired in during installation. This disconnect must be used to power down the drive when servicing, or when drive is not to be operated for a long period of time.

If the drive is nameplated for single phase input, wire to terminals L1 and L2. If the drive is nameplated for single or three phase input, wire to terminals L1 and L2 for single phase input, or L1, L2, and L3 for three phase input. If the drive is nameplated for three phase input, wire to terminals L1, L2, and L3.

All three power output wires, from terminals T1, T2, and T3 to the motor, must be kept tightly bundled and run in a separate conduit away from other wiring. Any switch or contactor installed in the power output wiring should NOT be operated while the drive is in operation, as this will cause the drive to "trip". Consult AC Technology for more information if disconnection during drive operation is required.



#### (4.3) CONTROL WIRING

Control signal wiring, when run external to the drive, MUST be in a separate conduit and away from all input and output power wiring. Use twisted wires or shielded cable grounded at drive panel ONLY.

##### RUN COMMAND

Start-stop control of the L1000 series can be accomplished by either a two wire or a three wire circuit. For two wire control, terminal 2 is connected to terminal 3 and the run contact is wired to terminals 1 and 2. For three wire control, a normally closed switch is wired to terminals 1 and 2 (stop signal) and a normally open switch is wired to terminals 2 and 3 (start signal).

##### SPEED REFERENCE SIGNAL

The L1000 allows for four speed reference signal types; a speed potentiometer (0-5 volt), 4-20 mA, 0-5 VDC or 0-10 VDC signals. The type of speed reference signal is selected by connecting to the proper control board terminals and moving the jumper plug on the "J4 Select Input" header to the proper position. For control by a speed pot, the pot wiper lead is connected to terminal 5A, the high and low end leads are connected to terminals 6 and 4, and the jumper plug is moved to the "POT" position on the "J4 Select Input" header. For 4-20 mA control, wire the positive to terminal 5B and the negative to terminal 2 and move the jumper plug to the "MA" position. For 0-5 VDC control or 0-10 VDC control, wire the positive to terminal 5C and the negative to terminal 2 and move the jumper plug to the "5V" or "10V" position. The input impedance of the speed control potentiometer and 0-5 VDC input is 100 K ohms, the 0-10 VDC input is 200 K ohms and the 4-20 Ma input is 100 ohms (0.4 to 2.0 VDC). Terminal 2 is circuit common (-).

##### OUTPUT FREQUENCY AND LOAD SIGNALS

The L1000 is equipped with output signals that are proportional to output frequency and current (load). These signals can be used to interface with other equipment or to operate speed and load meters.

Three signals proportional to frequency are available. Two of these are a 0-5 VDC signal with a source impedance of 560 ohms between terminals 2 and 10B and a 0-1 mA DC signal with an open circuit voltage of 6 VDC between terminals 2 and 10C. Both of

these signals are calibrated by adjusting the "SPD METER CAL" pot. There is a frequency output signal (pulse train) between terminals 2 and 10C. This frequency output signal can be selected as either 6 or 192 times the frequency of the drive power output by moving the jumper plug on the "J5 6X-192X" header to the corresponding position. The open circuit voltage of this signal is 12 VDC with a source impedance of 2200 ohms.

A 0-1 mA DC signal between terminals 2 and 11 is proportional to output current and can be used to indicate the motor load. This signal has a source impedance of 4700 Ohms and can be calibrated by adjusting the "LOAD METER CAL" pot.

See the "USER ADJUSTMENTS" section for information on how to make adjustments to these output signals.

#### RUN OR FAULT RELAY

The L1000 control board has a control relay with a form "C" contact which is connected to terminals 16, 17, and 18. This relay can be used as either a run relay or a fault relay by positioning the jumper plug of the "J6 RUN-FAULT" header.

When used as a fault relay, the relay energizes when incoming power is applied and will remain energized, unless one of the drive protection circuits ("A", "F", "H", "L", or "P") is activated. When used, the fault relay is reset by removing the run command.

When used as a run relay, the relay energizes when a start command is present and remains energized until the output frequency returns to zero after a stop command. Activation of any of the protection circuits ("A", "F", "H", "L", or "P") will also de-energize the run relay.

Note the section on Drive Diagnostics for an explanation of protection circuit display symbols.

## (5.0) VOLTAGE SELECTION

L1200 and L1300 series drives can operate, not only on input voltages of 230 VAC and 380 VAC, but also on input voltages of 208 VAC and 415 VAC respectively. Be sure the drive is properly set for the corresponding input voltage.

### (5.1) 208 VOLT INPUT ON SERIES L1200 DRIVES (230 VAC MODELS)

Model L1200 is normally shipped set to operate on 230 VAC. Models L12010 - L12050 can be operated on 208 VAC by moving plug (PL3), on the driver board, to the 208 V position. For operation on 230 VAC, plug PL3 MUST be in the 230 V position. On models L12075 - L12300, 208 VAC or 230 VAC operation can be set with switch SW901 on the Line Voltage Board. Moving this switch selects the proper primary winding in the Control Transformer.

```
*****
*  WARNING: Operation of the drive on 230 VAC input while  *
*  the drive is set for 208 VAC input will damage the      *
*  Control Transformer, Control Board, and Output          *
*  Transistors.                                             *
*****
```

### (5.2) 415 VOLT INPUT ON SERIES L1300 DRIVES (380 VAC MODELS)

Model L1300 is normally shipped set to operate on 380 VAC. Models L13010 - L13075 can be operated on 415 VAC by moving plug (PL3), on the driver board, to the 415 V position. For operation on 380 VAC, plug PL3 MUST be in the 380 V position. On models L13100 - L13600, 380 VAC or 415 VAC operation can be set with switch SW901 on the Line Voltage Board. Moving this switch selects the proper primary winding in the Control Transformer.

```
*****
*  WARNING: Operation of the drive on 415 VAC input while  *
*  the drive is set for 380 VAC input will damage the      *
*  Control Transformer, Control Board, and Output          *
*  Transistors.                                             *
*****
```

## (6.0) SETTING DIP SWITCHES (SW101)

### (6.1) COAST TO STOP (SWITCH S101-1)

When the "COAST STOP" switch is in the "off" position and the drive is issued a stop command, the output frequency of the drive is reduced to zero at the rate set by "SW101-6", "SW101-7", or "SW101-8" and adjusted with the "DECEL" pot. Stopping in this mode causes the motor to stop in a controlled fashion.

When the "COAST STOP" switch is in the "on" position, the drive is in the coast to stop mode. When a stop command is given, the drive instantaneously de-energizes the motor, allowing the motor to coast. Brake motors are usually run in this mode.

### (6.2) AUTO START (SWITCH S101-2)

Putting this switch in the "off" position prevents the drive from starting when line voltage is applied with the start command already closed. If input voltage is applied while the start command is closed, the diagnostic display will show "e" indicating a start error. To start the drive, open the start command to clear the error and re-apply the start. Drives are usually shipped with this switch in the "off" position.

This switch is placed in the "on" position for applications requiring automatic start whenever power is applied to the drive. To run in this mode the "AUTO START" switch is put in "on" position and the start circuit is kept closed. The drive should not be started frequently (more than three times per hour), using the auto start feature.

```
*****
*
*                                     CAUTION!
*   INSURE THAT AUTOMATIC START WILL NOT CAUSE INJURY!
*
*****
```



### (6.3) EXTENDED FREQUENCY RANGES (SWITCHES 101-3, 4, AND 5)

The output frequency range of 0-60 Hz constant torque can be extended to 72, 90, or 120 Hz constant horsepower or 0-120 Hz constant torque and 144, 180, or 240 constant horsepower by positioning switches SW101-3, SW101-4, SW101-5, and either removing (open) or not removing (close) jumper wire J3. These switches are labeled "WAVE SEL", "FREQ SEL A", and "FREQ SEL B". The table below lists these setting combinations as well as those for 50 hertz input models (L1300 series).

\*\*\*\*\*  
 \* CAUTION! \*  
 \* OPERATING MOTORS OR DRIVEN LOADS ABOVE THE MANUFACTURER'S \*  
 \* RATED SPEED CAN CAUSE DAMAGE TO EQUIPMENT AND INJURY TO \*  
 \* PERSONNEL. CONSULT MOTOR AND EQUIPMENT MANUFACTURER FOR \*  
 \* INFORMATION CONCERNING SAFE OPERATION ABOVE RATED SPEEDS. \*  
 \* \*\*\*\*\*

DIP SWITCH SETTINGS FOR 60 HERTZ INPUT DRIVES (SERIES L1200, L1400, AND L1500)				
SW101-3	SW101-4	SW101-5	J3	DESIRED OUTPUT FREQUENCY RANGE
ON	ON	ON	EITHER	0-60 Hz (CT) SINE WAVE
ON	OFF	ON	EITHER	0-60 Hz (CT) 60-72 Hz (CHP) SINE WAVE
ON	ON	OFF	EITHER	0-60 Hz (CT) 60-90 Hz (CHP) SINE WAVE
ON	OFF	OFF	EITHER	0-60 Hz (CT) 60-120 Hz (CHP) SINE WAVE
OFF	ON	ON	CLOSED	0-60 Hz (CT) SQUARE WAVE
OFF	OFF	ON	CLOSED	0-60 Hz (CT) 60-72 Hz (CHP) SQUARE WAVE
OFF	ON	OFF	CLOSED	0-60 Hz (CT) 60-90 Hz (CHP) SQUARE WAVE
OFF	OFF	OFF	CLOSED	0-60 Hz (CT) 60-120 Hz (CHP) SQUARE WAVE
OFF	ON	ON	OPEN	0-120 Hz (CT) SQUARE WAVE
OFF	OFF	ON	OPEN	0-120 Hz (CT) 120-144 Hz (CHP) SQUARE WAVE
OFF	ON	OFF	OPEN	0-120 Hz (CT) 120-180 Hz (CHP) SQUARE WAVE
OFF	OFF	OFF	OPEN	0-120 Hz (CT) 120-240 Hz (CHP) SQUARE WAVE
DIP SWITCH SETTINGS FOR 50 HERTZ INPUT DRIVES (SERIES L1300)				
SW101-3	SW101-4	SW101-5	J3	DESIRED OUTPUT FREQUENCY RANGE
ON	ON	ON	EITHER	0-50 Hz (CT) SINE WAVE
ON	OFF	ON	EITHER	0-50 Hz (CT) 50-60 Hz (CHP) SINE WAVE
ON	ON	OFF	EITHER	0-50 Hz (CT) 50-75 Hz (CHP) SINE WAVE
ON	OFF	OFF	EITHER	0-50 Hz (CT) 50-100 Hz (CHP) SINE WAVE
OFF	ON	ON	CLOSED	0-50 Hz (CT) SQUARE WAVE
OFF	OFF	ON	CLOSED	0-50 Hz (CT) 50-60 Hz (CHP) SQUARE WAVE
OFF	ON	OFF	CLOSED	0-50 Hz (CT) 50-75 Hz (CHP) SQUARE WAVE
OFF	OFF	OFF	CLOSED	0-50 Hz (CT) 50-100 Hz (CHP) SQUARE WAVE
OFF	ON	ON	OPEN	0-100 Hz (CT) SQUARE WAVE
OFF	OFF	ON	OPEN	0-100 Hz (CT) 100-120 Hz (CHP) SQUARE WAVE
OFF	ON	OFF	OPEN	0-100 Hz (CT) 100-150 Hz (CHP) SQUARE WAVE
OFF	OFF	OFF	OPEN	0-100 Hz (CT) 100-200 Hz (CHP) SQUARE WAVE
"CT" = CONSTANT TORQUE "CHP" = CONSTANT HORSEPOWER				

#### (6.4) ACCEL AND DECEL TIME RANGES (SWITCHES SW101-6,7,8)

The L1000 series has three ranges in which the ACCEL (acceleration) and DECEL (deceleration) times can be adjusted. These ranges, 6 to 75, 1 to 12, or 0.2 to 2.4 seconds, are set by switching on SW101-6, 7, or 8 respectively. Note one, but only one, of these switches must be in the "on" position. After the ACCEL and DECEL time range has been chosen, the ACCEL and DECEL times can be adjusted individually by following the procedure in the adjustment section.

#### (6.5) DELAY OVERLOAD (SWITCH SW101-9)

This switch puts the overload protection circuit in either a delay mode (switch "on") or in an instantaneous mode (switch "off"). When the overload protection circuit senses current overload, it shuts down the drive and displays a "P" on the diagnostic display.

In the instantaneous mode, the overload protection circuit is triggered instantaneously upon sensing a current level above that set with the "OL" potentiometer.

In the delay mode, the overload protection circuit trigger time is delayed. The length of this delay is inversely proportional to the amount by which the overload limit (set with the "OL" potentiometer) has been exceeded.

## (7.0) DIAGNOSTIC DISPLAY

The diagnostic display indicates the status of the drive by displaying one of the symbols in the table below. The display is located in the enclosure door on enclosed models or on the the control board of chassis models.

TABLE I      DIAGNOSTIC DISPLAY CODES		
SYMBOL	MEANING	DRIVE STATUS
-	(INPUT)	INPUT POWER TO DRIVE IS ON - DRIVE NOT IN RUN MODE
O	(OUTPUT)	OUTPUT POWER PRESENT - DRIVE IN RUN MODE ("O" WILL BE 5/6 LIT AND ROTATING)
A	(AMBIENT)	DRIVE IN PROTECTION TRIP DUE TO HIGH AMBIENT TEMPERATURE, ABOVE 75 C
C	(CURRENT)	DRIVE OPERATING IN "CURRENT LIMIT"
F	(FAULT)	DRIVE IN PROTECTION TRIP DUE TO GROUND OR PHASE TO PHASE SHORT CIRCUIT
H	(HIGH)	DRIVE IN PROTECTION TRIP DUE TO HIGH INPUT LINE VOLTAGE
L	(LOW)	DRIVE IN PROTECTION TRIP DUE TO LOW INPUT LINE VOLTAGE
P	(PROTECT)	DRIVE IN PROTECTION TRIP DUE TO EXCESSIVE MOTOR LOAD
8	(OVER RIDE)	DRIVE OPERATING IN DECEL OVER-RIDE MODE
e	(ERROR)	START ERROR - INCOMING VOLTAGE HAS BEEN APPLIED WITH START CIRCUIT CLOSED
.	(REVERSE)	DRIVE OPERATING IN REVERSE (DOT IS IN LOWER RIGHT OF DISPLAY - NEXT TO "O")

## (8.0) INITIAL POWER UP

```
*****
*
*           WARNING!   HAZARD OF ELECTRICAL SHOCK!
*
* THE DRIVE'S POWER COMPONENTS, BASE DRIVER BOARD AND MOTOR
* ARE AT LINE VOLTAGE WHEN THE INCOMING LINE IS ENERGIZED
* AND FOR UP TO THREE MINUTES AFTER LINE VOLTAGE IS
* REMOVED. ALWAYS REMOVE LINE VOLTAGE AND CHECK TO BE SURE
* BUS CAPACITORS HAVE DISCHARGED BEFORE SERVICING DRIVE.
*
*****
```

Before attempting to operate drive, motor, and driven equipment follow the procedures in this section.

Disconnect the driven load from the motor. Verify that the drive input terminals L1, L2, and L3 (L1 and L2 for single phase input) are wired to the proper input voltage (per the nameplate rating of the drive). For L1200 and L1300 series drives, verify the control transformer voltage has been properly selected, as noted in the "VOLTAGE SELECTION" section. Verify output terminals T1, T2, and T3 are wired to the proper (correct voltage) leads on the motor. Set the external speed control signal and the "MIN FREQ", "ACCEL", and "DECEL" potentiometers to minimum.


```
*****
*
*   INCOMING AC POWER MUST NOT BE WIRED TO T1, T2, OR T3!
*
*****
```

Energize the incoming power line. The diagnostic display should display a "-". Close the start command, the drive should now be in the run mode and displaying the run symbol (5/6 of an "O"). Increasing the speed control signal (increasing the setting on the speed pot) should increase the motor speed and the speed at which the "O" on the display rotates. Decreasing the speed control signal should decrease the speed of the motor and the display. Opening the start command (issuing a stop command) should decelerate the motor to a stop and return the display to a "-".

If the motor rotates in the wrong direction, remove the incoming power, wait three minutes, check to be sure the bus capacitors have discharged and swap motor wires connected to T1 and T2. If the "O" on the display does not appear or will not

rotate, remove the incoming power, wait three minutes, check to be sure the bus capacitors have discharged, and verify correct installation of wiring. If wiring is correct, re-apply incoming power, note display for drive status, and consult the trouble shooting guide.

## (9.0) CONTROL BOARD ADJUSTMENTS



THE L1000 SERIES CONTROL BOARD (960-3XX)

#### (9.1) MAXIMUM AND MINIMUM SPEED ADJUSTMENT

The "MAX FREQ" and "MIN FREQ" potentiometers are used to set maximum and minimum motor speeds when the speed control signal is from an external potentiometer (wired to terminals 4, 5A, and 6), but have no effect on 4-20 mA, 0-5 VDC, or 0-10 VDC speed control reference signals.

Select the desired frequency range per the "SETTING DIP SWITCHES - EXTENDED FREQUENCY RANGES" section, before setting the "MAX FREQ" and "MIN FREQ" potentiometers. Turn the external speed potentiometer to minimum, full counterclockwise. Start the drive and slowly turn the "MIN FREQ" potentiometer clockwise until the motor reaches the desired minimum speed. Minimum frequency can be set from 0% to 50% of the selected frequency range.

Slowly turn the external speed potentiometer to maximum, full clockwise. With the drive running at full speed, slowly turn the "MAX FREQ" potentiometer counterclockwise until the motor reaches the desired maximum speed. Maximum frequency can be set down to 50% of the selected frequency range.

#### (9.2) ACCELERATION AND DECELERATION TIME ADJUSTMENT

These adjustments affect the rate of speed change during starts, stops, or when the speed control reference signal is raised or lowered. The acceleration or deceleration times can be adjusted within the ranges selected with dip switches 6, 7, and 8 (see "DIP SWITCH SETTING"). Turning the "ACCEL" or "DECEL" potentiometer counterclockwise will increase the acceleration or deceleration time.

If the inertia of the driven load requires greater torque (current) to accelerate than can be provided by the drive at the existing "CURRENT LIMIT" setting, the acceleration time will automatically increase. This will cause the diagnostic display to indicate a "C" as the motor accelerates.

Minimum deceleration time for large inertia loads is typically three to four times the minimum acceleration time. With the use of an optional dynamic braking assembly, deceleration time can equal minimum acceleration time (See "DYNAMIC BRAKING"). If the inertia of the driven load requires a greater deceleration time than the rate set on the "DECEL" potentiometer, the time will automatically increase and the center bar of the diagnostic display will flash. This condition is more prevalent at higher motor speeds.

### (9.3) SLIP COMPENSATION

The slip compensation circuit increases output frequency to compensate for motor slippage caused by increased load (see the "AC MOTOR OPERATION" section for an explanation of slip).

Turning the "SLIP COMP" potentiometer clockwise increases slip compensation. If the "SLIP COMP" potentiometer is set too high, the motor speed may become unstable and "hunting" may occur. This may cause one of the drive protection circuits to activated ("H", "F", "P", or "C" on status indicator).

### (9.4) OVERLOAD LEVEL SET

The "O.L. LEVEL SET" potentiometer sets the level of motor current (load) that will activate the protection circuit and shut the drive down ("trip the drive"). This adjustment is used in either an instantaneous or delayed mode, depending on the setting of dip switch SW101-9 (see "DIP SWITCH SETTINGS"). The overload level adjustment has a range of 70% (full counterclockwise) to 180% (full clockwise) on the "O.L. LEVEL SET" potentiometer.

When operated in the instantaneous trip mode (SW101-9 "OFF"), any load which causes motor current to exceed the set overload level will instantaneously cause the drive to trip. When in the delayed mode, a motor load causing motor current to exceed the overload level will not trip the drive until a delay period has passed. The length of this delay period is inversely proportional to the amount by which the overload limit has been exceeded.

To adjust the "O.L. LEVEL SET" setting, first determine the type of trip required for the given application and set dip switch 101-9. Note the full load current rating of both the drive and the motor. Turn the "O.L. LEVEL SET" potentiometer, fully counterclockwise. Operate the drive and motor under load for thirty minutes. The output current should remain within the rated limits. If a nuisance trip occurs during operation, turn the "O.L. LEVEL SET" clockwise one division. Repeat this procedure until satisfactory performance is achieved.

### (9.5) SPEED METER CALIBRATION

The "SPD METER CAL" potentiometer is used to adjust the analog output frequency indicating signals, which are used to indicate motor speed (see "OUTPUT FREQUENCY AND LOAD SIGNALS" in the "CONTROL BOARD WIRING" section). Turning the "SPD

METER CAL" potentiometer clockwise increases the level of the 0-1mA and 0-5 VDC signal with respect to the output frequency of the drive.

#### (9.6) LOAD METER CALIBRATION

The "LOAD METER CAL" potentiometer is used to adjust the 0-1 mA DC current indicating signal. This signal can be used to power a load meter (see "OUTPUT FREQUENCY AND LOAD SIGNALS" in the "CONTROL BOARD WIRING" section). Turning the "LOAD METER CAL" potentiometer clockwise increases the level of this signal with respect output current of the drive. This signal has approximately a 4 to 1 range. When used with digital meters , a 22 MFD, 16 VDC tantalum capacitor connected between terminals 2 (negative) and 11 (positive) on the control board may be needed for filtering.

#### (9.7) VOLTS TO HERTZ RATIO ADJUSTMENT

The "V/Hz" potentiometer is used to change the ratio between drive output voltage (Volts) and frequency (Hertz). This ratio has a unique value which optimizes motor output (see the "AC MOTOR OPERATION" section).

Standard L1200, L1400, and L1500 series are preset at the factory for full rated output voltage of 230, 460, and 575 VAC at 60 Hz, with V/Hz ratios of 3.83, 7.67, and 9.58 respectively. Standard L1300 series drives are set for full rated voltage output of 380 VAC at 50 Hz, with a V/Hz ratio of 7.60. Factory settings are marked in red but can be changed if needed for special motors or applications. Adjustable range is 60% to 110% of normal ratio.

To re-set volts per hertz ratio, first turn the "V/Hz" potentiometer to a near fully counterclockwise position and place an ANALOG AC voltmeter (must be analog) across output terminals T1 and T2. Start the drive and, using a tachometer (not the speed meter on the drive), set the motor to 90% of the rated motor speed. Turn the "V/Hz" potentiometer clockwise until the measured voltage reaches 90% of rated voltage (207 VAC for 230 VAC drives, 342 VAC for 380 VAC drives, 414 VAC for 460 VAC, and 518 VAC for 575 VAC drives).

#### (9.8) BOOST VOLTAGE ADJUSTMENT

The "BOOST" potentiometer is used to increase the amount of voltage applied to the motor when the drive is operated at very low output frequencies.

At lower motor speeds, a large percentage of available output



voltage is used to overcome resistance in the motor windings rather than producing motor current (torque). Increasing the voltage at low speed can compensate for resistance in the motor windings and increase low speed torque.

Turn the "BOOST" clockwise to increase the motor starting and low speed torque. Decrease the setting if the motor exhibits excessive low speed cogging or heating.

#### (9.9) VARIABLE TORQUE ADJUSTMENT

The variable torque adjustment is used for applications where less torque is required as speed decreases and lower motor noise is desirable. Centrifugal fans and pumps, installed in commercial buildings, are typical applications of this type.

When the "VAR TORQ" potentiometer is full counterclockwise the drive is in the standard operating (constant torque) mode. Turning the "VAR TORQ" potentiometer clockwise will reduce motor torque and noise at lower speeds, but may cause the motor to stall if set too high.

#### (9.10) CURRENT LIMIT ADJUSTMENT

The "CURRENT" potentiometer is used to limit the maximum power output current the drive will produce. The limit is increased by turning the potentiometer clockwise, and has a 0 to 180% range. The limit is set at maximum current at the factory, but can be decreased if an application requires a limited maximum setting of the torque or power (current) level.

#### (9.11) STABILITY ADJUSTMENT

Some high efficiency or low slip motors may exhibit instability (speed oscillation) when operated at low speeds. This generally occurs between 12 and 24 hertz. The L1000 is equipped with a stability circuit which usually can eliminate this condition.


To make the stability adjustment, first turn the "STAB" potentiometer fully counterclockwise and operate the motor at the speed where the greatest degree of instability occurs. Turn the "STAB" potentiometer clockwise, slightly, until the condition is minimized. Setting this adjustment too high may cause instability at higher speeds and/or a drive protection trip which displays "F" or "H" on the diagnostic.

#### (9.12) 4-20 mA ZERO AND CALIBRATION ADJUSTMENTS

A 4-20 mA reference signal (follower), used to control speed (see "SPEED REFERENCE SIGNALS" in the "CONTROL BOARD WIRING" section), can be zeroed and calibrated using the "4-20 ZERO" and "4-20 CAL" potentiometers. These potentiometers are preset at the factory for the full speed range of operation and marked in red, but can be changed if necessary.

The "4-20 ZERO" potentiometer is used to "zero" the output frequency corresponding to a 4 mADC input signal. Turning the potentiometer clockwise increases output frequency which corresponds to a 4 mA input signal.

The "4-20 CAL" potentiometer calibrates the signal by setting the output frequency which corresponds to a 20 mADC input signal. Turning the potentiometer clockwise increases the frequency which corresponds to a 20 mA input signal.



THE L1000 SERIES CONTROL BOARD (960-3XX)

(10.0) OPTIONS

(10.1) REVERSE-DC BRAKE BOARD (P/N 970-XXX)


The L1000 series "REVERSE-DC BRAKE BOARD" features both electronic reversing and DC braking. Electronic reversing allows motor rotation to be switched from one direction to the other. DC braking applies low level DC voltage to the motor stator coils, which produces shaft stopping (holding) torque. This can be used to help bring a coasting motor shaft to a stop or to hold a stopped motor shaft.

The reversing circuit can be used to change the direction of motor rotation, either while the motor is rotating or when the motor is stopped. If the reversing circuit is activated while the motor shaft is rotating, the drive's output frequency is reduced at the rate set by the selected ACCEL/DECEL range and the deceleration adjustment, and reverse rotation is subsequently increased at the rate set by the acceleration adjustment. If the motor is stopped and a reversing command is given, the direction of motor rotation will be opposite that which it was prior to stopping when it is restarted. A direction signal is given by closing a contact between terminals 8 or 9 (forward or reverse) on the reversing board and terminal 2. If neither terminal 8 or 9 are closed to terminal 2, LED 901 will light, and the drive will decelerate to a stop.

The DC braking circuit applies low level DC voltage to the motor after a stop command is given. The DC voltage is applied to the motor after the output frequency of the drive has gone to zero, or instantaneously, if the drive is in the "coast to stop mode" (switch SW101-1 "on"). The DC braking voltage may be selected to be applied continuously by placing the jumper plug in the "CONT" position on the J902 header or it may be set for a duration which can range from 0.25 to 10 seconds by placing the jumper plug in the "TMD" position and adjusting the "BRK TM" pot. The DC braking circuit can be de-activated externally by closing a contact wired between terminal 2 and terminal 14 on the "REVERSE-DC BRAKE BOARD". The magnitude of the applied DC voltage is adjusted with the "BRK VDC" pot.

```
*****
*                                     *
*          CAUTION!                  *
*  SETTING A CONTINUOUSLY APPLIED DC BRAKING          *
*  VOLTAGE TOO HIGH MAY CAUSE OVERHEATING OF THE      *
*  MOTOR!  MOTOR TEMPERATURE SHOULD BE MAINTAINED    *
*  WITHIN RATED LIMITS.                  *
*****
```

The Reverse-DC Braking Board can be installed on any 960-3XX series control board which is equipped with plug "PL106". To install, clip supplied standoffs into the bottom of the option board, plug into "PL106", and secure with the screws supplied. Wire the board per the diagram on the board itself (shown below). Note, that closing terminal 14 to terminal 2 DE-ACTIVATES the DC brake.



THE REVERSE-DC BRAKING OPTION BOARD (970-XXX)

## (10.2) DYNAMIC BRAKING

### STANDARD DUTY DYNAMIC BRAKING (P/N DB1XXXX)

The standard duty dynamic braking option consists of a circuit board on models L1X010 through L1X030 and a circuit board and separate resistor assembly on models L1X050 through L1X750. Circuit boards are mounted to the drive panel with two 8-32x3/8 thread forming (chip free) screws and the resistor assembly, when required, is mounted to the inside of the enclosure using 10-32x3/8 thread forming (chip free) screws, lockwashers, and nuts. When field mounting the standard dynamic brake option, note the accompanying installation and wiring instructions.

Standard duty dynamic brakes are not recommended for continuous cycling applications which require stopping inertial loads greater than twice that of the; motor from 1800 rpm more than eight times, from 2500 rpm more than four times, or from 3600 rpm more than two times, during a five minute period.

### HEAVY DUTY DYNAMIC BRAKING (P/N HDB1XXXX)

The heavy duty dynamic braking option is capable of providing more frequent stopping and stopping larger inertia loads than the standard duty dynamic braking option by using externally mounted resistors.

All heavy duty dynamic braking options consist of a circuit board, a separate resistor assembly (mounted external to the enclosure containing the drive) and a protective ventilated cover for the resistor assembly. Circuit boards are mounted to the drive panel with two 8-32x3/8 thread forming (chip free) screws and the resistor assembly and ventilated cover are mounted using 10-32x3/8 thread forming (chip free) screws, lockwashers, and nuts. When field mounting the heavy duty dynamic brake option, note the accompanying installation and wiring instructions.

Continuous braking ("hold back") of; 100% (of motor rated torque) at output frequencies up to 15 Hz (25% of motor base speed), 50% at output frequencies up to 30 Hz (50% of motor base speed), and 25% at output frequencies up to 60 Hz (100 of motor base speed) is possible.

Intermittent (once per minute) braking ("hold back") at 180% of motor rated torque is possible for; thirty seconds at output frequencies up to 15 Hz (25% of motor base speed) fifteen seconds at output frequencies up to 30 Hz (50% of

motor base speed), and seven seconds at output frequencies up to 60 Hz (100% of motor base speed).

Heavy duty dynamic braking is not recommended for continuous cycling applications which require stopping inertial loads greater than twice that of the motor from 1800 rpm more than eight times, from 2500 rpm more than four times, or from 3600 rpm more than two times, during a one minute period.

Consult AC Technology if assistance is needed when selecting or sizing a dynamic brake option. Please have available information concerning the number of stops per minute, required stopping time, motor operating speed, inertia of the driven load, and the motor frame size.


### (10.3) INPUT SELECT-FAULT RELAY BOARD (P/N 969-XXX)

The "INPUT SELECT-FAULT RELAY BOARD" combines a fault relay circuit, four internal speed potentiometers, and a control signal selection circuit. This option allows for jogging, switching from auto to manual speed control, up to four internal preset speeds, a fault indicating relay, and switching between a variety of speed references.

This board augments the existing choice of speed references with four internal potentiometers for use as preset speeds. One of these potentiometers can be set to override any active speed reference for jogging applications. The fault relay is similar to the run/fault relay built into the L1000 series control board except that it functions only as a fault relay.

The INPUT SELECT-FAULT RELAY board can be installed on any 960-3XX series control board which is equipped with jumper header "J4 SELECT INPUT" and plug "PL107". To install clip the supplied standoffs into the bottom of the option board, plug into the "J4 SELECT INPUT" plug and "PL107", and secure with the supplied screws.

The input selection circuit allows selection of the active speed reference signals by an external switches. Control can be switched between a maximum of four possible selections. The position of jumper plugs J301 through J305 set the type of reference at each selection and closure of contacts between terminal 2 on the control board and terminals 12, 13A, 13B, and 13C on the option board determine which reference signal is active. Note the diagram and INPUT SELECTION AND SETTING table below.



1.) JOG BUTTON OR PRESET SPEED #1

- a) JOG: If J301 is in the "JOG" position and terminal 12 to terminal 2 is closed the drive will START AND RUN at the speed set on the "JOG" potentiometer.  
NOTE: THIS SETUP AND SELECTION OVERRIDES ANY OTHER REFERENCE THAT MIGHT BE ACTIVE INCLUDING "STOP".
- b) If J301 is in the "2SPD" position, terminal 12 to terminal 2 is closed and the drive run command is closed, the drive will run at the speed set on the "JOG" potentiometer (preset #1).

a) EXT. POTENTIOMETER: If J303 is in the "R" position, terminal 13A to terminal 2 is closed, terminal 12 to terminal 2 is open and the drive run command is closed, the drive will run at the speed set by the external speed potentiometer signal applied at terminal 5A.

- b) If J303 is in the "L" position, terminal 13A TO terminal 2 is closed, terminal 12 to terminal 2 is open and the drive run command is closed, the drive will run at the speed set on the internal "Input 13A" potentiometer (preset #2).

3.) 4-20 mA INPUT OR PRESET SPEED #3

- a) 4-20 mA INPUT: If J304 is in the "R" position, terminal 13B to terminal 2 is closed, terminal 12 to terminal 2 is open and the drive run command is closed, the drive will run at the speed set by the external 4-20mA DC signal applied to terminal 5B.
- c) If J304 is in the "L" position, terminal 13B to terminal 2 is closed, terminal 12 to terminal 2 is open and the drive run command is closed, the drive will run at the speed set on the internal "Input 13B" potentiometer (preset #3).

4.) 0-5 VDC OR 0-10 VDC OR PRESET SPEED #1

- a) 0-5 VDC INPUT: If J305 is in the "R" position, terminal 13C to terminal 2 is closed, terminal 12 to terminal 2 is open, J302 is in the "5V" position and drive run command is closed the drive will run at the speed set by the external 0-5 VDC signal applied to terminal 5C.
- b) 0-10 VDC: If J305 is in the "R" position, terminal 13C to terminal 2 is closed, terminal 12 to terminal 2 is open, J302 is in the "10V" position and drive run command is closed the drive will run at the speed set by the external 0-10 VDC signal applied to terminal 5C.
- c) If J305 is in the "L" position, terminal 13C to terminal 2 is closed, terminal 12 to terminal 2 is open and the drive run command is closed, the drive will run at the speed set on the internal "Input 13C" potentiometer (preset #4).



\* \* \*

\*\*\*\*\*  
WARNING!  
\*\*\*\*\*

\*\*\*\*\*  
HAZARD OF ELECTRICAL SHOCK  
\*\*\*\*\*

ELECTRICAL COMPONENTS OF THE DRIVE AND MOTOR ARE AT LINE VOLTAGE WHEN THE INCOMING LINE IS ENERGIZED AND FOR UP TO ONE MINUTE AFTER LINE VOLTAGE IS REMOVED. ALWAYS REMOVE LINE VOLTAGE AND VERIFY THAT BUS CAPACITORS HAVE FULLY DISCHARGED BEFORE TOUCHING ANY ELECTRICAL PART OF THE DRIVE OR MOTOR. ALL DRIVE SERVICING MUST BE PERFORMED BY QUALIFIED PERSONNEL USING APPROPRIATE CAUTION. CONNECTING GROUNDED OR NON-INSULATED TEST LEADS TO THE L1000 SERIES DRIVE MAY DAMAGE THE DRIVE AND THE TEST EQUIPMENT.

\* \* \*

- 1) Analog type V.O.M. meter (Simpson #260/270 or equivalent)
- 2) Clamp-on ammeter
- 3) Basic hand tools

Do not alter the setting of any of the drive's adjustments unless instructed to do so.

Under the heading of REMEDY, component test (number) are called for. Refer to the end of the trouble shooting guide for information on how to perform these tests.

If further assistance is needed in locating a drive problem, consult your local sales representative or AC Technology Corporation.

## DIAGNOSTIC DISPLAY

The diagnostic display indicates the status of the drive by displaying one of the symbols shown below. The display is located in the enclosure door on enclosed models or on the control board of chassis models.

TABLE I DIAGNOSTIC DISPLAY CODES

SYMBOL	MEANING	DRIVE STATUS
-	(INPUT)	INPUT POWER TO DRIVE IS ON - DRIVE NOT IN RUN MODE
O	(OUTPUT)	OUTPUT POWER PRESENT - DRIVE IN RUN MODE ("O" WILL BE 5/6 LIT AND ROTATING)
A	(AMBIENT)	DRIVE IN PROTECTION TRIP DUE TO HIGH AMBIENT TEMPERATURE (ABOVE 75 DEGREES CELSIUS)
C	(CURRENT)	DRIVE OPERATING IN "CURRENT LIMIT"
F	(FAULT)	DRIVE IN PROTECTION TRIP DUE TO GROUND OR PHASE TO PHASE SHORT CIRCUIT
H	(HIGH)	DRIVE IN PROTECTION TRIP DUE TO HIGH INPUT LINE VOLTAGE
L	(LOW)	DRIVE IN PROTECTION TRIP DUE TO LOW INPUT LINE VOLTAGE
P	(PROTECT)	DRIVE IN PROTECTION TRIP DUE TO EXCESSIVE MOTOR LOAD
8	(OVER RIDE)	DRIVE OPERATING IN DECEL OVER-RIDE MODE
e	(ERROR)	START ERROR - INCOMING VOLTAGE HAS BEEN APPLIED WITH START CIRCUIT CLOSED
.	(REVERSE)	DRIVE OPERATING IN REVERSE (DOT IS IN LOWER RIGHT OF DISPLAY - NEXT "O")

# DIFFICULTY

## POSSIBLE CAUSE

## REMEDY

1. Diagnostic Display is not lit, motor does not operate and:

A. No AC line power at terminals L1, L2, and L3 (with 3 phase input)

a. An open line disconnect switch, fuse, circuit breaker or incoming wiring

a. Locate and correct

B. Drive Main Fuse (s) 1FU and/ or 2FU blown

a. Defective fuse  
b. Short or ground in motor or motor wiring

a. Replace  
b. Repair or replace

c. short or ground in drive wiring  
d. Defective Input Dode Bridge  
e. Defective Bus Filter Capacitor(s)  
f. Defective Transistor Module(s)  
g. Defective Control Transformer  
h. Defective Base Driver Board

c. Locate and correct  
d. Test (#1), replace if defective  
e. Test (#2), replace if defective  
f. Test (#3), replace if defective  
g. Test (#4), replace if defective  
h. Replace and return to AC Tech for service  
i. Replace and return to AC Tech for service

C. Control Fuse 6FU Blown (this fuse is labeled 901FU on some models)

a. Defective Fuse  
b. Defective Base Driver Board

a. Replace  
b. Replace and return to AC Tech for service  
c. Replace and return to AC Tech for service  
d. Test (#4), replace if defective

D. AC line voltage is present and all fuses are good

a. Defective Control Transformer  
b. Defective Control Board

a. Test (#4), replace if defective  
b. Replace and return to AC Tech for service  
c. Replace and return to AC Tech for service

2. Diagnostic Display indicates 'e' when incoming power is applied to drive.

a. Start Command is closed when incoming power is applied

a. 1. Open and close start command  
2. Note 'Auto-Start Section in 'DIP SWITCH SETTINGS'  
b. Replace and return to AC Tech for service

# DIFFICULTY

## POSSIBLE CAUSE

## REMEDY

3. Diagnostic Display Indicates  
- and motor does not operate
  - a. Defective Start Command or Wiring
  - b. Defective Control Board
  - a. Repair or replace
  - b. Replace and return to AC Tech for service
4. Diagnostic Display Indicates  
'A' and Motor does not operate
  - a. Drive is in an excessive ambient temperature
  - b. Defective Control Board
  - a. Reduce temperature around Drive, note drive Specifications
  - b. Replace and return to AC Tech for service
5. Diagnostic Display indicates  
'F' and motor does not operate
  - a. Defective motor or motor wiring
  - b. Improper setting of 'Boost' and/or 'Volts/Hertz' potentiometer
  - c. Defective Transistor Module(s)
  - d. Defective Base Driver Board
  - e. Defective Control Board
  - a. Repair or replace
  - b. Adjust per 'ADJUSTMENTS' section
  - c. Test (#3), replace if defective
  - d. Replace and return to AC Tech for service
  - e. Replace and return to AC Tech for service
6. Diagnostic Display indicates  
'H' and motor does not operate
  - a. Input line voltage greater than 110% of drive's nameplate rating
  - b. Defective Control Board
  - a. Check line power and correct problem
  - b. Replace and return to AC Tech for service
7. Diagnostic Display indicates  
'H' as motor is decelerating
  - a. Excessive mechanical load (inertia) connected to motor
  - b. Defective optional Dynamic Braking assembly
  - c. Defective Control Board
  - d. Defective Base Driver Board
  - a. Increase 'Decel' adjustment potentiometer
  - b. Test (#6), replace if defective
  - c. Replace and return to AC Tech for service
  - d. Replace and return to AC Tech for service
8. Diagnostic Display indicates  
'L' and motor does not operate
  - a. Input line voltage less than 90% of drive's nameplate rating
  - b. Defective fuse(s) 5FU and/or 4FU (on some models)
  - c. Defective Control Board
  - d. Defective Base Drive Board
  - a. Correct voltage problem
  - b. Replace
  - c. Replace and return to AC Tech for service
  - d. Replace and return to AC Tech for service

# DIFFICULTY

## POSSIBLE CAUSE

## REMEDY

9. Diagnostic Display indicates 'L' as motor is accelerating or at set speed
    - a. "Soft" input AC power line, drops to less than 90% of drive's nameplate rating when motor is drawing current
    - b. Defective Control Board
    - c. Defective Base Driver Board
  10. Diagnostic Display indicates 'C' and motor does not operate
    - a. Excessive mechanical load (inertia) connected to motor
    - b. Improper setting of 'Boost'; Volts/Hertz' or 'Slip Comp.' potentiometer
    - c. Defective motor or motor wiring
    - d. Defective Transistor Module(s)
    - e. Defective Control Board
    - f. Defective Base Driver Board
  11. Diagnostic Display indicates 'C' as motor is accelerating or at set speed
    - a. Excessive motor load for setting of 'Accel' and/or 'Current Limit' potentiometer
    - a. Excessive mechanical load (inertia) connected to motor
    - c. 'Stability' potentiometer improperly set
    - d. Defective Control Board
    - e. Defective Base Driver Board
  12. Diagnostic Display indicates 5/6 of an '0' and does not rotate
    - a. Defective Speed Control potentiometer or 'External Speed Reference' signal
    - b. Line Voltage 10% high
    - c. Defective Control Transformer
    - d. Defective Control Board
- |   |  |
|---|--|
| <ol style="list-style-type: none"><li>a. Check and correct if defective</li><li>b. Replace and return to AC Tech for service</li><li>c. Replace and return to AC Tech for service</li></ol>   | <ol style="list-style-type: none"><li>a. Reduce drive's load or increase gear ratio</li><li>b. Adjust per set-up adjustments</li><li>c. Replace or repair</li><li>d. Test (#3), replace if defective</li><li>e. Replace and return to AC Tech for service</li><li>f. Replace and return to AC Tech for service</li></ol> |
| <ol style="list-style-type: none"><li>a. Increase 'Accel' and/or 'Current Limit' adjustment</li><li>a. Reduce drive's load or increase gear ratio</li><li>c. Adjust 'Stability' per 'Set-up' instructions</li><li>d. Replace and return to AC Tech for service</li><li>e. Replace and return to AC Tech for service</li></ol> | <ol style="list-style-type: none"><li>a. Test (#5), repair or replace if defective</li><li>b. Reduce to less than +10%</li><li>c. Test (#4), replace if defective</li><li>d. Replace and return to AC Tech for service</li></ol>   |

# DIFFICULTY

## POSSIBLE CAUSE

## REMEDY

13. Diagnostic Display indicates a rotating '0' or 'C', motor operates and

- |  |   |   |
|--|---|---|
| <p>A. Motor will not reach desired minimum speed when the 'Speed Control' potentiometer is fully decreased</p> | <p>a. Improper setting of 'Min' Speed potentiometer<br/>b. Defective 'Speed Control' potentiometer and/or wiring<br/>c. Defective 'External Speed Reference Signal'<br/>d. Defective Control Board</p>  | <p>a. Set 'Min' adjustment per 'Set-up' instructions<br/>b. Test (#5), repair or replace if defective<br/>c. Locate and correct<br/>d. Replace and return to AC Tech for service</p>  |
| <p>B. Motor will not reach desired maximum speed when the 'Speed Control' potentiometer is fully increased</p> | <p>a. Improper setting of 'Max Speed' potentiometer<br/>b. Motor load too great for setting of 'Current Limit' potentiometer<br/>c. Motor overloaded<br/>d. Defective 'Speed Control' potentiometer<br/>e. Defective 'External Speed Reference' potentiometer<br/>f. Improper setting of "Volts/Hertz" potentiometer<br/>g. Defective Control Board</p> | <p>a. Set 'Max' adjustment per 'Set-up' instructions<br/>b. Increase 'Current Limit' adjustment, but do not allow continuous overloads<br/>c. Reduce motor load to within drive nameplate rating<br/>d. Test (#5), repair or replace if defective<br/>e. Locate and correct<br/>f. Adjust per Set-up adjustments<br/>g. Replace and return to AC Tech for service</p> |
| <p>C. Motor runs at one speed and cannot be varied by 'Speed Control' potentiometer</p>                        | <p>a. Defective 'Speed Control' potentiometer and/or wiring<br/>b. Defective 'External Speed Reference Signal'<br/>c. Defective Control Board</p>   | <p>a. Test (#5), repair or replace if defective<br/>b. Locate and correct<br/>c. Replace and return to AC Tech for service</p>  |

# DIFFICULTY

## POSSIBLE CAUSE

## REMEDY

D. Motor speed drops excessively	a. 'Current Limit' potentiometer set too low	a. Increase 'Current Limit' adjustment
	b. Motor being loaded beyond nameplate rating	b. Reduce motor load or change gear ratio
	c. Improper setting of 'Volts/Hertz' 'Boost' and/or 'Slip Compensation' potentiometer(s)	c. Adjust per drive 'Set-up' instructions
14. Drive and Motor operates, then stops and diagnostic display indicates 'P'	a. Motor load too great for setting of 'O.L.' potentiometer	a. Increase 'O.L.' adjustment but do not exceed the rating of the motor and drive
	b. Defective Control Board	b. Replace and return to AC Tech for service
	c. Defective Base Driver Board	c. Replace and return to AC Tech for service

## COMPONENT TEST PROCEDURES

### TEST (#1) - INPUT DIODE BRIDGE

This test procedure can be used for a single or three phase rectifier.

1. Disconnect incoming AC voltage.
2. Remove all (4 or 5) push-on wires from bridge terminals.
3. Set V.O.M. on R x 1 scale.
4. Place meter red (+) lead on bridge (-) terminal and meter black (-) lead separately on each of the three bridge AC terminals. Meter should read about one-half scale. (5-20 Ohms).
5. Place meter black (-) lead on bridge (+) terminal and red (+) lead separately on each of the bridge AC terminals. Meter should read about one half scale. (5-20 Ohms).
6. Set V.O.M. on R x 10K scale (or highest scale).
7. Place meter black (-) lead on bridge (-) terminal and red (+) lead separately on each of the three bridge AC terminals. Meter should read open circuit (infinite resistance).

8. Place meter red (+) lead on bridge (+) terminal and black (-) lead separately on each of the three bridge AC terminals. Meter should read open circuit (infinite resistance).
9. If any test fails, replace diode bridge.

#### TEST (#2) - BUS FILTER CAPACITOR

If the L1000 drive is equipped with two or more filter capacitors, test each separately.

1. Disconnect incoming AC voltage.
2. Place V.O.M. on 250 VDC scale and check that all voltage has discharged from capacitor(s).
3. Remove wires from capacitor(s) terminals.
4. If capacitor shows signs of leaking oil, it MUST BE REPLACED.
5. Set V.O.M. on R x 1K scale.
6. Place meter red (+) lead on capacitor (+) terminal and meter black (-) lead on capacitor (-) terminal. Meter needle should deflect to near zero ohms followed by a steady movement of the needle toward open circuit (infinite resistance) as the capacitor charges. Charge time should be 1 to 1 1/2 minutes.
7. If test fails, replace capacitor.

#### TEST (#3) - OUTPUT TRANSISTOR MODULE(S)

1. Disconnect incoming AC voltage.
2. Remove all power leads from transistor module(s) and control wiring plug(s) from Base Driver Board.
3. Test the transistor module(s) using the same series of tests as in Test #1-3 through #1-8.
4. If any test fails, replace transistor module(s) and check the condition of Base Driver fuses 301FU through 801FU. If any fuse is defective, replace.
5. If drive still fails to operate, re-test transistor module(s) and replace Base Driver Board. Return defective Base Driver Board to MC Techni-Log Corporation for repair.



#### TEST (#4) - CONTROL TRANSFORMER

1. Disconnect incoming AC voltage.
2. Remove all transformer plugs except PL1 and pull them free of all other components.
3. Apply incoming AC Voltage.
4. Set V.O.M. on 50VAC scale.
5. On plugs PL(RD), PL(OR), PL(BU), and PL(VI) the measured voltage should be 10VAC (+10%, -10%) from pin 1 to pin 2 and 20VAC (+10%-10%) from pin 1 to pin 3.
6. On plug PL(GR) the measured voltage should be 16VAC (+10%-10%) from pin 1 to pin 2 and 32VAC (+10%, -10%) from pin 1 to pin 3.
7. Disconnect incoming AC voltage.
8. If any test fails, replace transformer.

#### TEST (#5) - SPEED CONTROL POTENTIOMETER

1. Disconnect incoming AC voltage
2. Remove wires from drive terminals 4, 5 and 6.
3. Set V.O.M. on R x 1K scale.
4. Measure resistance from wire which was on terminal 4 to wire which was on terminal 6. Reading should be 10 (10,000 ohms).
5. Measure resistance from wire which was on terminal 4 to wire which was on terminal 5. Turn potentiometer up; resistance should increase proportionately to potentiometer setting. At full rotation, resistance should be 10,000 ohms.
6. Replace potentiometer or wiring if defective.


TEST (#6) - DYNAMIC BRAKING ASSEMBLY (OPTION)

1. Disconnect incoming AC voltage.
2. Check fuse on Dynamic Braking Board, REPLACE WITH SAME VALUE if defective.
3. Set V.O.M. on 600 VDC scale.
4. Using alligator clips, connect V.O.M. across the braking resistor(s).
5. Apply incoming AC voltage and operate drive at low speed. Meter should read zero.
6. Turn Speed Control potentiometer up. Meter should read zero.
7. Rapidly turn Speed Control down; meter should read voltage as the motor is decelerating (20 to 600 VDC). The amplitude of voltage across the resistor is a function of the inertial load and the deceleration rate. When motor arrives at new speed, the meter should return to zero.
8. If any test fails, replace Dynamic Braking assembly and return to AC Technology Corporation for repair.



# ROD OPERATED DISCONNECT SWITCHES - 30 Through 200 Ampere Size

A complete disconnect switch consists of the following components:



## Description

The Bulletin 1494R rod operated disconnect switch is applicable to both NEMA Type 1 and 12 enclosures. It is designed to meet industrial requirements for a dependable manual type disconnect device. The complete Disconnect Switch consists of the disconnect switch, operating handle, connecting rod and hitch pin.

## Warning




To avoid hazards of electrical shock, remove all power to the panel before proceeding. Auxiliary contacts commonly control separate sources of power. Be sure they and all sources of power are disconnected. The outlined procedures should only be performed by qualified personnel familiar with the operation of the equipment in which the switch is mounted.



# 100 Ampere and 200 Ampere Size Installation

**100 Ampere Size -**  
Catalog No. 1494R-N100  
**200 Ampere Size -**  
Catalog No. 1494R-N200



NEMA Designation	Dimensions in Inches										Approximate Shipping Weight		
	A Wide	B High	C Deep	D	E	F	G	H	J			K	L
									Standard Shaft	Long Shaft			
100 Amperes	6-7/16	7-3/16	5-7/16	15/16	5	5-1/4	23/32	1-1/2	6-1/4 Min. 12-7/8 Max.	6-1/4 Min. 25-7/8 Max.	Ⓢ	Ⓣ	9 Lbs.
200 Amperes	7-1/4	9-1/2	6-1/2	1-7/16	5-3/4	6-1/2	3/4	1-23/32	7-7/16 Min. 12-7/8 Max.	7-7/16 Min. 25-7/8 Max.	Ⓢ	Ⓣ	15 Lbs.

- ① The Adjusted Coupling Position is determined by measuring the cabinet depth and subtracting  $15/16" \pm 1/16"$ .  
② The Shaft Length is determined by measuring the cabinet depth (Dimension "J") and subtracting  $1-7/8"$ .



### Mounting the Disconnect Switch

1. Measure the cabinet depth (Dimension "J" on Page 4) to insure that your cabinet is within the minimum and maximum size range.
2. Select desired location on disconnect switch mounting surface for mounting the disconnect switch.
3. From the line drawing and dimension table on Page 4, locate the mounting holes of the switch.
4. Mount the disconnect switch on the enclosure mounting surface. Use  $\frac{1}{4}$ " or  $\frac{4}{16}$ " screws. Torque to 40-50 lb-in.

### Mounting the Activating Rod

1. Determine shaft length (Dimension "L" on Page 4) from table and cut uninsulated end of shaft to size.
2. Insert the insulated end of the shaft through the hole in the support bracket and into the two square holes in the switch lever. Torque the set screw (or screws) to 35-40 lb-in. to secure shaft to switch lever. Insert hitch pin furnished into hole in shaft (see side view above).
3. Determine the adjusted coupling position (Dimension "K") and attach the coupling to the shaft with set screws. The word "On" and the arrow molded on the face of the coupling must be at the bottom with the switch in the "Open" position. Torque the set screws to 25-30 lb-in.

### Mounting the Handle Assembly

1. Using the template and dimension table on Page 4 as a guide, determine the point on the cover, within  $\frac{1}{8}$ ", at which the center of the rod and the center of the handle assembly should meet.
2. With the template located, center-punch the location of the five mounting holes. Drill the  $\frac{15}{64}$ " diameter holes. Drill pilot holes for Greenlee cutters for the  $\frac{1}{2}$ " and  $1\frac{1}{2}$ " diameter holes. Cut the  $\frac{1}{2}$ " diameter hole with Greenlee cutter first, then the  $1\frac{1}{2}$ " diameter hole, overlapping the  $\frac{1}{2}$ " diameter hole.
3. Close the cover and check the coupling spear-point for alignment with the center of the large diameter hole. Adjust the support bracket, if necessary to center the spear-point within  $\frac{1}{16}$ ".
4. On the outside surface of the cover, mount the nameplate and handle so that the handle passes through the nameplate and enclosure cover. Peel off the adhesive protective shield from the back of the nameplate before installing. On the inside surface of the cover the rubber washer, the spacer (used only on 14 and 16 gauge covers) and the interlock are assembled, in that order, around the protruding shoulder of the handle assembly. Torque the three mounting screws to 25-30 lb-in.

5.



#### CAUTION:

Make sure the cover interlock latch swings freely.


6. With the handle in the "Open" position, the cover should open freely. With the handle in either the "On", "Off", or "Lock" position, the cover interlock MUST prevent opening the cover unless the defeater is used.





## 30 Ampere and 60 Ampere Size Installation

30 Ampere Size -  
Catalog No. 1494R-N30  
60 Ampere Size -  
Catalog No. 1494R-N60



NEMA Designation	Dimensions In Inches								Approximate Shipping Weight
	A Wide	B High	D	E	J		K	L	
					Standard Shaft	Long Shaft			
30 Amperes	3-31/32	4-13/16	1-1/8	3-1/8	4-3/8 Min. 10-7/8 Max.	4-3/8 Min. 19-3/8 Max.	①	②	4 Lbs.
60 Amperes	4-21/32	5-1/4	1-1/16	3-13/16	4-1/2 Min. 10-7/8 Max.	4-1/2 Min. 19-3/8 Max.	①	②	4-1/2 Lbs.

- ① The Adjusted Coupling Position is determined by measuring the cabinet depth and subtracting  $9/16" \pm 1/16"$ .  
② The Shaft Length is determined by measuring the cabinet depth (Dimension "J") and subtracting  $1-3/8"$ .



## 30 Ampere and 60 Ampere Size Installation

### Mounting the Disconnect Switch

1. Measure the cabinet depth (Dimension "J" on Page 2), to insure that your cabinet is within the minimum and maximum size range.
2. Select desired location on disconnect switch mounting surface for mounting the disconnect switch.
3. From the line drawing and dimension table on Page 2, locate the mounting holes of the switch.
4. Mount the disconnect switch on the enclosure mounting surface. Use 3/16" or #10 screw. Torque to 25-30 lb-in.

### Mounting the Activating Rod

1. Determine shaft length (Dimension "L" on Page 2) from table and cut uninsulated end of shaft to size.
2. Insert the insulated end of shaft through the hole in the support bracket and into the two square holes in the switch lever. Torque the set screw to 35-40 lb-in to secure shaft to switch lever. Insert hitch pin furnished into hole in shaft (see side view on Page 2).
3. Determine the adjusted coupling position (Dimension "K" on Page 2) and attach the coupling to the shaft with set screws. The "D" molded on the face of the coupling must be at the bottom and the "C" at the top, with the switch in "Off" position. Torque the set screws to 25-30 lb-in.

### Mounting the Handle Assembly

1. Using the template and dimension table as a guide, determine the point on the cover, within 1/8", at which the center of the rod and the center of the handle assembly should meet.
2. With the template located, center-punch the location of the five mounting holes. Drill the 13/64" diameter holes. Drill pilot holes for Greenlee cutters for the 1/2" and 1 1/4" diameter holes. Cut the 1/2" diameter hole with Greenlee cutter first, then the 1 1/4" diameter hole.
3. Close the cover and check the coupling spear-point for alignment with the center of the large diameter hole. Adjust the support bracket, if necessary, to center the spear-point within 1/16".
4. On the outside surface of the cover, mount the nameplate and handle so that the handle passes through the nameplate and enclosure cover. Peel off the adhesive protective shield from the back of the nameplate before installing. On the inside surface of the cover the rubber washer, the spacer (used only on 14 and 16 gauge covers) and the interlock are assembled, in that order, around the protruding shoulder of the handle assembly. Torque the three mounting screws to 16-20 lb-in.

5.



#### CAUTION:

Make sure the cover interlock latch swings freely.


6. With the handle in the "Open" position, the cover should open freely. With the handle in either the "On", "Off" or "Lock" position, the cover interlock **MUST** prevent opening the cover unless the defeater is used.



## INSTRUCTIONS

### Bulletin 800T, Shallow, Mini And Sealed Switch Contact Blocks

The contact blocks of the sealed switch, shallow and mini construction cannot be mixed with the 1-5/8 inch deep (Series A) construction contact block. A sealed switch contact block may be mounted on either or both sides of an operator, one deep only (no other contact blocks on that side). A shallow contact block may be mounted on either or both sides of an operator, two deep maximum or in conjunction with a mini contact block on the second level. A sealed switch contact block may be mounted on one side with shallow and mini contact blocks on the other side, observing above restrictions. Each additional contact block will contain enough mounting hardware to mount one block. When mounting two or more contact blocks discard all excess hardware. Contact block retaining clips cannot be used with an XA1, XA2, XA4, XA7 and a sealed contact switch block.



#### Note:

- 1) Contact blocks used on operators with projections at four corners of adapter plate must be mounted without spacer.
- 2) Contact blocks used on operators without projections must be mounted with one spacer.

Caution: Extender must not be used when block is mounted directly to operator; extender can be easily removed. Extender must be used when block is mounted in tandem as illustrated.

(Continued on other side)



40060-226-01(D)  
Printed in U.S.A.

**ALLEN-BRADLEY**  
Milwaukee, Wisconsin 53204

**NOTE:** The sealed switch contact block contacts are hermetically sealed in a glass envelope. Dust, dirt, oxidation, oil laden air, or other air-borne contaminants do not affect the continuity of the contacts. The contacts of the shallow and mini contact blocks and the operating mechanism of all the blocks are not sealed however, and must be protected by an enclosure and an external operator suitable for the environment. Contact blocks must be protected from dirt or contamination that might enter enclosure during installation, maintenance or any time the enclosure is open. Never blow dirt off of electrical components, as this may force dirt into internal mechanisms - use vacuum.

Sealed switch contact blocks can be used with any operator except the following (these operators are not mechanically compatible with the sealed switch contact blocks):

800 - T - 2,3,4 Way Switch  
800 - K - Selector Push Button

#### IMPORTANT - Do Not Use

Catalog Number 800T-XD3 Contact Block with the following Selector Switch Operators:

Cat. No. 800T-J-KE7  
Cat. No. 800T-J-KR1  
Cat. No. 800T-J-KR7  
Cat. No. 800T-J-KT1  
Cat. No. 800T-J-KT7  
Cat. No. 800T-J-KU7  
Cat. No. 800T-N-KK4  
Cat. No. 800T-N-KM4  
Cat. No. 800H-JR-KE7  
Cat. No. 800H-JR-KR1  
Cat. No. 800H-JR-KR7  
Cat. No. 800H-JR-KT1  
Cat. No. 800H-JR-KT7  
Cat. No. 800H-JR-KU7  
Cat. No. 800H-NR-KK4

## INSTALLATION and MOUNTING INSTRUCTIONS for BULLETIN 800T PUSH BUTTON UNITS

This device is for use on a flat, smooth surface of a NEMA Type 4 or 13 enclosure.

**WARNING:** To prevent injury, this device must be disconnected from all power sources prior to initiating work.

**CAUTION:** When installing in a metal enclosure, maintain 1/2" (12.7) minimum clearance between exposed metal parts of contact block and enclosure.

Installation: Place the unit (less mounting ring, thrust washer, legend plate and with proper number of gaskets per Figure 1) in the mounting hole. Install legend plate (if legend plate is not use install trim washer). Install thrust washer and tighten mounting ring. See Figure 2 for illustrated assembly. Bulletin 800T push button operators will accept one to four contact blocks. The following blocks may be used:

Catalog No. 800T-XD1, XD2, XD3, XD4, XA (Series C or higher) and Catalog No. 800T-XD1R, XD2R, XAR, XA4R (Series A or higher). Catalog No. 800T-XD5, XD6, (Series B or higher) may be used on second level only. A device bonding kit, Catalog No. 800T-N300 is available to meet the bonding requirements of CSA Standard C22.2 No.0.4.




Figure 1




Figure 2

40060-331-01 (A)  
Printed in U.S.A.

**ALLEN-BRADLEY**  
A ROCKWELL INTERNATIONAL COMPANY



To determine the contact targets of Allen-Bradley three position selector switches, proceed as follows:

1. Determine on which **SIDE** of the selector switch the contact block is mounted: **WHITE** or **BLACK**. On the back of the selector switch is a molded plastic cover. On this cover is a nameplate indicating Catalog No. of the operator and location of side 1 (white actuator). Side 2 (black actuator) is the opposite side.

2. Identify the **CONTACT BLOCK** used by looking at the contact block cover plate and finding a Catalog No., such as B00T-XA.

3. Identify the CIRCUIT for which the contact target is desired by looking again at the contact block cover plate for a wiring symbol such as "A", "B", "A1", etc.

4. Identify the CAM used by looking again at the nameplate on

the molded plastic cover on the back of the selector switch operator. The Catalog No., with exceptions listed below,

The A1 is the cam identification (there may be digits following).

**Exceptions:** Selector switches where a special cam was not specified. On standard maintained and spring return three position selector switches, a H7 cam is used.

Example Catalog Nos. of standard selector switches:  
800T-12A 800T-117C 800T-J2B 800T-J42B.


Refer to the table below and find the actuator color, contact block, and wiring symbol. Read across the top to find the cam and knob position. Where these two columns intersect will be the contact target.

[illegible]

**1** The slanted lines represent the knob positions.

**2** Noted CAMS cannot be used with wing lever operators.

Abbreviations and Symbols	
MO = Normally Open	X = Closed
NC = Normally Closed	O = Open
LB = Late Break	N/A = Not Available
EM = Early Make	



40060-259-03 (B)  
Printed in U.S.A.

**CAUTION:** When installing in a metal enclosure, maintain 1/2" (12.7) minimum clearance between exposed contact blocks and enclosure.




**INSTALLATION** -- Place the unit (less lens, mounting ring, thrust washer and legend plate or trim washer) with the lens side facing the mounting hole.




**REPLACING LAMP** — Bayonet Base: Remove lens. Push proper number of gaskets per Figure 1 into mounting. Install legend plate or trim washer and thrust lamp inward and turn to the left. To install new lamp, insert in socket, push down and turn to the right; see Figure 2.

**CAUTION:** Lens must be tight against bushing to protect lens.

vide an outright test; see Figure 2.

**NOTE:** Lens must be assembled to Pilot Light for use in Class 1, Division 1 hazardous locations.

Gaskets required for various panel thicknesses.		
Units are shipped with three 1/16" (1.6) gaskets.		
16 Gauge 1/16" (1.6)		3
12 Gauge 7/64" (2.8)		2
10 Gauge 9/64" (3.6)		1
Panels thicker than 3/16" (4.8) must be counterbored.		



Note: Dimensions shown in parentheses are in millimeters.


Illuminated push button and pilot light units will accept dual input modules: Catalog Nos. 800T-N290 (120V) and 800T-N201 (24V). These kits are mounted in place of the transformer or the full voltage module.

A (5V) flashing lamp, Catalog No. 800T-N212, is available for any illuminated device which utilizes the No. 755 or 800T-N231 (2.4V). These kits are indicated in product literature.

A device bonding kit, Catalog No. 800T-N300 is available to meet the bonding requirements of CSA Standard C22.2 No. 147.

**ALLEN-BRADLEY**  
Milwaukee, Wisconsin 53204

 40060-136-01(F)



40060-259-03 (B)  
Printed in U.S.A.

**ALLEN-BRADLEY**  
Milwaukee, Wisconsin 53204





# MOUNTING INSTRUCTIONS

## Bulletin 800T — 2 Position Selector Switches

This device is for use on a flat, smooth surface of a NEMA Type 4 or 13 enclosure.

**WARNING:** To prevent injury, this device must be disconnected from all power sources prior to initiating work.

**CAUTION:** When installing in a metal enclosure, maintain 1/2" (12.7) min. clearance between exposed metal parts of contact block and enclosure.

### INSTALLATION


The knob assembly or coin slot cap may be installed having any one of four orientations with respect to the switch body. To obtain proper orientation, proceed as follows:

- Unscrew mounting ring and remove knob assembly or coin slot cap from switch. Place correct number of gaskets on switch bushing as indicated in Figure 1.
- Place switch in panel and place the legend plate and thrust washer on the bushing. Note: Trim washer must be used if legend plate is not used. Use legend plate with notch instead of tang (800T-X500 and -X600 Series).
- With the help of the diagram shown in Figure 2, determine the switch setting. (Note the position of the stop projection on the shaft with respect to the opening in the bushing.)
- Place the knob assembly or coin slot cap over the end of the shaft and arrange the indicator to point to the position on the legend plate which corresponds to the switch setting.
- Keying** — Knob assemblies having 3 legs may be keyed to interfere with assembly of the knob except in the selected position. If keying is desired, determine which of the four holes in the shaft will not be occupied by one of the 3 legs of the knob assembly or coin slot cap when the knob or cap is properly oriented. Fill the unused hole with a rigid material. (A No. 8 x 1/4" (6.4) long set screw or other similarly sized "plug" may be used, apply light pressure only).  
Knob assemblies having only 2 legs may be partially keyed. (When keyed, a 2-leg knob will fit in either of

2 positions, 180° apart.) If such keying is desired, fill either of the two unoccupied holes in the shaft according to the instructions above.

- Thread mounting ring onto bushing with knob assembly or coin slot cap in place, and tighten securely.
- Ground operator as shown in Figure 3, when required.
- Note: For illustration of mounted assembly, see Figure 4.

### Mounting Instructions



Two position selector switch with wing lever requires 3" (76.2) minimum vertical spacing and 3-1/4" (82.6) minimum horizontal spacing.

Gaskets required for various panel thicknesses. Units are shipped with three 1/16" (1.6) gaskets.

16 Gage 1/16" (1.6)	3	
12 Gage 7/64" (2.8) 10 Gage 9/64" (3.6)	2	
3/16" (4.8)	1	
Panels thicker than 3/16" (4.8) must be counterbored.		

Figure 1

Note: Dimensions shown in parentheses are in millimeters.




Figure 2




Figure 3




Figure 4

### INDICATOR INSERT REMOVAL/INSTALLATION — Except wing lever and coin operated types.

(Note: Have a replacement insert on hand — insert may break during removal.) To remove indicator insert, place a knife blade or sharp instrument under edge of insert at mounting ring and pry up. Grasp insert and remove from operator (Figure 5). To install insert, place into slot in operator and apply a small amount of pressure to assure seating.

### Installation and Removal of Indicator Insert




Figure 5

**CONTACT BLOCK MOUNTING:** An operator may be used with 1 to 4 of the contact blocks listed in Table 1. The contact blocks may be mounted in tandem, and in various combinations, two tiers deep maximum.

Table 1		
Standard Block Cat. No. 800T-	Logic Reed Block Cat. No. 800T-	Number of Contacts <sup>2</sup>
XA	XAR	1 N.O. - 1 N.C.
XA1		1 N.C. L.B. - 1 N.O.
XA2 <sup>3</sup>	XA2R	2 N.O.
XA4	XA4R	2 N.C.
XA7		1 N.C. L.B. - 1 N.C.
XD1 & XD5	XD1R	1 N.O.
XD2 & XD6	XD2R	1 N.C.
XD3		1 N.O. E.M.
XD4		1 N.C. L.B.

<sup>2</sup> N.O. — Normally Open N.C. — Normally Closed  
E.M. — Early Make L.B. — Late Break

<sup>3</sup> XA2 blocks must be used only on the 2 ND level if stacked.

Sealed Contact Switch Blocks. 800T-XAP, XD1P, and XD2P may be mounted singly, or side-by-side, directly to an operator. (No stacking.)

A device bonding kit, Catalog No. 800T-N300 is available to meet the grounding requirements of CSA Standard C22.2 No. 0.4.




**CAUTION:** When installing in a metal enclosure, maintain 1/2" (12.7) minimum clearance between potentiometer housing terminals and enclosure.

**POWER RATING:** Maximum Power (P) = 2 watts, provided maximum working voltage is not exceeded! Maximum Working Voltage (EMAX) shall not exceed 300 volts (RMS or DC), or as determined by  $EMAX = \sqrt{P \cdot R}$ , where R = Resistance, whichever is less. See Table 1 for power derating with respect to rotation for rheostat application.

**INSTALLATION:** See Figure 2 for illustrated assembly. Place the unit (less mounting ring, thrust washer and legend plate or trim washer) with number of gaskets per Figure 1, in mounting hole. Position legend plate by rotating knob all the way counterclockwise and aligning "Min." on legend plate with white indexer on knob. (Note: Trim washer must be used if legend plate is not used.) Place thrust washer over knob inserting tang through notch on legend plate or trim washer into panel. Install mounting ring and tighten securely against thrust washer.

A device bonding kit, Catalog No. 800T-N300 is available to meet the bonding requirements of CSA Standard C22.2 No. 0.4.

#### MOUNTING INSTRUCTIONS



Gaskets Required for Various Panel Thicknesses. Units are Shipped with Three 1/16" (1.6) Gaskets.	
16 Gage 1/16" (1.6)	3
12 Gage 7/64" (2.8)	2
10 Gage 9/64" (3.6)	1
3/16" (4.8)	1
Panels thicker than 3/16" (4.8) must be counterbored.	

Note: Dimensions shown in parentheses are in millimeters.

Figure 1



40060-150-01(G)  
Printed in U.S.A.

TABLE 1 Power Derating with Respect to Rotation for Rheostat Application			
Percent Rotation	Multiply Wattage Rating By	Percent Rotation	Multiply Wattage Rating By
100	1.00	40	0.81
90	0.99	30	0.68
80	0.98	20	0.49
70	0.96	10	0.23
60	0.93	0	0.11
50	0.89		




Figure 2  
(Continued on Opposite Side)

**ALLEN-BRADLEY**  
Milwaukee, Wisconsin 53204

**REPLACING POTENTIOMETER:** See Figure 3 for illustrated assembly.

Note 1: Refer to nameplate on housing for original potentiometer resistance.

Note 2: Unit need not be removed from panel to replace potentiometer.

#### POTENTIOMETER REMOVAL:

1. Remove the two screws on the rear of the housing and pull the housing from the panel mounting bushing.
2. Disconnect the three wire leads from the potentiometer terminals.
3. Pull the potentiometer and knob through the panel mounting bushing.
4. Loosen the set screws in the knob with a 1/16" (1.6) hex socket wrench and remove knob from potentiometer shaft.
5. Remove diaphragm to expose nut on the potentiometer bushing.
6. Remove nut, lock washer and mounting plate.

#### POTENTIOMETER INSTALLATION:

1. Before installing potentiometer, bend the three terminals 80° - 90° and remove the nut and lock washer from bushing. (See Figure 4.)
2. Install mounting plate, printed side up, over potentiometer shaft, aligning locating tab on potentiometer with slot in mounting plate.
3. Tighten nut and lock washer on potentiometer shaft and bend locating tab flush with mounting plate.
4. Place diaphragm over potentiometer shaft.
5. Position shaft at maximum clockwise (C.W.) rotation and align white indexer on knob with white mark on mounting plate (diaphragm flange will need to be lifted up to expose mounting plate). Secure set screws using a 1/16" (1.6) hex socket wrench. (See Figure 5.)
6. Insert wire leads onto the potentiometer terminals making sure the leads identified as 1, 2 & 3 are attached to the corresponding identified potentiometer terminals. (See Figure 3 for terminal and lead identification.) If the potentiometer housing does not have wires with terminal lugs, then solder the wire end to the appropriate potentiometer terminal.
7. Line up holes in diaphragm, potentiometer mounting plate and housing and push the unit through the panel mounting bushing. Rotate knob all the way counterclockwise (C.C.W.). Orientate unit so that the white indexer on knob is pointing to "MIN" on legend plate.
8. Secure by threading in the two screws from the rear of the potentiometer housing.

Note: On special potentiometer units such as switch type and/or multiples, discard the housing and secure the potentiometer mounting plate to the panel mounting bushing with the special short screws included.





Figure 3




Figure 5




Figure 6



## INSTALLATION AND MOUNTING INSTRUCTIONS

### Bulletin 800T Illuminated Pilot Devices

This device is for use on a flat, smooth surface of a NEMA Type 4 or 13 enclosure.

**WARNING:** To prevent injury, this device must be disconnected from all power sources prior to initiating work.

**CAUTION:** When installing in a metal enclosure, maintain 1/2" (12.7) min. clearance between exposed metal parts of contact block and enclosure.


**Installation:** Place the unit (less lens, mounting ring, thrust washer and legend plate or trim washer) with proper number of gaskets per Figure 1 in mounting hole. Position legend plate or trim washer and thrust washer. Install mounting ring and tighten securely against thrust washer. Install lens: see Figure 2. Use legend plate with notch instead of tang (800T-X500 and -X600 Series).

**CAUTION:** Lens must be tight against bushing to provide an oiltight seal; see Figure 2.

Illuminated pushbutton operators will accept one or two contact blocks mounted in tandem. Following blocks may be used: Catalog No. 800T-XD1, -XD2, -XD3, -XD4, -XA (Series C or higher) and Catalog No. 800T-XD1A, -XD2R, -XAR, -XA2R, -XA4R (Series A or higher). Catalog No. 800T-XD5, -XD6 (Series B or higher) may be used on second level, but may not be mounted adjacent to the transformer (first level).

**REPLACING LAMP:** Bayonet Base: Remove lens. Push lamp inward and turn to the left. To install new lamp, insert in socket, push down and turn to the right; see Figure 3.

**NOTE:** Lens must be assembled to Pilot Light for use in Class I, Division 2 Hazardous Locations.



**Note:** Dimensions shown in parentheses are in millimeters. Illuminated push button and pilot light units will accept dual input modules: Catalog Nos. 800T-N290 (120V) and 800T-N291 (24V). These kits are mounted in place of the transformer or the full voltage module. A (6V) flashing lamp, Catalog No. 800T-N212 is available for any illuminated device which utilizes the No. 755 or No. 1866 lamp.

A device bonding kit, Catalog No. 800T-N300 is available to meet the bonding requirements of CSA Standard C22.2 No. 0.4.

40060-136-01 (G)  
Printed in U.S.A.

**AB ALLEN-BRADLEY**  
A Rockwell International Company



# CONTACT TARGET TABLE FOR 2 POSITION SELECTOR SWITCHES

To determine the contact targets of Allen-Bradley two position selector switches, proceed as follows:

1. Determine on which **SIDE** of the selector switch the contact block is mounted: **WHITE** or **BLACK**. On the back of the selector switch is a molded plastic cover. On this cover is a nameplate indicating Catalog No. of the operator and location of side 1 (white actuator). Side 2 (black actuator) is the opposite side.
2. Identify the **CONTACT BLOCK** used by looking at the contact block cover plate and finding a Catalog No., such as 800T-XA.
3. Identify the **CIRCUIT** for which the contact target is desired by looking again at the contact block cover plate for a wiring symbol such as "A", "B", "A1", etc.
4. Identify the **CAM** used by looking again at the nameplate on

the molded plastic cover on the back of the selector switch operator. The Catalog No., with exceptions listed below, contains the cam identification following the flag letter "K".

Example Catalog Nos.: 800T-H2KE8 or 800H-HR2KE8.

The E8 is the cam identification (there may be digits following).

**Exceptions:** Selector switches where a special cam was not specified. On standard two position maintained, a B6 cam is used. On standard two position spring return, an L8 cam is used.

Example Catalog Nos. of standard selector switches:  
800T-H2A, 800T-H17C, 800T-H2B, 800T-H32H.

5. Refer to the table below and find the actuator color, contact block, and wiring symbol. Read across the top to find the cam and knob position. Where these two columns intersect will be the contact target.

ACTUATOR COLOR	Contact Block 800T-	Single Circuit Or Optional	Normal Circuit Operation	Wiring Symbol	CAM CODE AND KNOB POSITIONS <sup>1</sup>				
					Maintained			Spring Return From Left	Spring Return From Right
					B6	E8	L8	L8	L8
					↖ ↗	↖ ↗	↖ ↗	↖ ↗	↖ ↗
WHITE	XA, XAR, XAP	XD2 or XD6 XD2R, XD2P	NC	B	X O	O X	O X	O X	X O
		XD1 or XD5 XD1R, XD1P	NO	A	O X	X O	X O	X O	O X
	XA1	XD4	NCLB	BZ1	X O	O X	O X	O X	X O
		XD1 or XD5 XD1R, XD1P	NO	A2	O X	X O	X O	X O	O X
	XA2, XA2R	XD1 or XD5 XD1R, XD1P	NO	A1	O X	X O	X O	X O	O X
		XD1 or XD5 XD1R, XD1P	NO	A2	O X	X O	X O	X O	O X
	XA4, XA4R	XD2 or XD6 XD2R, XD2P	NC	B1	X O	O X	O X	O X	X O
		XD2 or XD6 XD2R, XD2P	NC	B2	X O	O X	O X	O X	X O
	XA7	XD4	NCLB	BZ1	X O	O X	O X	O X	X O
		XD2 or XD6 XD2R, XD2P	NC	B2	X O	O X	O X	O X	X O
	XD3	—	NOEM	AZ	O X	X O	X O	X O	O X
	XD4	—	NCLB	BZ	X O	O X	O X	O X	X O
BLACK	XA, XAR, XAP	XD2 or XD6 XD2R, XD2P	NC	B	X O	X O	O X	O X	X O
		XD1 or XD5 XD1R, XD1P	NO	A	O X	O X	X O	X O	O X
	XA1	XD4	NCLB	BZ1	X O	X O	O X	O X	X O
		XD1 or XD5 XD1R, XD1P	NO	A2	O X	O X	X O	X O	O X
	XA2, XA2R	XD1 or XD5 XD1R, XD1P	NO	A1	O X	O X	X O	X O	O X
		XD1 or XD5 XD1R, XD1P	NO	A2	O X	O X	X O	X O	O X
	XA4, XA4R	XD2 or XD6 XD2R, XD2P	NC	B1	X O	X O	O X	O X	X O
		XD2 or XD6 XD2R, XD2P	NC	B2	X O	X O	O X	O X	X O
	XA7	XD4	NCLB	BZ1	X O	X O	O X	O X	X O
		XD2 or XD6 XD2R, XD2P	NC	B2	X O	X O	O X	O X	X O
	XD3	—	NOEM	AZ	O X	O X	X O	X O	O X
	XD4	—	NCLB	BZ	X O	X O	O X	O X	X O

<sup>1</sup> The slanted lines represent the knob positions.

**Abbreviation and Symbols**  
 NO = Normally Open X = Closed  
 NC = Normally Closed O = Open  
 LB = Late Break  
 EM = Early Make

<sup>2</sup> XA2 contact blocks must be used only on the 2 NO level if stacked.

40060-259-02 (E)  
Printed in U.S.A.

**AB ALLEN-BRADLEY**  
A ROCKWELL INTERNATIONAL COMPANY







## ROD OPERATED DISCONNECT SWITCH


30 Ampere Size—Catalog Number 1494R-N30  
60 Ampere Size—Catalog Number 1494R-N60

See Reverse Side for  
100 and 200 Ampere Size



Cover Drilling Dimensions

Cabinet cover thickness  
#16 Ga. Min. to #10 Ga. Max.



NEMA Designation	Dimensions in Inches							Approximate Shipping Weight
	A Wide	B High	D	E	J		K L	
30 Amperes	3 11/32	4 13/16	1 1/8	3 3/8	Standard Shaft	4 3/8 Min. 10 3/8 Max.	1 2	4 Lbs.
					Long Shaft	4 3/8 Min. 19 3/8 Max.		
60 Amperes	4 21/32	5 1/4	1 1/16	3 11/16	Standard Shaft	4 1/2 Min. 10 3/8 Max.	1 2	4 1/2 Lbs.
					Long Shaft	4 1/2 Min. 19 3/8 Max.		

1 The Adjusted Coupling Position is determined by measuring the cabinet depth and subtracting  $\frac{1}{16}$  ±  $\frac{1}{16}$ ."

2 The Shaft Length is determined by measuring the cabinet depth and subtracting  $1\frac{3}{4}$ ."

### MOUNTING THE DISCONNECT SWITCH

1. Measure the cabinet depth (Dimension "J"), to insure that your cabinet is within the maximum and minimum size range.
2. Select desired location on enclosure surface for mounting the disconnect switch.
3. From the line drawing and dimension table above, locate the mounting holes of the switch.
4. Mount the disconnect switch on the enclosure mounting surface. Use  $\frac{3}{16}$ " or #10 screw.

### MOUNTING THE ACTIVATING ROD

1. Determine shaft length (Dimension "L") from table and cut uninsulated end of shaft to size.
2. Insert the insulated end of shaft through the hole in the support bracket and into the two square holes in the switch lever. Tighten set screw to secure shaft to switch lever. Insert hitch pin furnished into hole in shaft (see side view above).
3. Determine the adjusted coupling position (Dimension "K") and attach the coupling to the shaft with set screws. The "D" molded on the face of the coupling must be at the bottom and the "C" at the top, with the switch in "Off" position.



### MOUNTING THE HANDLE ASSEMBLY

1. Using the template and dimension table as a guide, determine the point on the cover, within  $\frac{1}{8}$ ", at which

the center of the rod and the center of the handle assembly should meet.

2. With the template located, center-punch the location of the five mounting holes. Drill the  $\frac{13}{64}$ " diameter holes. Drill pilot holes for Greenlee cutters for the  $\frac{1}{2}$ " and  $1\frac{1}{4}$ " diameter holes. Cut the  $\frac{1}{2}$ " diameter hole with Greenlee cutter first, then the  $1\frac{1}{4}$ " diameter hole.
3. Close the cover and check the coupling spear-point for alignment with the center of the large diameter hole. Adjust the support bracket, if necessary, to center the spear-point within  $\frac{1}{16}$ ".
4. On the outside surface of the cover, mount the nameplate and handle so that the handle passes through the nameplate and enclosure cover. Use trichlorethylene or lacquer thinner to activate the adhesive on the back of the nameplate. On the inside surface of the cover the rubber washer, the spacer (used only on 14 and 16 gauge covers) and the interlock are assembled, in that order, around the protruding shoulder of the handle assembly. Tighten the three mounting screws securely.
5. CAUTION: MAKE SURE THE COVER INTERLOCK LATCH SWINGS FREELY.
6. With the handle in the "Open" position, the cover should open freely. With the handle in either the "On", "Off" or "Lock" position, the cover interlock MUST prevent opening the cover unless the defeater is used.






Cover Drilling Dimensions

Cabinet cover thickness  
#16 Ga. Min. to #10 Ga. Max.

NEMA Designation	Dimensions in Inches											Approximate Shipping Weight		
	A Wide	B High	C Deep	D	E	F	G	H	J		K		L	
100 Amperes	6 <sup>7</sup> / <sub>16</sub>	7 <sup>3</sup> / <sub>16</sub>	5 <sup>1</sup> / <sub>16</sub>	1 <sup>5</sup> / <sub>16</sub>	5	5 <sup>1</sup> / <sub>4</sub>	2 <sup>3</sup> / <sub>32</sub>	1 <sup>1</sup> / <sub>2</sub>	Standard Shaft	6 <sup>1</sup> / <sub>4</sub> Min.	12 <sup>1</sup> / <sub>2</sub> Max.	1	2	9 Lbs.
									Long Shaft	6 <sup>1</sup> / <sub>4</sub> Min.	25 <sup>1</sup> / <sub>4</sub> Max.			
200 Amperes	7 <sup>1</sup> / <sub>4</sub>	9 <sup>1</sup> / <sub>2</sub>	6 <sup>1</sup> / <sub>2</sub>	1 <sup>1</sup> / <sub>16</sub>	5 <sup>3</sup> / <sub>4</sub>	6 <sup>1</sup> / <sub>2</sub>	¾	1 <sup>23</sup> / <sub>32</sub>	Standard Shaft	7 <sup>7</sup> / <sub>16</sub> Min.	12 <sup>1</sup> / <sub>2</sub> Max.	1	2	15 Lbs.
									Long Shaft	7 <sup>7</sup> / <sub>16</sub> Min.	25 <sup>1</sup> / <sub>4</sub> Max.			

- 1 The Adjusted Coupling Position is determined by measuring the cabinet depth and subtracting 1 1/4" ± 1/16".  
2 The Shaft Length is determined by measuring the cabinet depth and subtracting 1 1/4".



## MOUNTING THE DISCONNECT SWITCH

- Measure the cabinet depth (Dimension "J") to insure that your cabinet is within the maximum and minimum size range.
- Select desired location on enclosure surface for mounting the disconnect switch.
- From the line drawing and dimension table above, locate the mounting holes of the switch.
- Mount the disconnect switch on the enclosure mounting surface. Use 1/4" or 5/16" screws.

## MOUNTING THE ACTIVATING ROD

- Determine shaft length (Dimension "L") from table and cut uninsulated end of shaft to size.
- Insert the insulated end of the shaft through the hole in the support bracket and into the two square holes in the switch lever. Tighten set screw (or screws) to secure shaft to switch lever. Insert hitch pin furnished into hole in shaft (see side view above).
- Determine the adjusted coupling position (Dimension "K") and attach the coupling to the shaft with set screws. The word "On" and the arrow molded on the face of the coupling must be at the bottom with the switch in the "Open" position.

## MOUNTING THE HANDLE ASSEMBLY

- Using the template and dimension table as a guide, determine the point on the cover, within 1/8", at which

the center of the rod and the center of the handle assembly should meet.

- With the template located, center-punch the location of the five mounting holes. Drill the 1/4" diameter holes. Drill pilot holes for Greenlee cutters for the 1/2" and 1 1/2" diameter holes. Cut the 1/2" diameter hole with Greenlee cutter first, then the 1 1/2" diameter hole, overlapping the 1/2" diameter hole.
- Close the cover and check the coupling spear-point for alignment with the center of the large diameter hole. Adjust the support bracket, if necessary, to center the spear-point within 1/16".
- On the outside surface of the cover, mount the nameplate and handle so that the handle passes through the nameplate and enclosure cover. Use trichlorethylene or lacquer thinner to activate the adhesive on the back of the nameplate. On the inside surface of the cover the rubber washer, the spacer (used only on 14 and 16 gauge covers) and the interlock are assembled, in that order, around the protruding shoulder of the handle assembly. Tighten the three mounting screws securely.
- CAUTION: MAKE SURE THE COVER INTERLOCK LATCH SWINGS FREELY.**
- With the handle in the "Open" position, the cover should open freely. With the handle in either the "On", "Off", or "Lock" position, the cover interlock **MUST** prevent opening the cover unless the defeater is used.




**ALLEN-BRADLEY**

Industrial Control Division  
Milwaukee, Wisconsin 53204







Switch Mounting Bracket

NEMA Designation	Dimensions in Inches										K	L	Approximate Shipping Weight	
	A Wide	B High	C Deep	D	E	F	G	H	J					
100 Amperes	6 <sup>1</sup> / <sub>16</sub>	7 <sup>7</sup> / <sub>16</sub>	5 <sup>7</sup> / <sub>16</sub>	1 <sup>1</sup> / <sub>16</sub>	5	5 <sup>1</sup> / <sub>4</sub>	2 <sup>3</sup> / <sub>32</sub>	1 <sup>1</sup> / <sub>2</sub>	Standard Shaft	6 <sup>3</sup> / <sub>4</sub> Min.	12 <sup>1</sup> / <sub>4</sub> Max.	1	2	9 Lbs.
									Long Shaft	6 <sup>3</sup> / <sub>4</sub> Min.	25 <sup>1</sup> / <sub>4</sub> Max.			
200 Amperes	7 <sup>1</sup> / <sub>4</sub>	9 <sup>1</sup> / <sub>2</sub>	6 <sup>1</sup> / <sub>2</sub>	1 <sup>1</sup> / <sub>16</sub>	5 <sup>3</sup> / <sub>4</sub>	6 <sup>1</sup> / <sub>2</sub>	3 <sup>1</sup> / <sub>4</sub>	1 <sup>23</sup> / <sub>32</sub>	Standard Shaft	7 <sup>7</sup> / <sub>16</sub> Min.	12 <sup>1</sup> / <sub>2</sub> Max.	1	2	15 Lbs.
									Long Shaft	7 <sup>7</sup> / <sub>16</sub> Min.	25 <sup>1</sup> / <sub>4</sub> Max.			

1. Measure the cabinet depth and subtract 1<sup>1</sup>/<sub>16</sub>" ± 1<sup>1</sup>/<sub>16</sub>"

- 1 The Adjusted Coupling Position is determined by measuring the cabinet depth and subtracting 1 1/16" ± 1/16".
- 2 The Shaft Length is determined by measuring the cabinet depth and subtracting 1 1/8".

### MOUNTING THE DISCONNECT SWITCH

1. Measure the cabinet depth (Dimension "J") to insure that your cabinet is within the maximum and minimum size range.
2. Select desired location on enclosure surface for mounting the disconnect switch.
3. From the line drawing and dimension table above, locate the mounting holes of the switch.
4. Mount the disconnect switch on the enclosure mounting surface. Use 1/4" or 5/16" screws.

### MOUNTING THE ACTIVATING ROD

1. Determine shaft length (Dimension "L") from table and cut uninsulated end of shaft to size.
2. Insert the insulated end of the shaft through the hole in the support bracket and into the two square holes in the switch lever. Tighten set screw (or screws) to secure shaft to switch lever. Insert hitch pin furnished into hole in shaft (see side view above).
3. Determine the adjusted coupling position (Dimension "K") and attach the coupling to the shaft with set screws. The word "On" and the arrow molded on the face of the coupling must be at the bottom with the switch in the "Open" position.

### MOUNTING THE HANDLE ASSEMBLY

1. Using the template and dimension table as a guide, determine the point on the cover, within 1/8", at which

the center of the rod and the center of the handle assembly should meet.

2. With the template located, center-punch the location of the five mounting holes. Drill the 1/4" diameter holes. Drill pilot holes for Greenlee cutters for the 1/2" and 1 1/2" diameter holes. Cut the 1/2" diameter hole with Greenlee cutter first, then the 1 1/2" diameter hole, overlapping the 1/2" diameter hole.
3. Close the cover and check the coupling spear for alignment with the center of the large diameter hole. Adjust the support bracket, if necessary, center the spear-point within 1/16".
4. On the outside surface of the cover, mount the nameplate and handle so that the handle passes through the nameplate and enclosure cover. Use trichlorethylene or lacquer thinner to activate the adhesive on the back of the nameplate. On the inside surface of the cover, mount the rubber washer, the spacer (used only on 1 1/2" 16 gauge covers) and the interlock are assembled that order, around the protruding shoulder of the handle assembly. Tighten the three mounting screws securely.
5. CAUTION: MAKE SURE THE COVER INTERLOCK LATCH SWINGS FREELY.
6. With the handle in the "Open" position, the cover should open freely. With the handle in either the "Off", or "Lock" position, the cover interlock should prevent opening the cover unless the defeater is used.



**ALLEN-BRADLEY**  
Industrial Control Division  
Milwaukee, Wisconsin 53204





## Ball Bearing Units

### MOUNTING AND LUBRICATION INSTRUCTIONS

Hub City Bearing Unit performance is dependent on proper installation and lubrication where required. Failure to follow instructions may result in poor performance and short bearing life.

#### MOUNTING INSTRUCTIONS

1. For best results use turned and ground shafting, free of rough spots and burrs. If old shafting is used, locate bearing on a smooth unworn section.
2. Clean shaft and bearing bore. Coat shaft with a small amount of oil.
3. Check bearing for freedom of alignment, before mounting bearing unit on shaft.

#### A — Eccentric Collar Bearings

- 4a. Slide bearing unit and collar on the shaft. (If projecting side of bearing is to be mounted toward the machine, put the locking collar on first). Collar should be opposing thrust load. **DO NOT HAMMER THE ENDS OF THE INNER RACE.** If it is necessary to apply force in mounting, use a soft metal bar or pipe against the inner race only. Tap the bearing unit into place.
- 5a. Fit the eccentric locking collar on the projecting inner race. **TURN IT IN THE DIRECTION OF SHAFT ROTATION.** Tighten the collar securely, using a spanner or setscrew wrench. Tighten the setscrew against shaft.

#### B — Setscrew Lock Bearings

- 4b. Slide the bearing unit on the shaft. **DO NOT HAMMER THE ENDS OF THE INNER RACE.** If it is necessary to apply some force in mounting, use a soft metal bar or pipe against the inner race only. Tap the bearing unit into place. Tighten the two setscrews securely to lock bearing to shaft.

#### LUBRICATION INSTRUCTIONS

All Hub City bearing units are factory lubricated and ready for use (except for unusually severe applications). Lubricated-For-Life bearings have no grease fitting and require no additional lubrication while in use. Re-lube bearing housings have a lubrication fitting mounted on the housing and should be lubricated when used in wet or dirty applications. For normal operation there is no need to relubricate bearings at all. The following table is a general guide for relubrication. Experience will determine the best interval for each specific application.

#### LUBRICATION GUIDE

Operating Conditions	Bearing Temperatures	Grease Interval	Recommended Grease or Equivalent
Clean	32° F to 120° F	6 to 12 months	Shell Alvania #2 Texaco Multigrade #2
	120° F to 150° F	1 to 3 months	
Dirty	150° F to 200° F	1 to 4 weeks	Sun Prestige #41 Humble L 100K #2
	32° F to 150° F	Daily — 1 Week	
Moisture	32° F to 200° F	Daily — 1 Week	Shell Litholine Multi-Purpose

When lubricating bearings add grease slowly while shaft is rotating. When grease begins to come out the seals, the bearing will contain the correct amount of lubricant.

Bearings should not run in steady operation over 200° F and should not exceed 225° F for intermittent operation.

For unusual or severe applications, contact Hub City Customer Service Department.

#### REPLACEMENT OF ADAPTOR BEARINGS IN BEARING UNITS

All Hub City bearing units are fitted with self-aligning adaptor bearings which can be replaced in case of wear or damage to the original adaptor bearing. To replace bearing:

1. Loosen setscrew in locking collar or bearing.
2. Loosen locking collar, if any, from shaft by turning in direction opposite to shaft rotation.
3. Remove unit from shaft.
4. Remove collar, if any, from inner race of bearing unit.
5. Rotate bearing 90° in the housing.
6. Withdraw along the slots in the sides of the housing.
7. Inspect housing for wear or damage and replace if necessary.
8. Clean inside of housing with solvent and dry with lint-free cloth or paper towel.
9. Insert bearing in the slots.
10. Rotate bearing 90° in the housing to operating position. If the fit between the housing and bearing is loose, the housing should be replaced.
11. Replace collar, if any.
12. Remount unit on shaft following the procedure outline above.



2914 Industrial Dr., P. O. Box 1089, Aberdeen, SD 57402-1089, U.S.A.  
Phone (605) 225-0360 • Telex 29-2236 • FAX 605-225-0567





LEROY-SOMER, INC.  
560 S. HICKS RD.  
PALATINE, IL 60067  
PH. 312/359-2440  
TLX 210231

SAVINGS  
THROUGH  
EFFICIENCY

LEROY-SOMER

**ECONOGEAR®**

**ECONOGEAR®**

**ECONOGEAR®**

**ECONOGEAR®**


**ECONOGEAR®**

**ECONOGEAR®**

**ECONOGEAR®**

**ECONOGEAR®**

# ***MAINTENANCE***





## Installation

All speed reducers should be mounted on a solid foundation to support it and to isolate it from vibrations.

Remove protective coating on output shaft.


When chain drives, belt drives or open gearing are used on the output shaft of the speed reducer, great care should be taken in installation to minimize abnormal loading. Avoid hammering. Prefer preheating the parts to be mounted on the shaft. Sheave or sprocket should be mounted as close as possible to the housing to reduce overhung load. Do not over-tension the chain or the belt. Refer to manufacturer's recommendation.

Check for proper shaft parallelism.

## Lubrication

Before starting up, fill the gearbox with oil until level reaches level plug. Econogear® reducers can be used in any position. Check with following table the location of level (L), filling (F) and draining (D) plugs according to mounting position. Fit the breather supplied with the box in place of filling plug.

Oil grade: EP gear oil, viscosity 150 VG 150. AGMA #4EP. First oil change after a running period comprised between 1000 and 1500 hours. Following oil changes every 5000 hours.



CORRESPONDANCE TABLE OF THE LUBRICANTS FOUND ON THE HOME MARKET

Make	Running conditions between 15 °F and 60 °F		Running conditions between 60 °F and 165 °F	
	without backstop	with backstop	without backstop	with backstop
AGMA lubricant	# 2 EP	# 2	# 4 EP	# 4
Cities Service Co	CITGO EP Comp. # 68	Pacemaker # 68	Citgo EP Compo # 150	Pacemaker # 150
Fiske Bros. Refining	Lubriplate APG 80	Lubriplate Non. Det # 2	Lubriplate APG 90	Lubriplate STM 90
Gulf Oil Corp.	EP Lubricant HD 68	Harmony 68	EP Lubricant HD 150	Harmony 150 D
Keystone Div.	KLC - 543	KLC 543	KLC 432	KLC 432
Mobil Oil Corp.	Mobil Gear 626	Mobil DTE heavy med.	Mobil Gear 629	Mobil DTE extra heavy
Shell Oil Corp.	Omala 68	Turbo 68	Omala 150	Turbo 150
Sun Oil Corp.	Sunep 1050	Sunvis 931	Sunep 1060	Sunvis 975
Texaco, Inc.	Meropa # 1	Regal Oil PCR & O	Meropa # 2	Regal Oil GR & O



## Mounting Positions

Foot mounting single reduction		Foot mounting double and triple reduction		Flange mounting single reduction		Flange mounting double and triple reduction
SF	SC	SF	SC	OW1	OW2	OW1
SW1	SW2	SW1	SW2	OD	OW3	OD
SD	SU	SD	SU	OU	OW4	OU

plug locations - F: filling L: level D: draining

### Reducer oil capacity (us quarts)

Reducer size	Mounting position								
	SF	SW1/SW2	SC	SD	SU	OW1/OW3	OD	OU	OW2/OW4
B1	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3
C1	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4
D1	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
E1	1.5	1.9	3	1.2	1.8	1	1.9	1.8	1.9
F1	2.7	3.6	5	3.7	5.1	2.7	3.7	5.1	3.7
B2/B3	0.5	1.4	1.4	1.7	1.7	0.5	1.9	1.9	
C2/C3	1.1	2.1	2.1	3.1	3.1	1.1	3.1	3.1	
D2/D3	1.6	3.7	3.7	5.4	5.4	1.6	5.4	5.4	
E2/E3	2.3	4.7	6.9	7.9	7.9	2.4	7.9	7.9	
F2/F3	4.4	9.3	13.8	16.3	15.8	4.4	16.3	15.9	
R2/R3	9.5	23	23	38	38	9.5	38	38	
G2/G3	11.6	29	29	48	48	11.6	48	48	
H2/H3	24	58	58	100	100	24	100	100	

### Data to be supplied when ordering spare parts.

Always refer to the nameplate of the reducer, even if the unit is a gearmotor.  
Give the serial number indicated on the nameplate.

Locate on the exploded view of the unit, the part needed and give the reference number of the part.

For example:  
Econogear S/N #A20212  
Part no. 19

**ECONOGEAR®**


Designed for  
Outstanding Performance And Long Life

7

8

9

## Nomenclature B1-C1-D1-E1-F1



Ref. No.	Qty.	Item
1	1	Housing
2	1	Output shaft
3	1	Output shaft key
5	1	Oil seal
*8	1	Adjustment gage
16	1	Bearing
*18	1	Lock washer

Ref. No.	Qty.	Item
*20	1	Castle nut
21	1	Bearing
22	1	Snap ring
29	1	Gear key
35	1	Snap ring
37	1	Input pinion
38	4	Fixing threads

Ref. No.	Qty.	Item
44	1	Motor Key
44 bis	1	Pin (shank pinion)
47	1	Oil deflector
50	1	Gear
55	2	Gear washer
56	1	Fixing screw
90	1	Breather
91	1	Plug
92	1	Plug

\*For D1, E1 and F1 only


TYPES	Principal maintenance parts			
	5	8	16	21
B1	25 x 52 x 7	—	6 205	6 203
C1	30 x 62 x 7	—	6 206	6 205
D1	40 x 80 x 10	63 x 80 x 3 + 63 x 80 x gages	30 208	32 006
E1	52 x 85 x 10	63 x 80 x 3	30 209	30 208
F1	60 x 90 x 10	65 x 85 x 3,5	30 210	30 209

LEROY-SOMER, INC. 560 S. HICKS RD. • PALATINE, IL 60067 • PH. 312/359-2440 TLX 210231





## Nomenclature B2-B3-C2-C3-D2-D3



### Nomenclature B3-C3-D3 (For B2-C2-D2 take off ref. no. of axis 2:12-13-23-24-25-27-57-58)


Ref No.	Qty.	Item	Ref No.	Qty.	Item	Ref No.	Qty.	Item
1	1	Housing	22	1	Snap ring axis 3	47	1	Oil deflector
101	1	End bell	23	1	Pinion axis 2	50	1	Gear axis 1
2	1	Output shaft	24	1	Key axis 2	52	1	Snap ring axis 1
3	1	Output shaft key	25	1	Gear axis 2	53	1	Bearing axis 1
4	1	Gear key	27	1	Bearing axis 2	55	1	Washer axis 1
5	1	Oil seal	29	1	Key axis 1	56	1	Screw axis 1
6	1	"O" ring	30	1	Pinion axis 1	57	1	Screw axis 2
11	6	Fixing screw	31	1	Bearing axis 1	58	1	Washer axis 2
12	1	Snap ring (D3 type)	35	1	Snap ring	90	1	Breather
13	1	Bearing axis 2	37	1	Pinion	91	1	Plug
16	1	Bearing axis 3	38	4	Fixing threads	92	1	Plug
19	1	Gear axis 3	44	1	Motor key			
21	1	Bearing axis 3	44bis	1	Pin (shank pinion)			

Principal maintenance parts															
TYPE	5	6	16	21	31	53	TYPE	5	6	13	16	21	27	31	53
B2	30x42x8	126,72x1,78	6206 RS	6203	6302	6202	B3	30x42x8	126,72x1,78	6203	6206 RS	6203	6202	6302	6202
C2	35x52x10	133,07 x1,78	6207 RS	6204	6204	6204	C3	35x52x10	133,07x1,78	6204	6207 RS	6204	6204	6204	6204
D2	45x62x8	172x3	6209 RS	6206	6304	6205	D3	45x62x8	172x3	6304	6209 RS	6206	6205	6304	6205

LEROY-SOMER, INC. 560 S. HICKS RD. • PALATINE, IL 60067 • PH. 312/359-2440 TLX 210231



## Nomenclature E2-E3-F2-F3-R2-R3-G2-G3-H2-H3



Nomenclature E3-F3-R3-G3-H3 (for E2-F2-R2-G2-H2 take off ref. number of axis 2: 12-13-14-23-24-25-27)

Ref No.	Qty.	Item	Ref No.	Qty.	Item	Ref No.	Qty.	Item
1	1	Housing	23	1	Pinion axis 2	50	1	Gear axis 1
101	1	End Bell	24	1	Key axis 2	51	1 + x	Gages + axis 1 adjustment
2	1	Output shaft	25	1	Gear axis 2	52	1	Snap ring axis 1
3	1	Output shaft key	26*	1 + x	Gages + axis 2 adjustment	53	1	Bearing axis 1
4	1	Gear key	27	1	Bearing axis 2	55	2	Washer axis 1
5	1	Oil seal	29	1	Key axis 1	56*	1	Screw axis 1
6	1	"O" ring	30	1	Pinion axis 1	90	1	Breather
8	1 + x	Gages + axis 3 adjustment	31	1	Bearing axis 1	91	1	Plug
11	6	End Bell fixing screw	35	1	Snap ring	92	1	Plug
12	1	Snap ring axis 2	37	1	Pinion	93	1	Lifting eye bolt
13	1	Bearing 2	38	4	Fixing thread + nut			
14	1	Snap ring axis 2 (E.F.)						
16	1	Bearing axis 3	44	1	Motor key			
19	1	Gear axis 3	44bis	1	Pin (shank pinion)			
20	1	Snap ring 3 (E.F.)	47	1	Oil deflector			
21	1	Bearing axis 3	48					
22	1	Snap ring axis 3						

\*gages in front on E and gages at rear on G and H. \*2 screws on H


Principal maintenance parts															
TYPE	5	6	16	21	31	53	TYPE	5	6	13	16	21	27	31	53
E2	50x65x8/10	224.5x3	30210 + deflector	32209	30205	30205	E3	50x65x8/10	224.5x3	30205	30210 + deflector	32209	30304	6304	6205
F2	65x90x10/12	280x3	30213 + deflector	33012	32207	32207	F3	65x90x10/12	280x3	32007	30213 + deflector	33012	32206	6306	6207
R2	70x90x10	330x4	22214 + deflector	22211	32307	32208	R3	70x90x10	330x4	32307	22214 + deflector	22211	32208	30207	30207
G2	80x100x10	380x4	30216 + deflector	32211	32308	32210	G3	80x100x10	380x4	32308	30216 + deflector	32211	32210	30306	32207
H2	90x110x14	470x4	32218 + deflector	33212	32310	32212	H3	90x110x14	470x4	32310	32218 + deflector	33212	32212	30309	30309

LEROY-SOMER, INC. 560 S. HICKS RD. • PALATINE, IL 60067 • PH. 312/359-2440 TLX 210231




# Nomenclature B-C-D-E-F


C face adaptor B-C-D




C face adaptor E-F



Ref. No.	Qty.	Item
501	1	Housing
505	1	Snap ring
507	1	Bearing
509	1	Oil seal
35	1	Snap ring
37	1	Pinion
516	1	Shaft for pinion
516 bis	1	Cut on the shaft pinion
44	1	Pinion key
44 bis	1	Pin (shank pinion E-F)
517	1	Ring (D)
518	1	Snap ring (B and C)
518 bis	1	Nut and lock washer (E and F)
519	1	Bearing
521	1	Coupling



## Input shaft assembly (with or without Backstop)



For modification into Backstop, order special parts 42 and 45, first maintenance parts and Backstop kit below

Ref No.	Qty.	Item
35	1	Snap ring
37	1	Pinion
39	1	Bearing
41	1	Snap ring
42	1	Housing
43	1	Bearing
44	1	Pinion key
44 bis	1	Pin (shank pinion)
45	1	Shaft
46	1	Key
48	1	Oil seal

BACKSTOP KIT		
Ref No.	Qty.	Item
49	1	Back stop cap
66	2	snap ring (B, C and D)
	4	Snap ring (E and F)
68	1	Key
69	1	Washer
70	1	Free wheel ring
71	1	Free wheel
72	4	Cap screw

## Principal maintenance parts

Reducer Type	Code ratio	C FACE ADAPTOR			INPUT SHAFT ASSEMBLY			INPUT SHAFT ASSEMBLY WITH BACKSTOP				
		507	509	519	39	43	48	39	43	48	70	71
B1	1.2	HK1312	20x47x7	6204	6304	6204	17x30x8	6304	6304	17x30x8	281543	BF522
B2	3.4.5.6	IR10x13x12.5		6204	6205			6205				
B3	7.8			6302								
C1	1.2.3	HK1312	20x47x7	6204	6304	6204	20x30x7	6304	6304	20x30x7	281543	BF522
C2	4.5.6.7	IR10x13x12.5			6205			6205				
C3												
D1	All	6302	30x62x10	6305	6206	6305	25x40x8	6206	6305	25x40x8	261257	BF722
D2												
D3												
E1	All	32007x	32x62x10	32007x	6307	6307	35x52x10	6307	6307	35x52x10	261258	BF912
E2												
E3												
F1	0.1.2.3	30307	32x80x10	30307	6309	6309	45x62x8	6309	6309	45x62x8	261729	BF1212
F2	4.5											
F3	6.7	30208		30208								


Never put extreme pressure oil with backstop

Note: some details in mounting can vary depending on types and ratios




## Nomenclature R2-R3-G2-G3-H2-H3

Input shaft assembly



Input shaft assembly  
(with Backstop)



Ref. No.	Qty.	Item
33	1	Snap ring (R.G.)
34	1	Snap ring
35	1	Snap ring (R3-G3-H3)
36	1	Spacer
37	1	Pinion
512	1	Shank pinion
38	1	Spacer
39	1	Bearing
40	1	Spacer
41	1	Snap ring
42	1	Housing
43	1	Bearing
44	1	Pinion key
44bis	1	Pin (shank pinion)
45	1	Shaft
46	1	Key
47	1	Key
48	1	Oil seal
69	1	Ring
530	1	Oil deflector
531	1	Bearing cap
BACK STOP KIT		
49	1	Cap 0748297101
66	2	Snap ring
68	1	Key
70	1	Ring 0748297001
71	1	Free wheel
72	6	Fixing screws

Principal maintenance parts							
Ref. No. Type	Input shaft assembly			Input shaft assembly with back stop			
	39	43*	48	39	43*	48	71
R2/G2	NU 2206 E	6309/21309	55 x 68 x 8	NU 2206	6309/21309	55 x 68 x 8	U 74 7580 243 (BW 13 243)
R3/G3	NU 2205 E	6309/21309	55 x 68 x 8	NU 2205 E	6309/21309	55 x 68 x 8	U 74 7580 243 (BW 13 243)
H2	NU 2207 E	6311/21311	60 x 80 x 8	NU 2207 E	6311/21311	60 x 80 x 8	U 74 7580 243 (BW 13 243)
H3	NU 2206 E	6311/21311	60 x 80 x 8	NU 2206 E	6311/21311	60 x 80 x 8	U74 7580 243 (BW 13 243)

\*depending on load on input shaft



**LEROY-SOMER, INC.**


560 S. HICKS RD.  
PALATINE, IL 60067  
PH. 312/359-2440  
TLX 210231

305-L-4080






# ECONOGEAR 90 HOLLOW SHAFT



REF.	QTY.	DESCRIPTION	REF.	QTY.	DESCRIPTION	REF.	QTY.	DESCRIPTION
1	1	HOUSING	15		GAUGES	40		GUAGES
10	2	FLANGE	16	1	BEARING AXIS 1	41		SLEEVES
2	1	OUTPUT SHAFT	19	1	OUTPUT GEAR	42		GUAGES
4	1	OUTPUT KEY	21	1	BEARING	50	1	GEAR AXIS 1
5	2	OUTPUT SEALS	22	1	SKF NUT & WASHER	52	1	SNAP RING AXIS 1
6	2	"O" RINGS	23	1	PINION AXIS 2	53	1	BEARING AXIS 1
8	1	SNAP RING AXIS 1	24	1	KEY AXIS 2	55	1	WASHER
10	1	SPACER	25	1	SPIRAL GEAR AXIS 2	56	1	BOLT AXIS 1
11	12	BOLTS	27	1	BEARING AXIS 2	90	1	BREATHER
12	2	SNAP RING AXIS 2	29	1	KEY AXIS 1	91	5	PLUG
13	1	BEARING AXIS 2	30	1	SPIRAL PINION AXIS 1			
14	2	SPACER	31	1	BEARING AXIS 1			
			39	1	SPACER			



# Econogear 90 Parts List



**Leroy-Somer, Inc.**

560 South Hicks Road • Palatine, IL 60067

312/359-2440 • Telex 210 231

ECONOGEAR 90

SPARE PARTS PRICE LIST

WITH RECOMMENDED SPARE PARTS

DISTRIBUTED BY  
**KING BEARING, INC.**



REFERENCE QTY - DESCRIPTION

1	1	Housing
101	2	Flange
2	1	Output Shaft
4	1	Output key
5	2	Output seals
6	2	"O" ring
8	1	Snap ring gear axis 3
10	1	Spacer
11	12	Bolts
13	1	Bearing axis 2
14	2	Spacer
15		Gauges
16	1	Bearing axis 3
19	1	Output gear
21	1	Bearing axis 3

REFERENCE QTY DESCRIPTION

22	1	SKF nut & washer
23	1	Pinion axis 2
24	1	Key axis 2
25	1	Spiral gear axis 2
27	1	Bearing axis 2
29	1	Key axis 1
30	1	Spiral pinion axis 1
31	1	Bearing axis 1
39	1	Spacer
40		Gauges
41	1	Sleeve
42		Gauges
50	1	Gear axis 1
52	1	Snap ring axis 1
53	1	Bearing axis 1
55	1	Washer
56	1	Bolt axis 1
90	1	Breather
91	5	Plug

 **Leroy-Somer, Inc.**

560 South Hicks Road • Palatine, IL 60067

312/359-2440 • Telex 210 231

ECONOGear 90

SPARE PARTS PRICE LIST

WITH RECOMMENDED SPARE PARTS

 DISTRIBUTED BY  
**KING BEARING, INC.**





## Ball Bearing Units

### MOUNTING AND LUBRICATION INSTRUCTIONS

Hub City Bearing Unit performance is dependent on proper installation and lubrication where required. Failure to follow instructions may result in poor performance and short bearing life.

#### MOUNTING INSTRUCTIONS

1. For best results use turned and ground shafting, free of rough spots and burrs. If old shafting is used, locate bearing on a smooth unworn section.
2. Clean shaft and bearing bore. Coat shaft with a small amount of oil.
3. Check bearing for freedom of alignment, before mounting bearing unit on shaft.

#### A — Eccentric Collar Bearings

- 4a. Slide bearing unit and collar on the shaft. (If projecting side of bearing is to be mounted toward the machine, put the locking collar on first). Collar should be opposing thrust load. **DO NOT HAMMER THE ENDS OF THE INNER RACE.** If it is necessary to apply force in mounting, use a soft metal bar or pipe against the inner race only. Tap the bearing unit into place.
- 5a. Fit the eccentric locking collar on the projecting inner race. **TURN IT IN THE DIRECTION OF SHAFT ROTATION.** Tighten the collar securely, using a spanner or setscrew wrench. Tighten the setscrew against shaft.

#### B — Setscrew Lock Bearings

- 4b. Slide the bearing unit on the shaft. **DO NOT HAMMER THE ENDS OF THE INNER RACE.** If it is necessary to apply some force in mounting, use a soft metal bar or pipe against the inner race only. Tap the bearing unit into place. Tighten the two setscrews securely to lock bearing to shaft.

#### LUBRICATION INSTRUCTIONS

All Hub City bearing units are factory lubricated and ready for use (except for unusually severe applications). Lubricated-For-Life bearings have no grease fitting and require no additional lubrication while in use. Re-lube bearing housings have a lubrication fitting mounted on the housing and should be lubricated when used in wet or dirty applications. For normal operation there is no need to relubricate bearings at all. The following table is a general guide for relubrication. Experience will determine the best interval for each specific application.

#### LUBRICATION GUIDE

Operating Conditions	Bearing Temperatures	Grease Interval	Recommended Grease or Equivalent
Clean	32° F to 120° F 120° F to 150° F 150° F to 200° F	6 to 12 months 1 to 3 months 1 to 4 weeks	Shell Alvania #2 Texaco Multigrak #2
Dirty	32° F to 150° F 150° F to 200° F	1 to 4 weeks Daily — 1 Week	Sun Prestige #41 Humble L 100K #2
Moisture	32° F to 200° F	Daily — 1 Week	Sinclair Litholene Multi-Purpose

When lubricating bearings add grease slowly while shaft is rotating. When grease begins to come out the seals, the bearing will contain the correct amount of lubricant.

Bearings should not run in steady operation over 200° F and should not exceed 225° F for intermittent operation.

For unusual or severe applications, contact Hub City Customer Service Department.

#### REPLACEMENT OF ADAPTOR BEARINGS IN BEARING UNITS

All Hub City bearing units are fitted with self-aligning adaptor bearings which can be replaced in case of wear or damage to the original adaptor bearing. To replace bearing:

1. Loosen setscrew in locking collar or bearing.
2. Loosen locking collar, if any, from shaft by turning in direction opposite to shaft rotation.
3. Remove unit from shaft.
4. Remove collar, if any, from inner race of bearing unit.
5. Rotate bearing 90° in the housing.
6. Withdraw along the slots in the sides of the housing.
7. Inspect housing for wear or damage and replace if necessary.
8. Clean inside of housing with solvent and dry with lint-free cloth or paper towel.
9. Insert bearing in the slots.
10. Rotate bearing 90° in the housing to operating position. If the fit between the housing and bearing is loose, the housing should be replaced.
11. Replace collar, if any.
12. Remount unit on shaft following the procedure outline above.







# BALDOR

## DC MOTOR

### INSTALLATION - MAINTENANCE INSTRUCTIONS

The safety of personnel depends upon following these instructions:

#### RECEIVING:

Inspect machine before accepting shipment for any damage in transit. Shaft should turn freely with only brush and bearing friction. Any damage from transit should be reported to the carrier immediately.

#### INSTALLATION

Qualified or trained personnel should install the machine. Electrical rotating equipment can result in property damage, serious injury, or death, when improperly installed. Equipment should be installed in accordance with the National Electrical Code, local codes and with NEMA MG2, Safety Standards for Construction and Guide for Selection, Installation and Use of Electrical Motors and Generators.

**WARNING: Observe the following for safety:**

1. When eyebolts are provided, they are intended only for lifting the motor and its included motor accessories. Eyebolt must be fully tightened.
2. The machine must be grounded in accordance with the National Electrical Code and any local code.
3. Permanently guard machine against accidental contact of body parts or clothing with moving parts.
4. Shaft key must be secured before starting motor.
5. The machine should match the voltage and the load (HP and RPM) for the application.
6. Applications for motor-mounted brake should have proper safeguards provided for personnel in case of possible brake failure.
7. Remove all power services and allow machine to reach standstill prior to servicing.
8. Do not by-pass or render inoperative safeguard or protective devices.

#### MOTOR ENCLOSURE

Open drip proof motors are intended for use in clean, dry locations with access to an adequate supply of cooling air. In addition, there should be protection from or avoidance of flammable or combustible materials in the area of open-type motors as they can eject flame and / or molten metal in the event of an insulation failure. Totally enclosed motors are intended for use where moisture, dirt, and / or certain corrosive materials are present in indoor or outdoor locations. Explosion-proof motors, as indicated by the Underwriters Laboratories, Inc. label, are required for hazardous locations in accordance with the National Electrical Code.

#### MOUNTING

Foot mounted machines should be mounted to a rigid foundation to prevent excessive vibration. Shims may be required if foundation is uneven.

Flange mounted machines should be properly seated and aligned. NOTE: If improper direction of rotation is detrimental to the load, check rotation prior to connecting the motor to the load.

For V-belt drive, mount the sheave (pulley) close to the motor housing, however, allow clearance for end to end movement of shaft. Do not overtighten belts as this may cause premature bearing failure and / or shaft breakage.

Direct coupled machines should be carefully aligned and shaft should turn freely without any binding.

#### WIRING

If the motor is part of an SCR drive system, refer to the control manufacturer's diagrams and installation data. If the motor is shunt wound and not part of an SCR control system, a proper resistance starter should be used. For protection, use a fuse or circuit breaker rated at 125% of full load amperage on the nameplate. If the motor is a series or compound wound motor, refer to the connection data tag attached to the motor. If the motor is a component part of a piece of equipment, be sure to refer to the Original Equipment Manufacturer's electrical circuit information for proper connection.

The wiring, fusing, and grounding must be in accordance with the National Electrical Code and any local codes.

When the machine is connected to the load for proper direction of rotation and started, it should start quickly and run smoothly. If this is not the case, immediately shut motor off. Investigate the cause. The cause could be: low-voltage, the motor is misconnected, or the load is too great, etc.

It is recommended that the motor current be checked after it has been operating a short time and compared against nameplate current.

#### BRUSHES

Periodically, the brushes should be inspected and the brush dust blown out of the motor. If the length has been worn down 1/2" from the original length shown in renewal parts data, the brushes should be replaced. If at this time the commutator is worn or rough, the armature should be removed. The commutator should be turned in a lathe, the mica recut, and commutator polished. Reassemble, and seal the new brushes using a brush seating stone. Be sure the rocker arm is set on the neutral mark.

#### LUBRICATION

This is a double sealed ball bearing motor. The bearings have been given lubrication at the factory. No lubricant need be added.

#### LUBRICANT


Baldor motors are pre-greased normally with Shell Oil Company's "Dolium R". Several equivalent greases which are compatible with the Baldor furnished grease are Chevron Oil's "SRI No. 2" and Texaco Inc. "Premium RB".

Additional copies may be obtained at no charge by writing:  
BALDOR ELECTRIC COMPANY • P. O. BOX 2400 • FORT SMITH, ARKANSAS 72902


LBS015-




# ADJUSTMENT LOCK




# PRESSURE ADJUSTMENT



# DISASSEMBLY




# REASSEMBLY




Torque Bonnet to 40-45 FT/LBS

# MOUNTING DIMENSIONS



\* NOTE: For each additional unit mounting, hole centers increase by 66mm (2 5/8).  
For 2 units, hole cts. are 177mm (6 31/32).  
For 3 units, hole cts. are 243mm (10 11/32).




# Schrader bellows

## PREP-AIR MODULAR

Scovill


Regulator Part Nos.

	NON-RELEIVING		RELEIVING	
	WITHOUT GAUGE	WITH GAUGE	WITHOUT GAUGE	WITH GAUGE
Less Port Connectors	4569-2010	4568-2210	4569-2000	4569-2200
1/4" NPTF + Port Connectors	4562-2010	4562-2210	4562-2000	4562-2200
3/8" NPTF + Port Connectors	4563-2010	4563-2210	4563-2000	4563-2200
1/2" NPTF + Port Connectors	4564-2010	4564-2210	4564-2000	4564-2200
3/4" NPTF + Port Connectors	4566-2010	4566-2210	4566-2000	4566-2200
ANSI Symbol				



**IMPORTANT**  
Grease O-ring in port connector and body connector grooves prior to assembly.

All units are filled or removed from each other and from port blocks by releasing fastening screws and sliding upwards.



Port Connector Kit	Wall Mounting Kit
1/4" NPTF = 9452-4000 3/8" NPTF = 9453-4000 1/2" NPTF = 9454-4000 3/4" NPTF = 9456-4000	9450-1000
Comprises: 2 Port Connectors + Seals	Comprises: 2 Brackets + Unit Filing Screws


J Spring 5-80 psig	J Spring 5-125 psig	J Spring 5-250 psig
4568-7035	4568-7036	4568-7037

A O-Ring	B O-Ring	C Valve Assy.	D O-Ring	E Spring	F O-Ring Retainer	G Diaphragm Assy.	H Connector O-Rings (Not Shown)
Service Kit 4568-8000 (Relieving) and 4568-9001 (Non-Relieving)							

\* Not contained in Service Kit 4568-8001 (Non-Relieving)

# TECHNICAL INFORMATION:


Initial Pressure: 30 psig, 200 kPa  
Temperature: 15 °F to 165 °F  
Outlet Pressure Range: -10 °C + 75 °C Max.



Schrader Bellows Division


Scovill





for MECHANICAL LOCK ONLY!

ITEM	QTY.	PART NO.	DESCRIPTION
1	1	9450-1000	WALL MTG. KIT
2	2	9452-A000	1/4 NPT PORT KIT
3	1	4539-2000	FILTER
4	1	4569-2200	REGULATOR
5	1	4589-2000	LUBRICATOR
6	-	OPTIONAL	BODY CONNECTOR
	2	9450-5000	W/O PORT
	-	9450-6000	W/ PORT

 <b>ADCO</b> MANUFACTURING, INC. <small>2175 ALABAMA • BOSTON, CALIFORNIA 92027 • (609) 875-5543          TEL: 875-7771 FAX: (609) 875-7943</small>		SCALE: DATE: 8-23-89	APPROVED BY: DRAWN BY: DK
		SCHRADER BELLOWS 1A5AT616	

