

Sales Model: 3612

Build Date: 2004-01-26

Feature Codes					
Reference Number	Eng Chg	Quantity	ASM LESS	Set Type	Description
PSTSPCL	F	1	I		***SPECIAL SETTING REQUEST***
1894427	F	2	I		TURBO GP - BASIC
1793444	F	1	I		CAMSHAFT GP. - 3612 IMO
2286505	F	1	I		VALVE GP - FLOAT
0K5558	F	1	I		3610 BKW @ 1000 RPM (4841 BHP)
612DE01	F	1	I		3612 EPG
FULDSTL	F	1	I		DISTILLATE FUEL
1000RPM	F	1	I		1000 RPM
TURBO05	F	1	I		TURBOCHARGER GP-BASIC 254
SRVRHSV	F	1	I		RIGHT HAND SERVICE SIDE
ENGACC1	F	1	I		ENGINE AND ACCESSORIES
NOBASE1	F	1	I		NO BASE
FLY0021	F	1	I		FLYWHEEL-STANDARD
FLYGD04	F	1	I		FLYWHEEL & COUPLING GUARDS
LFTEYE1	F	1	I		ENGINE LIFTING EYES
BARDEV1	F	1	I		MANUAL BARRING DEVICE - 50:1
GOVEL09	F	1	I		GOV GP-2301A LOAD SHARE
ACTEGB1	F	1	I		ACTUATOR-EGB HYDRA-ELECTRIC
ACTSHT3	F	1	I		SHUTDOWN-REV ACT ENRGD TO RUN
SNGLCK1	F	1	I		SINGLE/COMBINED CIRCUIT
JWHCN01	F	1	I		JACKET WATER HEATER CONN ONLY
ANSICN1	F	1	I		ANSI ADAPT CONN-SINGLE CIRCUIT
NOWTPMP	F	1	I		NO ENGINE MTD AUX WATER PUMP
OPADRN5	F	1	I		OIL PAN DRAIN VALVE-FRONT MTD
DOFLT01	F	1	I		DUPLEX OIL FILTER
PUMPA02	F	1	I		PRELUBE-AIR DRIVEN
PUMPE21	F	1	I		PRELUBE-CONT ELEC-REMOTE MOUNT
MANFPP1	F	1	I		MANUAL FUEL PRIMING PUMP
FUFLX05	F	1	I		FLEXIBLE FUEL OUTLET CONN
FUFLX06	F	1	I		FLEXIBLE FUEL INLET CONN
DPLXFU2	F	1	I		DPLX FUEL STRAINER-CUS RMT MNT
AIA0005	F	1	I		AIR INLET ADAPTER (90 DEG)
ACLRD10	F	1	I		ACL-STANDARD DUTY-HIGH VOL-VER
EXSHD01	F	1	I		EXHAUST SOFT MANIFOLD SHIELDS
ECPSYS4	F	1	I		ECP RELAY SYS-COM PRO-CUS MNT
ECOPT1	F	1	I		ANNUNCIATOR
INSPN05	F	1	I		MECH GAGE INST PANEL-CUS MNT
TST0001	F	1	I		STANDARD FUEL CONSUMPTION TEST
TOOL013	F	1	I		PROTECTION SYSTEM CALIBRATOR
TOOL005	F	1	I		CYLINDER HEAD REPAIR TOOL GP

TOOL004	F	1	I	TURBOCHARGER TOOL GROUP
TOOL012	F	1	I	3600 SPECIALIZED TOOLING
TOOL016	F	1	I	ELECTRIC SERVICE PUMP-230V
WHFAC01	F	1	I	FACTORY WIRING-BASIC
TSTAT01	F	1	I	THERMOSTAT-50 DEG C
SWP0025	F	1	I	SHRINK WRAP PROTECTION-ENGINE
TST0006	F	1	I	CERTIFIED DYNAMOMETER TEST
SRP0034	F	1	I	STORAGE PRESERVATION
LIT0006	F	1	I	INSTALLATION DRAWINGS
LIT0002	F	6	I	ADDITIONAL SET OF LITERATURE
LIT0003	F	6	I	ADDTL SER # SPECIFIC PARTS BK
LIT0004	F	6	I	ADDITIONAL SERVICE MANUAL
LIT0005	F	6	I	ADDITIONAL TECHNICAL MANUAL
LITPAPR	F	6	I	PAPER PARTS BOOK-IN ENGLISH
MSPETEP	F	1	I	PETROLEUM EPG
50HERTZ	F	1	I	50 HERTZ
PBCNTNU	F	1	I	CONTINUOUS POWER APPLICATION
ELT0230	F	1	I	230 VAC,50 HZ,SINGLE PH POWER
ELTAIR1	F	1	I	START AIR PRESSURE
ELT0024	F	1	I	24 VOLT DC POWER
ELT0400	F	1	I	400 VAC,50 HZ, THREE PH POWER
TWOBRG4	F	1	I	TWO BEARING PCKGNG-NON FACTORY
NOACMOD	F	1	I	NO ACCESSORY MODULE
PCGTBL2	F	1	I	TERMINAL BOX LOCATION - RIGHT
DAMPGD4	F	1	I	DAMPER GUARD - STANDARD
WELDPL2	F	1	I	WELD PLATES-MTG FOOT TO BASE
GVISOCH	F	1	I	GOVERNOR ISOCRONOUS SETTING
NOEXPTK	F	1	I	NO FACTORY SUPPLIED EXP TANK
WTRCNRH	F	1	I	WATER CONNECTIONS- RIGHT HAND
R2BUILD	F	1	I	BUILD FOR RIGHT HAND WATER CNS
PUMPR01	F	1	I	PRELUBE-REDUNDANT SYSTEM
TVA0003	F	1	I	TVA NOT PERFORMED BY CAT
TRKSHIP	F	1	I	PREP FOR TRUCK SHIPMENT IN USA
SHTTRAN	F	1	I	NON-OCEANIC TRANSPORT
REQNONE	F	1	I	NO SPECIAL REQUIREMENTS
RATSPEC	F	1	I	SPECIAL RATING REQUEST

Part Numbers

Reference Number	Eng	Chg	Quantity	ASM	LESS	Set	Type	Description	BreakDown
1798988	03		1	I				CONTROL GP.	BreakDown...
0P9899			1	I				FORWARDING/INSURANCE CHARGES	BreakDown...
0P8707			1	I				QUOTE NO.-	BreakDown...
1605960	00		1	I				FILTER GP. - FUEL	BreakDown...
2154632	00		1	I				HEATER GP - COMBO	BreakDown...
1984392	01		1	I				VALVE GP. - BOOST	BreakDown...
5Z3333	00		1	I	L			***SPECIAL SETTING REQUEST****	BreakDown...
1535035	02		1	I				MOTOR GP - STG	BreakDown...
2487386			1	I				PACKAGING AR.	BreakDown...

2360711	00	1	I	L	SENDER GP. - A	BreakDown...
0V3600		1	I		3600 QUOTE REF.	BreakDown...
7E7012	26	1	I		3612 ENGINE AR.	BreakDown...
2090124	01	1	I		SWITCH GP	BreakDown...
1W0806	06	3	I		FILTER GP-CENTRIFUGAL LUBE	BreakDown...
1599606	01	1	I		LINES GP. - INSTR.	BreakDown...
1W0887	06	1	I		COOLER GP	BreakDown...
1834577	00	1	I		LINES GP. - INSTRUMENT	BreakDown...
1W9874	11	2	I		FITTING GP-EXHAUST(ADAPTER)	BreakDown...
1839634	00	1	I		LINES GP. - INSTRUMENT	BreakDown...
2W3329	07	1	I		LINES GP	BreakDown...
1844673	00	1	I		LINES GP. - INSTRUMENT	BreakDown...
2W2681	04	2	I		FITTING GP-EXHAUST (EXPANDER)	BreakDown...
1988778	02	1	I		PANEL GP. - INSTRUMENT	BreakDown...
2W2682	04	2	I		FLANGE GP-EXHAUST (SIZE 18M)	BreakDown...
3L0392		1	I		TEST - FUEL CONSUMPTION	BreakDown...
2W7889	07	2	I		FITTING GROUP - EXHAUST	BreakDown...
1630096	02	1	I		CALIBRATOR GP.	BreakDown...
7C2145	01	2	I		COVER GP	BreakDown...
9U7522	01	1	I		TOOL GP. - HEAD REPAIR	BreakDown...
7E3150	01	1	I		DRAIN GP	BreakDown...
9U6249	02	1	I		TOOL GP. - CYLINDER	BreakDown...
7W0014	02	1	I		MOTOR GP - STARTING	BreakDown...
9U6250	04	1	I		TOOL GP. - PUMP	BreakDown...
7W5890	01	1	I		FILM - ROTATION	BreakDown...
8T0820	02	1	I		GAGE - PRESSURE	BreakDown...
8N8486	04	2	I		SILENCER GP-STARTING AIR.	BreakDown...
8T3035	00	1	I		LINES GP	BreakDown...
9U5105	16	1	I		TOOL GP. - BASIC	BreakDown...
9Y9990	06	1	I		LINES GP-AIR	BreakDown...
9U5106	04	1	I		TOOL GP. - DIESEL	BreakDown...
1123432	06	1	I		MANIFOLD GP. - EXHAUST	BreakDown...
1339196	00	1	I		GAGE AS.-OIL LEVEL	BreakDown...
2075034	01	1	I		TOOL GP. - STUD TENSIONER	BreakDown...
8S8033	08	1	I		PUMP GP - HYDRAULIC (230V)	BreakDown...
1447647	05	1	I		SENSOR GP. - PARTICLE DETECTOR	BreakDown...
1449991	00	2	I		SHIELD GP. - EXHAUST	BreakDown...
1981513	06	1	I		WIRING GP.	BreakDown...
1459075	01	1	I		LINES GP. - OIL	BreakDown...
2072691	02	1	I		FITTING GP.-CABLE CONNECTION	BreakDown...
7C7785	04	1	I		REGULATOR GROUP	BreakDown...
1561015	03	1	I		LINES GP. - WATER (HPAC)	BreakDown...
5P2506	00	1	I		LITERATURE - ENGLISH	BreakDown...
1836223	00	1	I		MOUNTING GP.-CABLE TRAY	BreakDown...
1306264	02	1	I		LINES GP.-WATER(TBO COOL HPAC)	BreakDown...
2058649	01	1	I		TEST - PROCEDURE	BreakDown...
0P7921		1	I		3616 SHRINK WRAP PROTECTION.	BreakDown...
7W1543	11	1	I		FILTER GP - FUEL	BreakDown...
1W0891	04	1	I		PUMP GP-FUEL TRANSFER	BreakDown...

3L0391		1	I	TEST REPORT-CERT. DYNOMOMETER	BreakDown...
0P9032		1	I	STORAGE/PRESERVATION 3612	BreakDown...
7C1903	07	12	I	PUMP GP - FUEL INJ.	BreakDown...
0P9801		1	I	3600 INSTALLATION SERVICES	BreakDown...
7C9428	03	1	I	LINES GROUP - FUEL INJECTION	BreakDown...
0P8903		6	I	3600 ADDL SET LITERATURE	BreakDown...
1859353	00	1	I	PUMP GP. - LINES &	BreakDown...
0P8904		6	I	3600 ADDL PARTS BOOK	BreakDown...
1W0797	03	1	I	PUMP GP-EO 1 GR	BreakDown...
0P8905		6	I	3600 ADDL SERVICE MANUAL	BreakDown...
4P2335	05	12	I	HEAD GP - CYL -B	BreakDown...
0P8906		6	I	3600 ADDL TECH MANUAL	BreakDown...
7W0127	04	1	I	DAMPER GP	BreakDown...
0V1672		6	I	ENGLISH PAPER PARTS LIST	BreakDown...
7W6583	03	1	I	GUARD GP-DAMPER(2-30 " NARROW)	BreakDown...
0V1055		1	I	END USE: PETROLEUM EPG	BreakDown...
1W0898	08	1	I	MOUNTING GP - TURBOCHARGER	BreakDown...
4P7959	07	1	I	LINES GP - TURBO OIL	BreakDown...
1162764	03	2	I	TURBOCHARGER GP. - BASIC	BreakDown...
1606512	02	1	I	LINES GP. - AIR(NO SHUTOFF)	BreakDown...
1882425	03	1	I	EXHAUST GP - FLEX	BreakDown...
2W4556	07	1	I	LINES GP-FUEL FILTER (RH SERV)	BreakDown...
4P2375	09	1	I	LINES GP - FILTER	BreakDown...
2076815	02	1	I	LINES GP-OIL(CONT. PRELUBE)	BreakDown...
1398479	03	1	I	LINES GP. - INSTR.(FR RH IF)	BreakDown...
1468982	04	1	I	LINES GP.-AIR SHUTOFF(HPAC)	BreakDown...
1099717	00	1	I	MOUNTING GP.-ENGINE	BreakDown...
1238775	01	1	I	MTG. GP. - ENGINE(450MM LH)	BreakDown...
9Y9341	05	1	I	LINES GP - AIR	BreakDown...
2W2977	16	1	I	LINES GP-AIR	BreakDown...
9Y1851	00	1	I	GEAR GP - RING	BreakDown...
9Y6182	02	1	I	FLYWHEEL GROUP	BreakDown...
4P6963	00	1	I	GUARD GP - FLY	BreakDown...
1190805	03	1	I	GUARD GP. - COUPLING	BreakDown...
1749798	00	1	I	SUPPORT GP. - COUPLING GUARD	BreakDown...
7C7950	03	1	I	LIFTING GROUP	BreakDown...
2W2742	00	2	I	COVER GP - PROT. LIFT	BreakDown...
4P8034	02	1	I	BARRING GP -B	BreakDown...
4P9212	02	1	I	DRIVE GP - GOV -A	BreakDown...
4P7035	03	1	I	FASTENER GP - GOV	BreakDown...
1317757	01	1	I	CONTROL AS. - GOVERNOR(2301A)	BreakDown...
1636457	01	1	I	ACTUATOR AS.	BreakDown...
1561014	01	1	I	LINES GP. - WATER(HPAC)	BreakDown...
1346342	02	1	I	LINES GP. - JACKET WATER	BreakDown...
7C9331	09	1	I	CONNECTION GROUP	BreakDown...
1103753	03	1	I	CONNECTION GP. - WATER - ANSI	BreakDown...
1312743	02	1	I	CONNECTION GP-ANSI-COOL OUT	BreakDown...

				CC	
4W0365	01	1	I	COVER GP - (SCAVENGE PUMP)	BreakDown...
4P2268	01	1	I	DRAIN GP - OIL PAN	BreakDown...
1W0798	23	1	I	FILTER GP-OIL	BreakDown...
1W0899	07	1	I	PUMP GP - PRELUBE (AIR)	BreakDown...
2W0642	04	1	I	LINES GP-AIR(PRELUBE W/AIR ST)	BreakDown...
4W3471	04	1	I	LINES GP-AIR(PRELUBE)(FRONT)LH	BreakDown...
9Y3300	03	1	I	LINES GP-LUBE OIL(PRELUBE PMP)	BreakDown...
1716233	02	1	I	PANEL GP - CNTOR	BreakDown...
1728022	01	1	I	LINES GP. - PRELUBE	BreakDown...
2210131	00	1	I	PUMP GP.-PRELUBE(CONTINUOUS)	BreakDown...
4W0705	07	1	I	PUMP GP - FUEL PRIMING	BreakDown...
7W1841	00	1	I	HOSE ASSEMBLY	BreakDown...
7W1840	00	1	I	HOSE AS.	BreakDown...
2W2683	02	1	I	FILTER GP-PRIMARY FUEL(DUPLEX)	BreakDown...
7C7897	00	1	I	FITTING GROUP	BreakDown...
1125539	00	1	I	FITTING GP.-PRIMARY FILTER	BreakDown...
2W3333	09	2	I	ELBOW GP - AIR INLET	BreakDown...
0P1667		1	I	CATINC HANDLING CHARGE	BreakDown...
4W3618	04	2	I	ADAPTER GP-AIR CLEANER	BreakDown...
7E1341	03	1	I	LINES GP	BreakDown...
4W5982	02	2	I	GAGE GP (AIR CLEANER)	BreakDown...
1329328	00	2	I	CLEANER GP.-AIR (3 ELE EPOXY)	BreakDown...
1358087	00	1	I	SHIELD GP. - MANIFOLD SOFT 12	BreakDown...
4P9191	04	1	I	INDICATOR GP - LIQ	BreakDown...
7W1145	07	2	I	SENSOR GP - ELEC.	BreakDown...
9Y9932	03	1	I	CONTACTOR GP	BreakDown...
1210250	01	1	I	CONTACTOR GP.-LO AIR ST PR ALM	BreakDown...
1219708	06	1	I	CONTACTOR GP.-CUST. MTD- COMPL	BreakDown...
1234634	02	1	I	CONTACTOR GP.-HI DIST FUEL TEM	BreakDown...
1798980	01	1	I	INSTRUCTIONS	BreakDown...
1798990	04	1	I	PANEL GP-ELEK	BreakDown...
1798991	03	1	I	BOX GP. - JUNCTION	BreakDown...
1798992	02	1	I	BOX GP. - JUNCTION	BreakDown...
1799000	01	1	I	DIAGRAM - WIRING	BreakDown...
1917683	02	1	I	MTG GP. - INSTRUMENT PANEL	BreakDown...
1917684	02	1	I	MTG GP. - INSTRUMENT PANEL	BreakDown...
2066009	00	1	I	MOUNTING GP. - JUNCTION BOX	BreakDown...
- 1798988	03	1	I	CONTROL GP.	BreakDown...

Ship Loose

Reference Number	Eng Chg	Quantity	ASM	LESS	Set Type	Description	BreakDown
		1	S			NO PRINT	BreakDown...
0S0509		1	S			BOLT	BreakDown...
0S1587		2	S			BOLT	BreakDown...
0S1594		6	S			BOLT	BreakDown...
0S1614		4	S			BOLT	BreakDown...

0S1621	1	S	BOLT	BreakDown...
1A2029	6	S	BOLT	BreakDown...
1B5357	24	S	NUT-FULL	BreakDown...
1F7958	2	S	NUT-FULL	BreakDown...
2B0858	6	S	PLUG-PIPE	BreakDown...
2W1836	1	S	ADAPTER	BreakDown...
2W2681	1	S	*PRT-FITTING GP-	BreakDown...
2W2682	1	S	*PRT-FLANGE GP-E	BreakDown...
2W2683	1	S	*PRT-FILTER GP-P	BreakDown...
2W2742	1	S	*PRT-COVER GP-PR	BreakDown...
2W2977	1	S	*PRT-LINES GP-AI	BreakDown...
2W2988	2	S	DOWEL	BreakDown...
2W3031	2	S	FITTING-EXHAUST	BreakDown...
2W7886	2	S	FLANGE-EXHAUST	BreakDown...
2W7889	1	S	*PRT-FITTING GP-	BreakDown...
2W9281	2	S	GASKET	BreakDown...
3B7725	2	S	CAP-PIPE	BreakDown...
3S2093	5	S	STRAP-CABLE	BreakDown...
3Y7829	1	S	BOSS	BreakDown...
4M5317	1	S	BUSHING-REDUCING	BreakDown...
4P4113	1	S	HOSE AS	BreakDown...
4P6974	1	S	GUARD AS	BreakDown...
4S1936	1	S	CLIP	BreakDown...
4W3618	1	S	*PRT-ADAPTER GP-	BreakDown...
4W3637	2	S	HOSE	BreakDown...
4W5120	2	S	ADAPTER-INLET	BreakDown...
4W5421	1	S	FILTER GP-FUEL-C	BreakDown...
4W5820	2	S	INDICATOR-SERV	BreakDown...
4W5982	1	S	*PRT-GAGE GP-AIR	BreakDown...
5D4661	4	S	WASHER-HARD	BreakDown...
5H0255	2	S	BOSS	BreakDown...
5K5068	2	S	NIPPLE-PIPE	BreakDown...
5L2534	1	S	U-BOLT	BreakDown...
5L3233	2	S	FITTING-SAFETY	BreakDown...
5L4398	32	S	BOLT	BreakDown...
5N5646	1	S	HOSE AS	BreakDown...
5P0537	4	S	WASHER-HARD	BreakDown...
5P1075	3	S	WASHER-HARD	BreakDown...
5P1076	2	S	WASHER-HARD	BreakDown...
5P2428	2	S	SEAL-O-RING	BreakDown...
5P4479	1	S	ELBOW	BreakDown...
5P4983	1	S	TEE-SWIVEL	BreakDown...
5P7701	1	S	SEAL-O RING	BreakDown...
5P7815	1	S	SEAL-O RING	BreakDown...
5P8245	48	S	WASHER-HARD	BreakDown...
5T4375	1	S	HOSE AS	BreakDown...
6D3479	1	S	CLIP	BreakDown...
6G9870	1	S	HOSE AS	BreakDown...
6H1717	2	S	BOLT	BreakDown...

6I1944	1	S	GUARD AS	BreakDown...
6K0806	2	S	STRAP-CABLE	BreakDown...
6K6967	1	S	ADAPTER-PIPE	BreakDown...
6V4245	1	S	ELBOW-PIPE	BreakDown...
6V5049	2	S	SEAL-O-RING	BreakDown...
6V5137	2	S	SETSCREW-SQ HD	BreakDown...
7C0818	1	S	BRACKET	BreakDown...
7C5273	2	S	SHIM	BreakDown...
7C7785	1	S	REGULATOR GP -B	BreakDown...
7C7897	1	S	*PRT-FITTING GP	BreakDown...
7C8540	2	S	SUPPORT AS	BreakDown...
7E0028	1	S	SENDER-PRESSURE	BreakDown...
7F4283	4	S	BOLT	BreakDown...
7W1771	1	S	GUIDE	BreakDown...
7W1840	1	S	*PRT-HOSE AS.	BreakDown...
7W1841	1	S	*PRT-HOSE AS.	BreakDown...
7W8486	1	S	PLATE-ENG MTG	BreakDown...
7W8487	2	S	PLATE-ENG MTG	BreakDown...
8C7533	1	S	ADAPTER	BreakDown...
8D9671	1	S	CLIP	BreakDown...
8K6898	1	S	FITTING AS	BreakDown...
8L2786	1	S	SEAL-O-RING	BreakDown...
8M4446	8	S	SEAL-O RING	BreakDown...
8N8451	2	S	GASKET	BreakDown...
8S2332	3	S	BOLT-12 POINT HD	BreakDown...
8S8033	1	S	PUMP GP-HYD	BreakDown...
8T0820	1	S	GAGE-PRESSURE	BreakDown...
8T3035	1	S	LINES GP	BreakDown...
9L9132	2	S	WASHER-HARD	BreakDown...
9M8729	1	S	BOLT-U	BreakDown...
9P7951	9	S	COMPOUND-JOINT	BreakDown...
9R6247	3	S	STRAP-CABLE	BreakDown...
9S4191	2	S	PLUG-STOR	BreakDown...
9S8752	2	S	NUT-FULL	BreakDown...
9U5105	1	S	TOOL GP-BASIC	BreakDown...
9U5106	1	S	TOOL GP-DIESEL	BreakDown...
9U6249	1	S	TOOL GP-CYLINDER	BreakDown...
9U6250	1	S	TOOL GP-PUMP	BreakDown...
9U7522	1	S	TOOL GP-HEAD REP	BreakDown...
9X8873	24	S	BOLT	BreakDown...
9Y9341	1	S	*PRT-LINES GP-AI	BreakDown...
0307975	2	S	ELBOW	BreakDown...
0318759	1	S	CONNECTOR	BreakDown...
0616739	1	S	UNION-FLARED	BreakDown...
0618248	1	S	UNION-FLARED	BreakDown...
0904885	2	S	TIE-PUSH MOUNT	BreakDown...
1085946	1	S	*PRT-PANEL GP-CN	BreakDown...
1099717	1	S	*PRT-MTG GP-ENGI	BreakDown...
1115819	2	S	GASKET-EXHAUST	BreakDown...

1115822	2	S	GASKET-EXHAUST	BreakDown...
1125539	1	S	*PRT-FITTING GP	BreakDown...
1168535	16	S	CLAMP-BAND	BreakDown...
1190805	2	S	*PRT-GUARD GP-CP	BreakDown...
1219708	1	S	*PRT-CONTACTOR G	BreakDown...
1234634	1	S	*PRT-CONTACTOR G	BreakDown...
1267252	1	S	*PRT-MTG GP-CONT	BreakDown...
1317757	1	S	*PRT-CONTROL AS-	BreakDown...
1329328	1	S	*PRT-CLEANER GP-	BreakDown...
1329332	2	S	CLEANER GP-AIR-B	BreakDown...
1449991	2	S	SHIELD GP-EXH -B	BreakDown...
1468982	1	S	*PRT-LINES GP-AI	BreakDown...
1580473	1	S	BRACKET	BreakDown...
1605960	1	S	*PRT-FILTER GP-F	BreakDown...
1630096	1	S	CALIBRATOR GP	BreakDown...
1716233	1	S	*PRT-PANEL GP-CN	BreakDown...
1728022	1	S	*PRT-LINES GP-PR	BreakDown...
1748976	2	S	LEG AS	BreakDown...
1749012	2	S	LEG AS	BreakDown...
1749798	1	S	*PRT-SUPPORT GP-	BreakDown...
1798980	1	S	*PRT-INST (RELA	BreakDown...
1798990	1	S	PANEL GP-ELEK	BreakDown...
1799000	1	S	*PRT-DIAGRAM WI	BreakDown...
1853545	16	S	PROTECTOR-STUD	BreakDown...
1917683	1	S	*PRT-MTG GP-INST	BreakDown...
1917684	1	S	*PRT-MTG GP-INST	BreakDown...
1923226	2	S	BRACKET AS	BreakDown...
1988778	1	S	*PRT-PANEL GP-IN	BreakDown...
1995776	1	S	PLATE-CONTACTOR	BreakDown...
2075034	1	S	TOOL GP-STUD TEN	BreakDown...
2089471	2	S	BELLOWS AS	BreakDown...
2154632	1	S	HEATER GP-COMBO	BreakDown...
2210131	1	S	*PRT-PUMP GP-PRE	BreakDown...
REN95970	1	S	SMGP	BreakDown...
SEBU6965	1	S	OMM	BreakDown...
SEBU6984	1	S	SUPP	BreakDown...
SEBU7003	1	S	LUBE	BreakDown...
SEBU7632	1	S	OMM	BreakDown...
SENR3585	1	S	SRVMA	BreakDown...
SENR3590	14	S	SRVMA	BreakDown...
ESO	1	S	(PRNT ESO COPY)	BreakDown...
PML	1	S	*REQUIRED DECALS	BreakDown...

Adjustments

Reference Number	Eng Chg	Quantity	ASM	LESS	Set Type	Description	BreakDown
1W0023	17	1				HSG GP-FRT	BreakDown...
1W0027	09	8				COVER GP-VALVE	BreakDown...
1W0789	18	12				MECHANISM GP	BreakDown...
1W0790	09	1				GEAR GP-FRT.	BreakDown...

1W0797	03	1	PUMP GP-ENG O	BreakDown...
1W0798	23	1	FILTER GP-OIL	BreakDown...
1W0804	08	1	VALVE GP-PRIORIT	BreakDown...
1W0806	06	3	FILTER GP-CENTRI	BreakDown...
1W0876	07	1	LINES GP	BreakDown...
1W0887	05	1	COOLER GP-ENG O	BreakDown...
1W0891	04	1	PUMP GP - FUEL	BreakDown...
1W0898	08	1	MTG GP-TURBO	BreakDown...
1W0899	07	1	PUMP GP-PRELUBE	BreakDown...
1W1952	01	2	BRACKET AS	BreakDown...
1W2470	09	12	LIFTER GP	BreakDown...
1W3382	05	1	COVER GP	BreakDown...
1W3645	09	4	VALVE GP-XPL RLF	BreakDown...
1W4191	07	3	FILTER GP-CNTFGL	BreakDown...
1W4776	00	1	PUMP GP-BSC	BreakDown...
1W8260	01	1	BRACKET AS	BreakDown...
1W8410	03	12	SHAFT AS	BreakDown...
1W9874	11	2	FITTING GP-EXH-A	BreakDown...
2W0642	04	1	LINES GP - AIR	BreakDown...
2W2681	04	2	FITTING GP-EXH	BreakDown...
2W2682	04	2	FLANGE GP-EXH	BreakDown...
2W2683	02	1	FILTER GP-PRIME	BreakDown...
2W2742	00	2	COVER GP-PROTECT	BreakDown...
2W2945	02	1	LUBRICATOR GP	BreakDown...
2W2977	16	1	LINES GP-AIR	BreakDown...
2W3329	07	1	LINES GP-OIL	BreakDown...
2W3333	08	2	ELBOW GP-AIR	BreakDown...
2W4556	07	1	LINES GP-FUEL	BreakDown...
2W7889	07	2	FITTING GP-EXH	BreakDown...
4P2268	01	1	DRAIN GP-OIL PAN	BreakDown...
4P2335	05	12	HEAD GP-CYLINDER	BreakDown...
4P2351	06	1	HOUSING AS-FRONT	BreakDown...
4P2375	10	1	LINES GP-FILTER	BreakDown...
4P6963	00	1	GUARD GP-FLYWHL	BreakDown...
4P7030	06	1	CONTROL GP-FUEL	BreakDown...
4P7035	03	1	FASTENER GP-GOV.	BreakDown...
4P7959	07	1	LINES GP-TURBO	BreakDown...
4P8027	00	1	HOUSING AS.	BreakDown...
4P8034	02	1	BARRING GP	BreakDown...
4P8035	00	1	BRACKET AS	BreakDown...
4P8036	02	1	REDUCER GP	BreakDown...
4P9185	00	1	COVER AS	BreakDown...
4P9191	04	1	DETECTOR GP.	BreakDown...
4P9212	02	1	DRIVE GP-GOV	BreakDown...
4W0012	01	1	MOUNTING GP	BreakDown...
4W0345	06	12	PLUG GP	BreakDown...
4W0365	01	1	COVER GP	BreakDown...
4W0379	01	2	INDICATOR AS.	BreakDown...
4W0543	03	4	COVER GP	BreakDown...

4W0698	01	1	COVER GP	BreakDown...
4W0705	07	1	PUMP GP-FUEL	BreakDown...
4W2100	02	1	VALVE GP-PRES	BreakDown...
4W3471	04	1	LINES GP - AIR	BreakDown...
4W3618	04	2	ADAPTER GP-AIR-C	BreakDown...
4W4544	05	1	PUMP GP-BSC	BreakDown...
4W5421	02	1	FILTER GP-FUEL-C	BreakDown...
4W5982	02	2	GAGE GP-AIR CLEA	BreakDown...
4W6273	01	1	SUPPORT AS	BreakDown...
4W6277	02	6	SUPPORT AS	BreakDown...
5P2506	00	1	LITERATURE GP-E	BreakDown...
5P3591	06	3	ADAPTER GP	BreakDown...
7C1124	00	1	TUBE AS	BreakDown...
7C1128	00	2	SHAFT AS	BreakDown...
7C1903	07	12	PUMP GP-F INJ-G	BreakDown...
7C2122	02	2	DAMPER GP-BSC	BreakDown...
7C2145	01	2	COVER GP-EXH.ADA	BreakDown...
7C7785	04	1	REGULATOR GP-TEM	BreakDown...
7C7897	00	1	FITTING GP	BreakDown...
7C7950	03	1	LIFTING GP	BreakDown...
7C9331	09	1	CONNECTION GP	BreakDown...
7C9428	03	1	LINES GP-FUEL	BreakDown...
7E1341	03	1	LINES GP INST	BreakDown...
7E1659	01	1	CAP GP OIL	BreakDown...
7E3150	01	1	DRAIN GP WATER	BreakDown...
7E3974	00	1	PUMP GP-HAND	BreakDown...
7E4385	01	1	HOUSING AS.	BreakDown...
7E7012	26	1	ENGINE AR	BreakDown...
7E7061	00	2	SHAFT AS	BreakDown...
7E7155	00	4	JOURNAL AS	BreakDown...
7E7156	00	8	JOURNAL AS-CAM	BreakDown...
7E7157	00	8	JOURNAL AS-CAM	BreakDown...
7E7166	00	2	SHAFT AS-CAM	BreakDown...
7E8179	08	2	PUMP GP-WATER -B	BreakDown...
7E8181	03	2	PUMP GP-WATER	BreakDown...
7E8307	00	2	FLANGE AS	BreakDown...
7E9610	06	1	SEAL GP.	BreakDown...
7E9630	08	1	HOUSING GP.	BreakDown...
7W0127	04	1	DAMPER GP.	BreakDown...
7W0146	09	1	PAN GP-OIL	BreakDown...
7W0522	02	1	LUBRICATOR GP	BreakDown...
7W1145	07	2	SENSOR GP-ELEC.	BreakDown...
7W1281	04	1	PUMP GP-F TFR	BreakDown...
7W1543	11	1	FILTER GP-FUEL	BreakDown...
7W1840	00	1	HOSE AS.	BreakDown...
7W1841	00	1	HOSE ASSEMBLY	BreakDown...
7W2970	01	1	SUPPORT AS	BreakDown...
7W5890	01	1	FILM - ROTATION	BreakDown...
7W5934	05	1	BREATHER GP	BreakDown...

7W6062	02	1	COVER GP	BreakDown...
7W6583	03	1	GUARD GP-DAMPER	BreakDown...
8N9071	00	2	VALVE AS	BreakDown...
8S8033	08	1	PUMP GP - HYDRAU	BreakDown...
8T0820	02	1	GAGE - PRESSURE	BreakDown...
8T3035	00	1	LINES GP	BreakDown...
9U5105	13	1	TOOL GP. - BASIC	BreakDown...
9U5106	04	1	TOOL GP. - DIESE	BreakDown...
9U6249	02	1	TOOL GP. - CYLIN	BreakDown...
9U6250	04	1	TOOL GP. - PUMP	BreakDown...
9U7522	00	1	TOOL GP. - HEAD	BreakDown...
9Y1851	00	1	GEAR GP-RING	BreakDown...
9Y3300	03	1	LINES GP-LUBE O	BreakDown...
9Y6182	02	1	FLYWHEEL GP	BreakDown...
9Y9341	04	1	LINES GP-AIR	BreakDown...
9Y9926	00	1	GUIDE GP-O LEVEL	BreakDown...
9Y9927	03	1	FILLER GP OIL	BreakDown...
9Y9932	03	1	CONTACTOR GP	BreakDown...
9Y9990	06	1	LINES GP-AIR	BreakDown...
1099717	00	1	MTG GP-ENGINE	BreakDown...
1103753	03	1	CONNECTION GP	BreakDown...
1123432	06	1	MANIFOLD GP-EXH	BreakDown...
1125539	00	1	FITTING GP	BreakDown...
1190805	03	1	GUARD GP-CPLG	BreakDown...
1210243	00	1	CONTACTOR GP	BreakDown...
1210244	01	1	CONTACTOR GP	BreakDown...
1210245	01	1	CONTACTOR GP	BreakDown...
1210246	01	1	CONTACTOR GP	BreakDown...
1210247	01	1	CONTACTOR GP	BreakDown...
1210250	01	1	CONTACTOR GP	BreakDown...
1210597	04	1	DETECTOR GP-LIQ	BreakDown...
1219708	06	1	CONTACTOR GP	BreakDown...
1234629	01	1	CONTACTOR GP	BreakDown...
1234630	01	1	CONTACTOR GP	BreakDown...
1234631	01	1	CONTACTOR GP	BreakDown...
1234632	01	1	CONTACTOR GP	BreakDown...
1234633	01	1	CONTACTOR GP	BreakDown...
1234634	02	1	CONTACTOR GP	BreakDown...
1238775	01	1	MOUNTING GP	BreakDown...
1254340	01	1	DETECTOR GP-LIQ	BreakDown...
1271119	00	1	MTG GP-ENGINE	BreakDown...
1285682	03	12	ARM GP-V ROCKER	BreakDown...
1306264	02	1	LINES GP-WATER	BreakDown...
1312743	02	1	CONNECTION GP	BreakDown...
1317757	01	1	CONTROL AS. - GO	BreakDown...
1329328	00	2	CLEANER GP-AIR	BreakDown...
1329332	01	2	CLEANER GP-AIR	BreakDown...
1339196	00	1	GAGE AS.-OIL LEV	BreakDown...
1346342	02	1	LINES GP-WATER	BreakDown...

1358087	00	1	SHIELD GP. - MAN	BreakDown...
1371382	00	1	GEAR AS	BreakDown...
1398479	03	1	LINES GP-INSTR	BreakDown...
1447647	05	1	SENSOR GP	BreakDown...
1449991	00	2	SHIELD GP. - EXH	BreakDown...
1459075	01	1	LINES GP-ENG OIL	BreakDown...
1468982	04	1	LINES GP-AIR	BreakDown...
1490481	05	1	BLOCK GP-CYL	BreakDown...
1490560	02	1	GEAR GP-REAR	BreakDown...
1490566	00	1	COVER GP	BreakDown...
1535035	02	1	MTG GP-MOTOR -A	BreakDown...
1561014	01	1	LINES GP-WATER	BreakDown...
1561015	02	1	LINES GP-WATER	BreakDown...
1599606	01	1	LINES GP-INSTR	BreakDown...
1605960	00	1	FILTER GP-FUEL-E	BreakDown...
1606512	01	1	LINES GP-AIR	BreakDown...
1630096	00	1	CALIBRATOR GP.	BreakDown...
1636457	01	1	ACTUATOR AS.	BreakDown...
1716233	02	1	PANEL GP-CNTOR	BreakDown...
1728022	01	1	LINES GP-PRELUBE	BreakDown...
1749798	00	1	SUPPORT GP-GD	BreakDown...
1756341	02	12	HEAD GP-CYL BSC	BreakDown...
1793444	01	1	CAMSHAFT GP-S	BreakDown...
1793446	00	1	CAMSHAFT AS	BreakDown...
1793447	00	1	CAMSHAFT AS	BreakDown...
1798968	01	1	DOOR GP-ELEK	BreakDown...
1798980	01	1	INSTRUCTIONS	BreakDown...
1798988	03	1	CONT GP	BreakDown...
1798990	04	1	PANEL GP-ELEK	BreakDown...
1798991	03	1	BOX GP-JUNCTION	BreakDown...
1798992	02	1	BOX GP-JUNCTION	BreakDown...
1799000	01	1	DIAGRAM - WIRING	BreakDown...
1834577	00	1	LINES GP-INSTR	BreakDown...
1836223	00	1	MTG GP-TRAY	BreakDown...
1839634	00	1	LINES GP-INSTR	BreakDown...
1844673	00	1	LINES GP-INSTR	BreakDown...
1855775	03	1	AFTERCOOLER GP-B	BreakDown...
1859353	00	1	PUMP GP-LINES	BreakDown...
1882425	03	1	EXHAUST GP-FLEX	BreakDown...
1894427	01	2	TURBO GP - BASIC	BreakDown...
1895746	00	2	SENSOR GP-SPD	BreakDown...
1915424	01	1	CRANKSHAFT GP	BreakDown...
1917683	02	1	MTG GP-INSTR	BreakDown...
1917684	02	1	MTG GP-INSTR	BreakDown...
1934652	00	1	SHUT-OFF GP-AIR	BreakDown...
1981513	06	1	WIRING GP	BreakDown...
1982731	02	1	MONITOR AS	BreakDown...
1984392	01	1	VALVE GP-BOOST	BreakDown...
1984394	01	1	VALVE GP-BOOST	BreakDown...

1988778	02	1	PANEL GP-INSTR	BreakDown...
2066009	00	1	MTG GP-JCT BOX	BreakDown...
2072691	02	1	FITTING GP	BreakDown...
2075034	01	1	TOOL GP. - STUD	BreakDown...
2076815	02	1	LINES GP-OIL	BreakDown...
2090124	01	1	SWITCH GP	BreakDown...
2154632	00	1	HEATER GP - COMB	BreakDown...
2210131	00	1	PUMP GP.-PRELUBE	BreakDown...
2249090	01	12	INJECTOR GP-FUEL	BreakDown...
2286505	02	1	VALVE GP-FLOAT	BreakDown...
2295867	01	1	STRAINER GP	BreakDown...
2360711	00	1	SENDER GP-A	BreakDown...
2365927	00	12	PISTON GP-ROD&	BreakDown...
2487386	00	1	PACKAGING AR.	BreakDown...