

O/S No. V69030

COUNTY SANITATION DISTRICTS OF LOS ANGELES COUNTY

STEAM TURBINE GENERATOR SETS FOR
COVER-GREENFIELD SLUDGE DEHYDRATION/ENERGY RECOVERY SYSTEM
AT THE JOINT WATER CONTROL PLANT
CONDENSING UNIT AND BACKPRESSURE UNIT

OPERATION AND MAINTENANCE MANUAL VOL. 4

CONTENTS

	VOL.No.
I. CONDENSING T/G UNIT	1
1. STEAM TURBINE AND AUXILIARIES	
2. SYNCHRONOUS GENERATOR AND ACCESSORIES	
3. CONDENSER	
4. VACUUM PUMP	
II. BACK PRESSURE T/G UNIT	2
1. STEAM TURBINE AND AUXILIARIES	
2. SYNCHRONOUS GENERATOR AND ACCESSORIES	
III. ELECTRICAL EQUIPMENT	3
IV. INSTRUMENTATION	4

DECEMBER 1990

FUJI ELECTRIC CO., LTD.

CONTENTS (Vol. 4)

No.	Name	Drawing No.
IV. INSTRUMENTATION		
1) TRANSMITTERS		
1.	Teleperm pressure transmitter (Type : FBC)	INF-TN2FBCa-E
2.	Teleperm diff. pressure transmitter (Type : FFC)	INF-TN2FFCa-E
2) CONVERTERS AND AMPLIFIERS		
1.	Teleperm distributor (Type : PXM)	INP-TN1PXM-E
2.	Teleperm EMF converter (Type : PRA)	INP-TN5PRA-E
3.	Teleperm adder (Type : PRB)	INP-TN5PRB-E
4.	Teleperm isolator (Type : PRF)	INP-TN5PRFa-E
5.	Teleperm isolated signal converter (Type : PRL)	INP-TN1PRLa-E
6.	Teleperm alarm unit (Type : PRP)	INP-TN5PRP-E
7.	Teleperm auto selector (Type : PRJ)	INP-TN5PRJ-E
3) Indicators and recorders		
1.	Teleperm moving coil type indicator (Type : PBA)	INP-TN500404-E/1
2.	Wide scale self-balancing recorder new kers (Type : PGN, PGV)	INP-TN2PGNb-E
3.	Alarm unit for PGN (Type : PHP)	INP-TN56065-E/1
4) CONTROLLERS		
1.	Compact controller E (continuous output) (Type : PMA)	INP-TN2PMA(C)a-E
5) INSTRUMENT POWER SUPPLIERS		
1.	Power supply (Type : PXJ5)	INP-TN1PXJ5-E

No.	Name	Drawing No.
6)	TURBINE SUPERVISORY INSTRUMENTS	
1.	Instrument rack Model VM-8H	6686-004
2.	Display power supply unit Model VM-8P1	6686-045
3.	Digital tachometer unit Model 2286-003	6687-006
4.	Dual zero speed monitor unit Model VM-8S2	6686-
5.	Eccentricity P-P monitor unit Model VM-8C2	6687-001
6.	Ramp differential expansion monitor unit Model VM-8D4	6687-002
7.	Dual thrust monitor unit Model VM-8T2	6687
8.	Dual vibration monitor unit Model VM-8K2	6687-003
9.	Dual seismic monitor unit Model VM-8U2	6687-005
10.	First out indicator Model 9086-005	6687-015
11.	Relay module unit Model VM-8Y1	6686-009
12.	Relay module unit Model VM-8Y2	6686-010
13.	Relay module unit Model VM-8Y3	6686-048
14.	Relay module unit Model VM-8Y5	6686-012
15.	Relay module unit Model VM-8Y6	6686-013
7)	Reference drawing	
(1)	For condenser	
1.	Instrumentation-board's drawings	TS461701
(2)	For back pressure	
1.	Instrumentation-board's drawings	TS461702