


PEL-88-100-A



Ref. #	Model #	Generic Part #	Eng. Part #	Description
1	PEL-88 , 100-A		21-013-064	Deck 24" x 19"
2	PEL-88 , 100-A		42-513-002	Deck Assembly
3	PEL-88 , 100-A		20-110-008	Roller with Nyloc Nut 5/16-18
4	PEL-88 -A		42-145-001	Nut ACME Threaded
4	PEL-100-A		42-145-002	Nut ACME Threaded
5	PEL-88 , 100-A		42-024-002	Cover Top Mast
6	PEL-88 , 100-A		16-132-070	Swivel Caster NO BRAKE
7	PEL-88 , 100-A		16-132-071	Swivel Caster With Brake
8	PEL-88 , 100-A		21-641-003	Drive Assembly Pel-88-A - Screw Drive
8	PEL-88 , 100-A		21-641-004	Drive Assembly Pel-100-A- Screw Drive
9	PEL-88 , 100-A		42-525-001	Handle Assembly
10	PEL-88 , 100-A		15-025-006	Handle Grip
11	PEL-88 , 100-A		PEL-A-HEC	Handle End Cap
12	PEL-88 , 100-A		21-156-002	Controller, Touchpad
13	PEL-88 , 100-A		21-139-001	Battery (12 v each)
14	PEL-88 , 100-A		21-034-009	Battery Charger Replaced 21-034-002
15	PEL-88 , 100-A		21-156-004	Motor Controller
16	PEL-88 , 100-A		42-024-001	Power Unit Cover

