Thompson Scale Company

Weighing Systems & Industrial Controls

Model 5297 Universal Filler Controller

14.94"

10.0"

5297
UNIVERSAL FILLER

NET 50.98 LB

| ZERO | G/N | TARE | UNITS | PRINT |

7	8	9
MENU/RUN			Esc
4	5	6
1	2	3
FILLER/SCALE			Enter
—	0	.

START   STOP/ABORT

FRONT PANEL & ENCLOSURE
VIEW

CPU CARD
470

CPU TO
FRONT
PANEL
INTEFACE

RESET

INDICATOR

PRINTERS

1
2
3
4
5
6
7
8

REMOTES

LOAD
CELL
DIGITIZER
474

EX+
REF+
SIG+
SIG−
REF−
EX−
GND
A0
A1
COM

1
2
3
4
5
6
7
8
9
10

120 VAC
INPUTS

1
2
3
4
5
6
7
8

L2
A1
A0
COM

120 VAC
OUTPUTS

1
2
3
4
5
6
7
8
9
10

L2
L1

POWER SUPPLY
472

+5VDC

−5VDC

24VDC

L1−OUT ON
WHEN LIT

ON

OFF

L1−IN
L1−OUT
L2

5297 CONTROLLER
BACK PANEL VIEW