Dividella

Pharma Packaging Technology

The Dividella **Sumpack**





Range of formats:

min. 70 x 30 x35 mm max. 270 x 175 x 135 mm

Pack contents:

Cylindrical glass, synthetic and aluminium objects, especially for the pharmaceutical industry.

Range of volumes:

1 - 500 ml, special sizes to order.

Output:

Max. 800 objects/min.

Packaging:

Printed or plain pre-formed paperboard trays, cartons or Machine size: thermoform trays .Pre-erected printed or plain open top approx. 500 x 2500 x 1800 mm trays or cartons with lid flat pre-glued crash-lock bottom (depending on configuration) cartons.

Application:

Semi- and fully automatic SumPack machine for automatic grouping and packing in variousmultipacks.

Method of operation:

The objects are either fed from a labeller or from cassettes, with automatic grouping and inserting of the items in corresponding packaging, using vacuum technology for product protection, insertion of leaflets as well as presence checker (for product and leaflet).

Additional equipment:

Leaflet inserter, multiple leaflet inserter, presence checker for product and leaflets, barcode reading system for pack and leaflet, hot foil system, carton erecting machine, carton sealing unit with or without evident seal.

Format change:

10 - 30 min. (2 Persons)







